# **SCH-r500 Series**

PORTABLE QUAD-BAND MOBILE PHONE

User Manual
Please read this manual before operating your
phone, and keep it for future reference.



# **Intellectual Property**

All Intellectual Property, as defined below, owned by or which is otherwise the property of Samsung or its respective suppliers relating to the SAMSUNG Phone, including but not limited to, accessories, parts, or software relating there to (the "Phone System"), is proprietary to Samsung and protected under federal laws, state laws, and international treaty provisions. Intellectual Property includes, but is not limited to, inventions (patentable or unpatentable), patents, trade secrets, copyrights, software, computer programs, and related documentation and other works of authorship. You may not infringe or otherwise violate the rights secured by the Intellectual Property. Moreover, you agree that you will not (and will not attempt to) modify, prepare derivative works of, reverse engineer, decompile, disassemble, or otherwise attempt to create source code from the software. No title to or ownership in the Intellectual Property is transferred to you. All applicable rights of the Intellectual Property shall remain with SAMSUNG and its suppliers.

# Samsung Telecommunications America (STA), LLC

Headquarters: Customer Care Center:

1301 E. Lookout Drive 1000 Klein Rd. Richardson, TX 75082 Plano, TX 75074

Toll Free Tel: 1.888.987.HELP (4357)

Internet Address: http://www.samsungusa.com

©2008 Samsung Telecommunications America, LLC is a registered trademark of Samsung Electronics America, Inc. and its related entities

Do you have questions about your Samsung Mobile Phone?

For 24 hour information and assistance, we offer a new FAQ/ARS System (Automated Response System) at:

www.samsungwireless.com/support

GH68-18317

Printed in Korea.

Licensed by Qualcomm Incorporated under one or more of the following patents: U.S. Patent No. 4, 901, 307; 5, 056, 109; 5, 099, 204; 5, 101, 501; 5, 103, 459; 5, 107, 225; 5, 109, 390.

T9 Text Input is licensed by Tegic Communications and is covered by U.S. Pat. 5,818,437; U.S. Pat. 5,953,541; U.S. Pat. 6,011,554 and other patents pending.

Openwave® is a registered Trademark of Openwave, Inc.

RSA® is a registered Trademark RSA Security, Inc.

The Bluetooth® word mark, figure mark (stylized "B Design"), and combination mark (Bluetooth word mark and "B Design") are registered trademarks and are wholly owned by the Bluetooth SIG.

microSD<sup>TM</sup> and the microSD logo are Trademarks of the SD Card Association.

# **Disclaimer of Warranties; Exclusion of Liability**

EXCEPT AS SET FORTH IN THE EXPRESS WARRANTY CONTAINED ON THE WARRANTY PAGE ENCLOSED WITH THE PRODUCT, THE PURCHASER TAKES THE PRODUCT "AS IS", AND SAMSUNG MAKES NO EXPRESS OR IMPLIED WARRANTY OF ANY KIND WHATSOEVER WITH RESPECT TO THE PRODUCT, INCLUDING BUT NOT LIMITED TO THE MERCHANTABILITY OF THE PRODUCT OR ITS FITNESS FOR ANY PARTICULAR PURPOSE OR USE; THE DESIGN, CONDITION OR QUALITY OF THE PRODUCT; THE PERFORMANCE OF THE PRODUCT; THE WORKMANSHIP OF THE PRODUCT OR THE COMPONENTS CONTAINED THEREIN; OR COMPLIANCE OF THE PRODUCT WITH THE REQUIREMENTS OF ANY LAW, RULE, SPECIFICATION OR CONTRACT PERTAINING THERETO. NOTHING CONTAINED IN THE INSTRUCTION MANUAL SHALL BE CONSTRUED TO CREATE AN EXPRESS OR IMPLIED WARRANTY OF ANY KIND WHATSOEVER WITH RESPECT TO THE PRODUCT. IN ADDITION, SAMSUNG SHALL NOT BE LIABLE FOR ANY DAMAGES OF ANY KIND RESULTING FROM THE PURCHASE OR USE OF THE PRODUCT OR ARISING FROM THE BREACH OF THE EXPRESS WARRANTY, INCLUDING INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES, OR LOSS OF ANTICIPATED PROFITS OR BENEFITS.

# **Table of Contents**

Section 1: Getting Started4	Menu Navigation
Understanding this User Manual	Navigate Using Shortcuts
Activating Your Phone	Section 5: Entering Text3
Charging the Battery	Text Entry Modes
Setting Up Your Voicemail	7 Entering Text in Alpha (Abc) Mode
Memory Card (Optional)	7 Entering Text in T9 Word Mode
Section 2: Understanding Your Phone	Entering Upper and Lower Case Letters
Features of Your Phone	Entering Numbers
Closed View of Your Phone	Entering Symbols
Front Open View of Your Phone	Section 6: Understanding Your Contacts 3
Command Keys	2 Your Contacts List
Understanding the Display Screen14	Adding a New Contacts Entry
Your Phone's Modes	Finding a Contacts Entry
Section 3: Call Functions18	Editing an Existing Contact Entry4
Making a Call — Number Entry Dialing	Speed Dial Numbers4
Making a Call — Speed Dialing19	Renaming a Contacts Group
Making a Call — Quick Search Dialing	Deleting a Contacts Entry
Making a Call — Voice Dialing20	) Memory Info
Answering a Call	Section 7: Messaging4
Ignoring a Call22	Accessing Your Messages4
Adjusting the Call Volume22	Creating and Sending New Messages4
Calls Log	2 Message Send Options
Roaming	Receiving New Messages
Section 4: Menu Navigation28	Voicemail

Message Folders	51
Erasing Messages	55
Message Settings	56
Section 8: Browser	57
Browser	57
Launching Browser	57
Using Browser	57
Using Links	58
How Browser Keys Work	58
Section 9: Brew	59
Finding Applications	59
Section 10: Camera	60
Taking Pictures and Videos	60
Screen Layouts	63
Saving Pictures and Videos	65
Camera Options	65
Camcorder Options	72
Zoom	77
Brightness	77
The Photo Gallery	77
The Video Gallery	78
Point, Click, and Send Pictures and Videos	79
Section 11: Multimedia	81
Accessing Multimedia	81
Music Player	
My Images	84
• •	

My Videos
My Ringtones 8
My Sounds
Section 12: Tools/Utilities9
Tools/Utilities Menu
Bluetooth
Calendar
Memo Pad
Alarm Clock
World Time
Calculator
Stop Watch 9
Converter
Tip Calculator
Section 13: Voice SVC10
Launching Voice SVC
Voice Commands
Voice Settings
Section 14: Changing Your Settings 10
Accessing Your Settings
Location
Display Settings
Sounds Settings
Call Settings
Phone Settings
Memory Info

Phone into	125
Section 15: Health and Safety Information	127
Health and Safety Information	127
Samsung Mobile Products and Recycling	128
UL Certified Travel Adapter	128
Consumer Information on Wireless Phones	129
Road Safety	134
Responsible Listening	136
Operating Environment	137
Using Your Phone Near Other Electronic Devices	138
FCC Hearing-Aid Compatibility (HAC) Regulations for Wil	reless
Devices	138
Potentially Explosive Environments	140
Emergency Calls	140
FCC Notice and Cautions	141
Other Important Safety Information	142
Product Performance	142
Availability of Various Features/Ring Tones	143
Battery Standby and Talk Time	143
Battery Precautions	143
Care and Maintenance	145
Section 16: Warranty Information	146
Standard Limited Warranty	146
Index	

# **Section 1: Getting Started**

This section explains how to start using your Samsung r500 phone by getting an understanding of how this manual is put together, activating your service, and setting up your voice mail.

### **Understanding this User Manual**

The chapters of this manual generally follow the same order as the menus and sub-menus in your phone. A robust index for quick reference to most features begins on page 150.

Also included is important safety information that you should know before using your phone. Most of this information is near the back of the guide, beginning on page 127.

### **Notes and Tips**

Throughout this guide are icons and text that are set apart from the rest. These are intended to point out important information, quick methods for activating features, to define terms, and more. The definitions for these methods are as follows:

- Notes Explain alternative options within the current feature, menu, or sub menu.
- Tips Provide quick or innovative methods for performing functions related to the subject at hand.
- Important Points out important information about the current feature that could affect performance, or even damage your phone.

#### **Text Conventions**

This manual provides condensed information about how to use your phone. To make this possible, the following terms and icon appear in place of repeatedly-used procedural steps:

**highlight** Use the Navigation key ( ) to move a highlighting effect onto a menu item or screen item of interest.

select After "highlighting" a menu item or screen item, press the MENU / OK key ( ) to launch, access, or save a highlighted menu item or screen field of interest

→ Used in place of "select" in long "drill down" procedure steps.

Example: "...Settings → Call Settings → Voice Call..."

# **Activating Your Phone**

Contact your Wireless Carrier and follow their instructions for obtaining service, if necessary. We suggest that you read this guide to fully understand the services your phone supports.

#### Install the Battery

Note: Your phone comes packaged with a partially charged rechargeable standard Li-lon battery and a travel adapter.

**Important!:** You must fully charge the battery the first time you use your phone, otherwise you could damage the battery.

 Insert the top end (1) of the battery first, matching the gold contacts on the top end of the battery to those inside of the phone.



- Press the bottom end of the battery (2) down into the phone.
- Place the battery cover over the battery and slide the cover upward into place (3) and press the bottom down (4) until it clicks.



#### Turn Your Phone On

- 1. Open the flip on your phone, as shown.
- 2. Press the END® key.

Note: As with any other radio-transmitting device, do not touch the antenna while using your phone as this can affect call quality and can cause the phone to operate at a higher power level than is necessary.



- The phone begins searching for a network signal.
- Once the phone finds a signal, the time, date and day appear at the top of the display.

You're now ready to place and receive calls.

Note: If you are outside of your carrier's coverage or roaming area (R), the No Service icon (Ts) appears at the top of the phone's display. If you cannot place or receive calls, try later when service is available, or at another location.

#### **Turn Your Phone Off**

 Press and hold the key for two or more seconds. Your phone powers off.

Note: If your phone is on and you press of reless than one second, the phone will not power off. This prevents your phone from being turned off accidentally.

#### Remove the Battery

Important!: You must unplug the Travel Adapter (if it is connected) before removing the battery from the phone during charging to avoid damage.

- 1. Press and hold the key to turn off the phone (if on).
- Move the cover latch (1) toward the bottom end of the phone.



- Lift the cover (2) up and away from the phone, bottom end first
- **4.** Lift the battery up (3) and away (4) from the phone, bottom end first.



### Charging the Battery

Your phone is powered by a rechargeable standard Li-lon battery. Only use Samsung-approved charging devices and batteries. Samsung accessories are designed to maximize battery life. Using other accessories may invalidate your warranty and may cause damage.

### Use the Travel Adapter


The travel adapter included with your phone is a convenient, light-weight charger that rapidly charges your phone from any 120/220 VAC outlet.



 Plug the large end of the Travel Adapter into a standard 120 VAC or 220 VAC wall outlet.

Note: For connection to an electrical supply not located in North America, you must use an adapter of the proper configuration for the power outlet. Use of the wrong adapter could damage your phone and void your warranty.

Insert the smaller end of the Travel Adapter into the charger/accessory connector on the left side of your phone.



Note: With the device turned OFF, a discharged battery recharges fully in approximately 4 hours.

#### Low Battery Indicator

The battery indicator ( ) in the upper-right corner of the display indicates power level. Monitor the battery strength and ensure your battery is adequately charged.

- Three bars ( ) indicate a full charge.
- An empty battery icon ( ) indicates a near empty battery.
- A blinking empty battery icon ( ) and a tone sounding indicate you have two to three minutes before the battery is too low to operate the phone.

If you continue to use your phone without charging its battery, the phone shuts down.

### Setting Up Your Voicemail

Voice mail allows callers to leave voice messages, which can be retrieved any time.

Note: Once your voice mail account has been set up, you can use the Voicemail folder (under the Message menu) to view details of voice messages in your voice mail box.

 In standby mode, press and hold the key or dial your own mobile number to dial Voicemail. Follow the prompts in the new user tutorial to setup your voice mail box.

#### Listen to Voicemail


- In standby mode, press and hold the key or dial your own mobile number to dial voice mail. After connecting, you will hear your voice greeting.
- Interrupt your greeting by pressing .You are then prompted to enter your password.
- Enter your password and follow the prompts to listen to your voice mail.

# Memory Card (Optional)

Your phone has a memory card slot on its right side, above the Camera key. You can install a microSD $^{TM}$  card in this slot to provide additional memory for storing files (such as, sound files and photos) in your phone.

### Install a Memory Card

 Open the microSD cover on the right side of your phone (above the Camera key). Insert the memory card — label side facing down and smaller end pointing toward the phone — into the memory card slot.



- Press the memory card up into the slot until the card locks into place.
- 4. Replace the microSD cover.

### Remove a Memory Card

- Open the microSD cover on the right side of your phone (above the Camera key).
- Press the memory card up into the slot until the card lock releases.
- 3. Remove the memory card from the memory card slot.

- If desired, install another memory card. (For more information, refer to "Install a Memory Card" on page 7.)
- 5. Replace the microSD cover.

# **Section 2: Understanding Your Phone**

This section outlines some key features of your phone. It also displays the screen and the icons that are displayed when the phone is in use.

#### **Features of Your Phone**

- Domestic and international voice and text messaging service (available on participating networks).
- High speed data (CDMA 1x EVDO Technology)
- Global Positioning (GPS) Technology
- Personal Information Management (PIM) functions (Calendar, Calculator, and so on)
- · Picture/Video (MMS) Messaging
- · Text (SMS) Messaging
- 1.3 Mega pixel Camera with Camcorder function
- · Advanced Music Player (MP3 compatible)
- Advanced Speech Recognition
- Speakerphone
- microSD<sup>TM</sup> Memory Card slot
- Bluetooth® Wireless Technology (see Note)

Note: The r500 phone supports the wireless headset, handsfree, object push and file transfer for Bluetooth<sup>®</sup> wireless technology. The r500 phone does not support Bluetooth OBEX or file transfer profiles.

#### **Closed View of Your Phone**




#### **Features**

- 1. Camera Lens The lens of your built-in camera.
- Power/Accessory Connector Used to connect charging accessories and any available accessory cables to your phone. Lets you plug in an optional headset for safe, convenient, hands-free conversation.

- Mirror Used to center the image when taking selfportraits.
- Volume Keys With the phone closed and idle, turns on the front display backlight when pressed.
   When receiving a call, mutes the ringer.
- When playing music, adjusts the Media Player volume.

  5. Front Display Indicates the status of your phone.
- including status icons, message indicators, signal strength, and so on. Shows time and date.
- Camera/Media Player Key With the flip closed and the phone idle, turns on the front display backlight when pressed.
  - With the flip closed, the phone idle, and with a memory card containing music files inserted, launches the Media Player when pressed and held.
- Memory Card Socket Used to plug in a microSD memory card for additional multimedia file storage.

### Front Open View of Your Phone



#### Features

Earpiece — Lets you hear the other caller.

- Main Display Indicates the status of your phone, including status icons, message indicators, signal strength, and so on. Shows menus, calls, and messages.
- Navigation Key Lets you scroll through the phone menu options.
- Left Soft Key Used to navigate through menus and applications and to select the choice available in the Left Soft key option.
- Speakerphone Key Turns Speakerphone mode On and Off.
- Volume Keys With the phone open and idle, adjusts the call ringer volume when pressed.
  - When receiving a call, mutes the ringer.
- SEND Key Lets you place or receive a call. In standby mode, press the key once to access the recent call log.
- Microphone Lets the other caller hear you clearly when you are speaking to them.
- Special Function Keys Enter special characters.
   Perform various functions.

- Alphanumeric Keys Use these keys to enter numbers, letters, and characters.
- 11. CLR Key Deletes characters from the display when you are in text entry mode. Press this key to return to the previous menu or screen when navigating features on your phone.
- END Key Ends a call. If you press and hold the END key, the power goes On or Off. When you receive an incoming call, press to send the call to voicemail.
- **13. Voice Recognition Key** Launches VoiceSignal options.
- **14. Camera/Media Player Key** With the flip open, launches the Camera in your phone.
  - When in Camera or Camcorder mode, switches between Camera and Camcorder.
- 15. MENU/OK Key In idle mode, launches the Main Menu. When navigating through a menu, accepts the highlighted choice in the menu.
- Right Soft Key Used to navigate through menus and applications and to select the choice available in the Right Soft key option.

 Stereo Speakers — Enabled by Speakerphone key or Media Player for handsfree operation or to play music.

# **Command Keys**

Functions for the soft keys are defined by what appears above each in the display. There are two soft keys, the left soft key ( ) and the right soft key ( ).

### Left Soft Key

Some functions of the left soft key are as follows.

- In standby mode, press Settings to access the Settings menu. (For more information, refer to "Changing Your Settings" on page 108.)
- When the left soft key function is Edit, press the Edit (left) soft key
   ) to edit a Contact.
- When the left soft key function is Erase, press the **Erase** (left) soft key
   ( ) and a pop-up window appears prompting you to confirm the
   erasure.

### Right Soft Key

Some functions of the right soft key are as follows.

- In standby mode, press the Contacts (right) soft key ( ) to open the Messages menu.
- When the right soft key function is Options, press the Options (right) soft key ( ) and a pop-up menu appears.

### MENU/OK Key

- In standby mode, press the MENU/OK key (
  ) to open the main menu.
- In a menu, press the MENU/OK key ( ) to accept the highlighted selection.
- In camera mode, press the MENU/OK key ( ) to take a photo or to create a Pic message.
- When the MENU/OK key function is Edit, press the EDIT key ( ) to edit a Draft message.

### Speakerphone Key

In standby mode or during a call, pressing and holding the Speakerphone key ( ) places your phone in speakerphone mode, allowing you to use your phone handsfree and/or to include other nearby persons in a call. (For more information, refer to "Responsible Listening" on page 136.)

In speakerphone mode, pressing and holding the Speakerphone key ( ) disables speakerphone mode.

### Voice Recognition Key

In standby mode, pressing the Voice Recognition key ( ), launches the VoiceSignal application, enabling you to use spoken commands to control your phone. (For more information, refer to "Voice SVC" on page 103.)

#### **CLR Key**

- If you enter an incorrect character, briefly press to backspace (and delete) the character.
- 2. To erase the entire sentence, press and hold \text{\text{CLR}}.
- To return to standby mode, press and hold until you return to standby mode.

### **END Key**

- In standby mode, press and hold the END key ( turn your phone off.
- 2. Briefly press once to disconnect a call.
- 3. Press to return to standby mode from any menu, or to cancel the last input.
- 4. With your phone turned off, press to turn your phone on.

### SEND Key

The **SEND** key (**SEND**) is used to answer calls, dial calls, and to recall the last number(s) dialed, received, or missed.

- 1. Press **SEND** once to answer calls.
- 2. Enter a number and briefly press send to make a call.
- 3. Briefly press in standby mode to display a list of recent calls to and from your phone.
- 4. Press twice in standby mode to call the most recent number.
- 5. Press send to pick up a waiting call. Press send again to switch back to the other call.

### Navigation Key

Use the directional keys on the Navigation key ( ) to browse menus, sub-menus, and lists. In standby mode, the directional keys also act as shortcuts to launch applications.

### Camera Key

With the camera or camcorder active, pressing and holding the Camera key (

) switches between the camera and camcorder functions.

### **Understanding the Display Screen**

 The top line of your phone's main display contains icons that indicate network status, battery power, signal strength, connection type, and more.



- The center portion of the main display shows
   information such as call progress information, messages,
   and photos.
- 3. The bottom line of the main display shows current soft key functions. The sample screen shows that pressing the Left soft key ( ) will launch the Settings menu, pressing the MENU key ( ) will display the Main Menu, and pressing the Right soft key ( ) will show the Contacts menu.

#### **Display Screen Icons**

Your The r500 phone can show you definitions of the icons that appear on the top lines of the front and main displays. To access the Icon Glossary:

In standby mode, press the MENU/OK key (♠), then select Settings → Phone Info → Icon Glossary. A list shows of the icons that can appear on the top line of the display.

### **Dialogue Boxes**

Dialogue boxes prompt for action, inform you of status, or warn of situations such as low memory. Dialogue boxes and their definitions are outlined below.

- Choice
  - Example: "Save message?"
- Reconfirm
  - Example: "Erase all messages?"
- Performing
  - Example: "SENDING..." "Connecting..."
- Completed
  - Example: "Message saved"
- Information
  - Example: "New Message"
- Error
  - Example: "Card not available. Insert card"

#### Warning

- Example: "Low Battery," "Memory Full!"

# Backlights

Backlights illuminate the display and the keypad. When you press any key or open the phone, the backlights come on. They go off when no keys are pressed within a period of time set in the **Backlight** menu.

Note: During a phone call, the display backlight dims and turns off after 60 seconds to conserve battery power, regardless of the Backlight setting.

For more information, refer to "Backlight" on page 111.

#### **Your Phone's Modes**

#### **Call Answer Mode**

You can select how you wish to answer a call.

- - Any Key Pressing any key except or answers a call.
  - Send Key Only pressing answers a call.
  - Flip Open Only opening the flip or pressing answers a call.

Tip: You can set your phone to answer calls automatically, without any input from you. (For more information, refer to "Auto Answer" on page 114.)

- 2. Highlight an option.
- Press to select the method for answering calls.

### Input mode

Input mode determines how you enter text, numbers and symbols. While at any text entry screen, press the Left soft key ( ), then choose the input mode from the pop-up menu using the navigation keys. Optional input modes are **T9 Word**, **Abc**, **ABC**, **123**, and **Symbols**. (For more information, refer to "Entering Text" on page 30.)

Tip: You can also cycle between T9 Word, Abc, and 123 by repeatedly pressing and holding the key.

### **Lock Modes**

#### **Phone Lock**

When the phone is in Phone Lock mode, restrictions are placed on phone use. You can receive calls and messages, but cannot place outgoing calls (except for emergency numbers) until you unlock the phone. Phone Lock mode also restricts access to menus and the volume key. Unlock your phone by entering the

lock code when prompted. (For more information, refer to "Lock Phone" on page 116.)

# Standby Mode

Standby mode is the state of the phone once it has found service and is idle. The phone goes into standby mode:

- After you power the phone on.
- When you press after a call or from within a menu.

In standby mode, you will see the time, day, and date as well as all active phone status icons.

- To place a call, while in standby mode, enter a phone number, and press SEND .
- To end the call and return to standby mode, press END<sup>®</sup>.



### Receive Messages in Standby Mode

You can receive messages in standby mode. An alert tone sounds and a notification message appears in the display when a new message arrives. The following options also appear in the display:

- View Now
- View Later

Highlight the desired option and press 📆.



You can place and receive calls only when your phone is on. While in a call your phone is in Talk mode. Press the **Options** (right) soft key ( ) to display a list of menu options. (For more information, refer to "The In-Use Options" on page 28.)

### Speakerphone Mode

While in standby mode or Talk mode, press and hold the Speakerphone key ( ) to switch from using the earpiece to the speakerphone (speakerphone option) and back to using the earpiece. Use the volume keys - located on the left side of your phone — to adjust the volume.

When you end a call, your phone automatically drops out of Speakerphone mode.

In Speakerphone mode, press and hold the Speakerphone key ( ) to switch back to using the earpiece.

#### Silent Mode

Silences all tones your phone makes and replaces the ringers with vibrations.

In standby mode, press and hold will "Entering silent mode" pops-up.

# **Adjust the Ringer**

1.	In standby mode, press the volume key ( $\bigcirc$ ) on the		
	left side of the phone Up • Ringer Off • Vibrate • Low • Low/Medium	or Down. Options are: • Medium • Medium/High • High • Vibrate/High	
2.	2. When you are satisfied with the setting, press <b>SET</b> (  Your phone returns to standby mode.		
. ME Na	I can also access the <b>Volume-Vo</b> NU key (), then pressing the polygation key or the Volume key (of ust the ringer volume setting.	ice Calls sub-menu by pressing the keys. Use the n the upper left side of your phone) to	

Note: The Vibrate icon (||||||) appears in the display when the phone is in Vibrate mode.

### **Section 3: Call Functions**

This section explains how to make or answer a call. This section also includes the features and functionality associated with making or answering a call.

### Making a Call — Number Entry Dialing

- With the phone on, enter the number you wish to call using the keypad.
- 2. Press send to place the call.

## **Dialing Emergency Numbers**

To place an emergency call:

- 1. With the phone on, enter 911 using the keypad.
- 2. Press send to place the call.

You can specify other numbers as emergency numbers using the **Emergency #** settings. (For more information, refer to "Emergency #" on page 117.)

Important!: Emergency number 911 is preset into your phone. You can dial this number almost any time, even when the phone is locked or restricted.

If you call 911 an audible tone is heard and an Emergency prompt appears in the display for the duration of the call.

Importantl: Because of various transmission methods, network parameters, and user settings necessary to complete a call from your wireless phone, a connection cannot always be guaranteed. Therefore, emergency calling may not be available on all wireless networks at all times.

Important!: DO NOT depend on this phone as a primary method of calling 911 or for any other essential or emergency communications.

### **Dialing International Numbers**

### Call another country from the U.S.

- In standby mode, enter the three-digit exit code (011) for the United States.
- 2. Enter the country code for the country that you are calling.
- 3. Enter the number that you wish to call, then press SEND



Note: Puerto Rico and Canada are on the North American dialing plan. When making calls to Puerto Rico and Canada it is similar to making calls within the United States, no unique country codes are necessary.

### **Manual Pause Calling**

When you call automated systems (like banking services), you are often required to enter a password or account number.

Instead of manually entering the numbers each time, you can store the numbers in your Contacts along with special characters called pauses.

- 2-Sec Pause A two-second pause stops the calling sequence for two seconds and then automatically sends the remaining digits.
- Wait A hard pause stops the calling sequence until you press

To manually call a number with pause(s) without storing it to your Contacts:

- 1. Enter the number you wish to call.
- Press **Options**. A pop-up menu containing the following options appears in the display:
  - 2-Sec Pause a two-second pause.
  - Wait a hard pause (awaits input from you).

Select the desired pause option to add to your number sequence.

3. Press send to call the number.

### Making a Call — Speed Dialing

You can store phone numbers and contact names in your phone's Contacts list. Speed Dialing lets you quickly and easily dial any contact in your Contacts list by using that contact's location number in the list. You can assign and change location (speed

dial) numbers for your contacts. (For more information, refer to "Assigning Speed Dial Numbers" on page 41.)

### **One-Touch Dialing**

Speed Dial numbers 2 through 9 are special One-Touch dialing numbers. You can call the phone numbers stored in your phone's Contacts list and assigned Speed Dial numbers 002 through 009 by pressing and holding a single key.

Example: For Speed Dial number 3, press and hold get until the name and number appear in the display and the number is dialed.

### **Two-Touch Dialing**

Speed Dial numbers 10 through 99 are special Two-Touch dialing numbers

Example: For Speed Dial number 13, briefly press to, then press and hold seed until the name and number appear in the display and the number is dialed.

#### Three-Touch Dialing

Speed Dial numbers 100 through 999 are special Three-Touch dialing numbers.

Example: For Speed Dial number 113, briefly press in briefly press again, then press and hold in the name and number appear in the display and the number is dialed.

### Pause Dialing From a Contacts Entry

- If you speed dial a contact that contains (two-second) 2-Sec Pause(s) simply wait for the pauses to pass and the dialing to complete.
- If you speed dial a contact that contains (hard) Wait(s), wait for the appropriate prompt(s) from the number you are calling (credit card number, bank account number, and so on) and enter the appropriate response(s).

# Making a Call — Quick Search Dialing

Use the **Quick Search** feature to dial any number stored in your Contacts list by pressing the number keys that correspond to the first few letters of a Contact name.

### **Quick Search Dialing a Contact**

To find and dial a Contact, do the following:

- In standby mode, press the number keys that correspond to the first few letters of the Contact name, as shown.
- Press the Up navigation key. The Contact List screen appears showing the desired Contact name, as shown.
- 3. Press send to call the number.

Note: To set Quick Search, refer to "Quick Search" on page 120.

### Making a Call — Voice Dialing

Your The r500 mobile phone includes state-of-the-art voice recognition software that lets you dial numbers using your voice.

### **Using Voice Dial**

Use the **Voice Dial** command to dial any number stored in your Contacts list by saying the name of the contact (Name Dialing). You can also use Voice Dial to dial any valid telephone number, even numbers not stored in your contact list, by speaking the individual digits in the number (Digit Dialing).

### **Voice Dialing Tips:**

- Wait for the beep before speaking.
- Speak clearly at a normal volume, as if you were talking to someone on the phone.
- · When saying a name, say the first name then the last name.

#### **Dialing a Name**

To dial a name, do the following:

- 1. In standby mode, press .....
  - "Say a Command" appears in the display and is pronounced through the earpiece.
- 2. Say, "Call".

You are prompted to "Say the name or #".

Speak clearly and say the name of a person in your Contacts list, first name followed by last name.

If the name is recognized, Voice Dial repeats the name and dials the number

If Voice Dial is not sure which name you said, it displays a choice list of up to three names and prompts you with "Did you say?" followed by the first name on the list.

- 4. Say "Yes" to confirm the name or "No" to hear the next name, or use the keypad to select the correct name from the list. (For more information, refer to "Choice Lists" on page 104,)
  - Press Repeat to say the name again.
  - Press or for to exit Voice Dial without dialing.
     If the recognized name has multiple numbers stored for it (that is, Home, Work, Mobile, and so on), Voice Dial displays the possible choices and prompts you with
  - "Which number?"
- 5. Say one of the following number types:
  - "Home"
  - "Work"

#### "Mobile"

Voice Dial dials the specified number.

#### **Dialing a Number**

To dial a number using Voice Dial, do the following:

- 1. In standby mode, press ...
  - "Say a Command" appears in the display and is pronounced through the speaker.
- Say "Call".VoiceSignal prompts you to "Say the name or #".
- 3. Speak clearly and say the telephone number of the person you want to call. For example, say "7 8 1 9 7 0 5 2 0 0." If it recognizes the number, Voice Dial repeats and dials the number. If Voice Dial is not sure it has recognized the number, it displays a choice list of up to three numbers and prompts you with "Did you say?" followed by the first number on the list
- Say "Yes" to confirm the number or "No" to hear the next one, or use the keypad to select the correct number from the list. (For more information, refer to "Choice Lists" on page 104.)

- Press **Repeat** to say the name again.
- Press or or to exit Voice Dial without dialing.

# Pause Dialing From a Contacts Entry

- If you voice dial a contact that contains (two-second) 2-Sec Pause(s) simply wait for the pauses to pass and the dialing to complete.
- If you voice dial a contact that contains (hard) Wait(s), wait for the appropriate prompt(s) from the number you are calling (credit card number, bank account number, and so on) and enter the appropriate response(s).

### **Answering a Call**

Your phone notifies you of a call in the following ways:

- A ring tone sounds and/or your phone vibrates (Your phone provides seven ring volume settings including: Ringer Off, Vibrate, Low, Low/Medium, Medium, Medium/High, High, or Vibrate/High, and/or different ring types to distinguish callers.)
- A phone number (unless blocked by the caller) and a name appear in the display (If the caller's number and name are stored in your Contacts list).
- If the caller can't be identified, Call from unavailable#, Call from restricted number, or no number appears in the display.
- Your phone continues to notify you of the call until one of the following events occurs:
  - You answer the call.
  - You ignore the call.

- The calling party ends the call.
- The call is sent to Voicemail.

### **Answering an Incoming Call**

Press sevo . The ring tone and/or vibration stop and the caller's voice can be heard in the earpiece.

Tip: You can set your phone to answer calls automatically or when you press any key but the key. (For more information, refer to "Call Settings" on page 113.

# **Ignoring a Call**

When you ignore an incoming call, the call is immediately forwarded to your voice mail.

During an incoming call, press the **Ignore** soft key. The caller is forwarded to your voice mail.

# **Adjusting the Call Volume**

During a call, repeatedly press the Volume key (on the left side of phone) Up or Down until the desired volume is heard in the earpiece or headset.

# Calls Log

The Calls log retains information about Outgoing, Incoming, and Missed calls. You can also view times for your last call and the time totals for all calls.

#### Review the Calls Log

- In standby mode, press MENU (
  ), then select Recent
  Calls.
- Select the Calls log that you wish to review or the function you wish to access:
  - · Outgoing Calls
  - Incoming Calls
  - Missed Calls
  - All Calls
  - Call Timer
  - Data Counter

Note: In cases where there is a Contacts match for a Calls log entry, the name associated with the number appears in the display instead of the number.

#### **Outgoing Calls**

Your phone retains information about the last 90 outgoing calls and stores them in the Outgoing calls log. You can review the Outgoing calls log for the time and date of a call, as well as other information.

Note: To quickly view your most recent calls, briefly press an in standby mode. Up to 270 of your most recent outgoing, incoming, and missed calls appear in the display.

- Highlight a call, then press OPEN ( ) to view further information about the call.
- Press Options. A pop-up menu containing the following options appears in the display:
  - **Save** Save the number to your Contacts.
  - **Details** Calls to Contacts Only Shows the entry for the called Contact.
  - **Erase** Erase the selected call from your Outgoing call log.
  - Lock / Unlock Protect the selected call from being erased.
  - Erase All Erase all calls from your Outgoing call log.
  - View Timer Shows the number of calls and/or the total time spent on the Last Call, Outgoing Calls, Incoming Calls, Roaming Calls, All Calls, Last Reset, and Lifetime Calls.
- 4. Press Msgs. The following options appear in the display:
  - Text Message Lets you send a text message to the selected number called.

- Picture Message Lets you send a picture message to the selected number called.
- Video Message Lets you send a video message to the selected number called.

Note: For more information, refer to "Creating and Sending New Messages" on page 46.

Select the desired option.

### **Incoming Calls**

Your phone retains information about the last 90 Incoming calls and stores them in the Incoming call log. You can review the Incoming call log for the time and date of the call, as well as other information.

- Highlight a call, then press OPEN ( ) to view further information about the call.
- 3. Press **Options**. The following options appear in the display:
  - Save Save the number to your Contacts.
  - Details Calls from Contacts Only Shows the entry for the calling Contact.

- **Erase** Erase the selected call from your Incoming calls log.
- **Lock/Unlock** Protect the selected call from being erased.
- Erase All Erase all calls from your Incoming calls log.
- View Timer Shows the number of calls and/or the total time spent on the Last Call, Outgoing Calls, Incoming Calls, Roaming Calls. All Calls. Last Reset. and Lifetime Calls.
- 4. Press Msgs. The following options appear in the display:
  - Text Message Lets you send a text message to the selected calling number.
  - Picture Message Lets you send a picture message to the selected calling number.
  - Video Message Lets you send a video message to the selected number called.

Note: For more information, refer to "Creating and Sending New Messages" on page 46.

5. Select the desired option.

### **Missed Calls**

Your phone retains information about the last 90 missed calls (calls that were never picked up) and stores them in the Missed call log. You can review the Missed call log for the time and date of the call, as well as other information.

- In standby mode, press MENU (♠), then select Recent
   Calls → Missed Calls. A list of your missed calls appears
   in the display.
- Highlight a call, then press OPEN ( ) to view further information about the call.
- 3. Press **Options**. The following options appear in the display:
  - Save Save the number to your Contacts.
  - Details Calls from Contacts Only Shows the entry for the calling Contact.
  - Erase Erase the selected call from your Missed call log.
  - Lock/Unlock Protect the selected call from being erased.
  - Erase All Erase all calls from your Missed call log.
  - View Timer Shows the number of calls and/or the total time spent on the Last Call, Outgoing Calls, Incoming Calls, Roaming Calls, All Calls, Last Reset, and Lifetime Calls.
- 4. Press **Msgs**. The following options appear in the display:
  - Text Message Lets you send a text message to the selected called number
  - Picture Message Lets you send a picture message to the selected called number.
  - Video Message Lets you send a video message to the selected number called.

Note: For more information, refer to "Creating and Sending New Messages" on page 46.

5. Select the desired option.

#### All Calls

You can review all of the calls log entries (outgoing, incoming, and missed calls) for the time and date of a call, as well as other information.

- Highlight a call, then press OPEN ( ) to view further information about the call.
- 3. Press **Options**. The following options appear in the display:
  - Save Save the number to your Contacts.
  - Details Calls from Contacts Only Shows the entry for the calling/called Contact.
  - Erase Erase the selected call from your Calls log.
  - Lock/Unlock Protect the selected call from being erased.
  - Erase All Erase all calls from your Calls log.

- View Timer Shows the number of calls and/or the total time spent on the Last Call, Outgoing Calls, Incoming Calls, Roaming Calls, All Calls, Last Reset, and Lifetime Calls.
- 4. Press Msgs. The following options appear in the display:
  - Text Message Lets you send a text message to the selected calling/called number.
  - Picture Message Lets you send a picture message to the selected calling/called number.
  - Video Message Lets you send a video message to the selected number calling/called.

Note: For more information, refer to "Creating and Sending New Messages" on page 46.

5. Select the desired option.

#### **Call Timer**

View the duration of your last call, total calls, and calls made during the life cycle of you phone using the Call Timer feature.

Note: Call Timer is not for billing purposes.

- In standby mode, press MENU (
   <sup>®</sup>
   <sup>®</sup>
   ), then select Recent
   Calls → Call Timer. The following options appear in the
   display:
  - Last Call View the duration of your last call.

- Outgoing Calls View the duration of the total outgoing calls made on your phone since the last erasure.
- Incoming Calls View the duration of the total incoming calls received on your phone since the last erasure.
- Roaming Calls View the total calls duration on your phone while roaming since the last erasure.
- All Calls View the duration of the total call, incoming, outgoing, and data calls made on your phone since the last erasure.
- Last Reset View the time and date all timers were last reset.
- Lifetime Calls View the duration of all calls since your phone was activated.
- Press Reset to reset a selected counter except Last Reset and Lifetime Calls.
- 3. Press Reset All to reset all counters except Lifetime Calls.
- 4. Press or END if you wish to exit the list.

Note: Although Total call timers can be erased, the Lifetime call timer can never be erased.

#### **Data Counter**

View the amount of Transmit data, Receive data, and Total data transmitted or received since the last time you reset the data counters, and the Lifetime amount of data transmitted or received.

Note: Data Counter is not for billing purposes.

- In standby mode, press MENU (♠), then select Recent Calls → Data Counter. The following options appear in the display:
  - Transmit View the total amount of data transmitted by your phone since the last reset.
  - Received View the total amount of data received by your phone since the last reset.
  - Total View the total amount of data sent or received by your phone since the last reset.
  - Last Reset View the time and date all timers were last reset.
  - Lifetime Data Counter View the total amount of data sent or received by your phone since activation (Lifetime Data Counter cannot be reset).
- Press Reset to reset a selected counter except Last Reset and Lifetime Calls
- Press Reset All to reset all counters except Lifetime Calls.
- 4. Press er or fi you wish to exit the list.

Note: Although Total data counters can be erased, the Lifetime Data Counter can never be erased.

### Roaming

#### What is Roaming?

Roaming lets you use your The r500 phone when you travel outside of your Wireless Provider's coverage area. The Roaming icon ( $\mathbb{R}$ ) appears in the top line of the display when Roaming is active, and extra charges may apply when making or receiving calls.

Note: Some features may be unavailable while roaming. Roaming also consumes additional power from the battery requiring more frequent recharging. Contact your Wireless Provider for more information about Roaming.

#### **How Roaming Works**

Roam Option lets you set roaming preferences if you move in and out of your home network. The following roaming options are available:

- Home only Your phone is available for normal operation only in the designated coverage area.
- Automatic Your Wireless Provider's Preferred Roaming List (PRL) of networks is used to acquire service. If no preferred networks are found, any digital system is acquired.

Note: For more information, refer to "System Select" on page 119.

# **Section 4: Menu Navigation**

This section explains the menu navigation for your phone. It also includes an outline of the menus available with your phone.

### **Menu Navigation**

Access menus using the **MENU** key ( ), the Navigation key, the two soft keys ( ), or a shortcut.


- 1. In standby mode, press **MENU** ( ). The Main Menu appears in the display.
- 2. Use the Navigation key to browse phone menus.
- Press to access a menu or sub-menu highlighted in the display.

#### Return to the Previous Menu

Press or **Back** to return to the previous menu.

### **Navigation Key Shortcuts**

In standby mode, press the Navigation key in a particular direction (as illustrated below) to launch its corresponding application.



# The In-Use Options

Access numerous menus and features even while in a call.

Note: If the call is disconnected while accessing the In-Use Option, the In-Use Option disappears from the display and the phone eventually returns to standby mode.

- While in a call, press **Options**. The following menu items appear in the display:
  - Message The Messages menu appears in the display. (For more information, refer to "Messaging" on page 46.)
  - Contacts The Contacts Find screen appears in the display.

- Recent Calls The All Calls menu appears in the display.
- Send DTMF Send your phone number as DTMF tones to the other person on the call.
- Voice Privacy When set to Enhanced, the phone sounds an audible beep when you loose privacy (encryption) on a CDMA connection. For this option to work correctly, you must have the Enhanced privacy option enabled in the Security settings. (This option is enabled by default.)
- Location Lets you set location identification function for continuous operation or to operate only in the event that you dial 911
- Voice Memo Lets you record your side of the current conversation for up to one minute.
- Connect Bluetooth Connects a Bluetooth device, such as a headset, in place of the phone's earpiece and microphone.

Do one of the following:

- Use the Navigation key to highlight a menu or feature. Press the key to open the highlighted menu or to activate the highlighted feature.
- Press the key to exit the menu.

Tip: You can block sound going to the other party(ies) on this call by pressing Mute. This can reduce noise on conference calls.

You can launch Speakerphone mode to conduct this call hands-free by pressing  $_{\overline{\mathbb{R}^n}}$  .

### **Navigate Using Shortcuts**

You can also access menus and sub menus using menu numbers. This method is often called a "shortcut." To shortcut to a menu or sub menu, press the **MENU** key (), then enter the menu and/or sub menu number(s) for the feature in question.

- In standby mode, press MENU ( ). The main menu appears in the display.
- Press the number of the menu, sub menu, and so on to arrive at the desired feature.

# **Section 5: Entering Text**

This section outlines how to select the desired text input mode when entering characters into your phone. This section also describes how to use the T9 predictive text entry system to reduce the amount of key strokes associated with entering text.

# **Text Entry Modes**

You can compose text messages using alphabetical characters, symbols, and numbers. Each method of character entry (symbol, number, and so on) is called a text entry mode. There are four text entry modes, as indicated:

- Alpha—Alphabetical text entry mode. Options are:
- ABC All upper case
- Abc Initial capital
- abc All lower case
- Symbols Symbol entry mode. Enter symbols into your message by pressing the corresponding number that appears above it in the display.
- 123 Number entry. Enter numbers by pressing the corresponding key on the keypad.
- T9 Word Predictive text mode. Press each key only once to enter the letter of the word that you're spelling.

Your current mode of text entry [**Abc**, **123**, or **T9 Word**] is indicated in the lower left part of the display when composing a text message.

### Changing the Text Entry Mode

- While composing a text message, press the Left soft key. A pop-up menu containing the following options appears in the display:
  - T9 Word
  - Abc
  - ABC
  - 123
  - Symbols

**Abc** is highlighted. Use the Up and Down navigation keys to choose any of the other four text entry modes. Uses of the text entry modes are explained in greater detail in "Messaging" on page 46.

### **Entering Text in Alpha (Abc) Mode**

- Enter characters while in Alpha (Abc) mode by pressing the key with the desired characters (such as, pressing once for "G").
- Press the key repeatedly until the desired character appears in the display (such as, pressing two times for "H").
- Pause briefly and the displayed character is accepted and inserted into your message.
- 4. Press to enter a space.

### **Entering Text in T9 Word Mode**

**T9 Word** recognizes commonly used words for a sequence of key presses and inserts the word into your message. Using T9 mode is much faster than the more traditional method Alpha mode, since T9 *requires only one key press per letter* of the word that you are spelling.

Note: See "Changing the Text Entry Mode" on page 30 for instructions on changing text entry modes.

 While in T9 Word mode, press each key that corresponds to a desired letter, in sequence, one time. Example: If you press the key sequence [2006] [2007], the word "Bad" is likely to appear in the text entry field.

- When you have completed pressing all the keys for the desired word, review the word appearing in the text entry field.
- If the word in the text entry field is not the one you meant to enter, repeatedly press or until the word you want appears.

Example: When you press the key sequence [25] [55], the word "And" appears on the screen. Suppose the word you want is "Cod". Just repeatedly press the [55] key until "Cod" is highlighted in the display.

4. Press the key to accept the highlighted word.
For practice, enter the word 'Samsung' into your message by pressing each of the following keys only once:



**T9 Word** recognizes that the most commonly used word for the sequence of keys you just pressed is "Samsung."

Tip: To enter words not likely to be in the T9 Word dictionary, such as uncommon abbreviations or slang, try changing the text entry mode from T9 Word to Abc or ABC

### **Entering Upper and Lower Case Letters**

In Abc and T9 Word modes, you can select to enter only upper case letters (ABC/T9 WORD), only lower case letters (abc/T9 word), or a mix of the two (Abc/T9 Word).

While in **T9 Word** or **Abc** mode, repeatedly press \*++ to change the capitalization setting.

The left soft key label changes to indicate the current capitalization setting.

For example, if the left soft key label is ABC, and you want to enter the word "BALL", press \*\*\* until the left soft key label changes to abc. then enter the word "ball".

Tip: To enter a capital letter within a word, such as "SimTam", change the capitalization setting to Abc at the beginning of the word and before entering the "T". The capitalization setting will automatically change to abc after you enter each upper case letter.

# **Entering Numbers**

Enter numbers into a text message while in number mode (123).

Note: See "Changing the Text Entry Mode" on page 30 for instructions on changing text entry modes.

While in 123 mode, press the key containing the corresponding number that you wish to insert into your message.

### **Entering Symbols**

**Symbol** mode enables you to enter symbols such as @ or % in a text message.

- 1. In standby mode, press the **Message** shortcut (Up navigation) key, then select **Send Message** → **Text** Message to compose a new text message.
- Enter the phone number of the recipient, then press @.



- Press the Left soft key. A pop-up menu containing the following options appears in the display:
  - T9 Word
  - Abc
  - ABC
  - 123
  - Symbols

- Use the Up and Down navigation keys to highlight Symbols, then press . The first of three screens of symbols appears in the display.
- Page through the other symbols by pressing Prev and Next to page through the other symbols, if necessary.
- Press the key that corresponds with the symbol that you
  wish to enter. For example, press 4 on for an exclamation
  point (!).

Note: You can also use the navigation keys to highlight the desired symbol and then press the Rey to enter the selected symbol into your message.

7. Repeat steps 3 through 6 to insert as many symbols into your message as desired.

# **Section 6: Understanding Your Contacts**

This section explains how to manage your daily contacts by storing their name and number in your Contacts. Contacts entries can be sorted by name.

## **Your Contacts List**

Your Contacts list can store up to 500 entries, with each contact having up to five associated phone numbers, an e-mail address, and a picture ID.

Each phone number can be up to 32 digits in length, including hard pauses. Contact names can be up to 32 characters in length. You can also specify a memory location for each entry, and you can restrict access to the Contacts list to prevent unauthorized use.

Tip: One-Touch, Two-Touch, and Three-Touch Dialing allow you to call numbers stored in your Contacts list faster. (See page 19.)

## **Open Your Contacts List**

- In standby mode, press MENU ( ), then select Contacts.
   The following Contacts sub-menus and options appear in the display:
  - **Find** Find a phone number by entering a Contact name.
  - Add New Entry Add a number or e-mail to your Contacts.

- **Speed Dial** Assign speed dial numbers to your Contacts.
- Group Rename one of your five Contacts groups.
- Memory Info View available memory for dial entries.
- Use the navigation keys to highlight the Contacts submenu or option of your choice, and press the Rep. key.

Tip: You can also access a sub-menu or menu option by pressing the number key corresponds to the menu item number. For example, press a for Add New Entry.

# **Adding a New Contacts Entry**

You can add an entirely new entry to your Contacts list or add information to an existing entry.

## **Using the Contacts Add Option**

- 1. In standby mode, press MENU ( ), then select Contacts
  - → Add New Entry. The Add New Entry screen appears in the display with the Name field highlighted.
- Enter a name or phrase to associate with the type using the keypad. (For more information, refer to "Entering Text" on page 30.)
- 3. Use the navigation keys to highlight each field.

- Enter a phone number (Mobile, Home, or Work,) or an e-mail address (**E-Mail**) for the new Contacts entry.
- If desired, assign the new Contact to a **Group**. This lets you send messages to and find this Contact and other related contacts. (See "Group" on page 38 for more information.)
- If desired, select a unique **Ringtone** to identify this new Contact. (For more information, refer to "Ringer Type" on page 112.)
- If desired, enter an additional phone number (Pager or Fax) for the new Contacts entry.
- If desired, select an identifying image by highlighting the photo ID field and pressing the Set soft key. The My **Images** screen appears in the display. (For more information, refer to "My Images" on page 84.)
- Press **SAVE** ( ) to save the new Contacts entry.

# Saving a Number from a Call

Once you've finished a call, you can save the number of the caller to your Contacts list.

Note: If the call was incoming and Caller ID information was unavailable. then the Save option is also unavailable.

- 1. After you press end to end your call, the call time, length of call, phone number, and name of the other party (if available) appear in the display.
- 2. Press the Save soft key. The Save screen appears in the display showing the following options:
  - Create New Lets you create a new Contacts entry.
  - **Update Existing** Lets you add the number or e-mail address you just entered to an existing Contacts entry.

**Tip:** You can also store a phone number from standby mode by entering the number, and pressing the Save soft key.

#### Creating a new Contacts entry:

Use the navigation keys to highlight **Create New**, then press 💮 . The following (number type) icons appear in the display:



Mobile



Home



Work

Pager



Fax

Use the Navigation key to highlight the number type that matches your new entry and press 💮 . The Add New **Entry** screen appears in the display with the number being save populating the selected number type field. (For more information on creating a new Contacts entry, see "Using the Contacts Add Option" on page 34.)

## Adding the number to an existing Contacts entry:

- Use the navigation keys to highlight Update Existing, then
  press . The Update Existing screen appears in the
  display showing your current Contacts list.
- 6. Enter the first few characters of the Contacts entry name under which you will store the saved number. (For more information on finding a Contacts entry, see "Finding a Contacts Entry" on page 37.)
- Highlight the desired Contacts entry, then press . The following (number type) icons appear in the **Update Existing** screen:



Mobile



Home 🕯



Work

Pager



Fax

 Use the Up and Down navigation keys to highlight the appropriate unassigned number type, then press . The Edit Contact screen appears in the display.

- Make any added changes you wish to the Contacts entry. (For more information, see "Editing an Existing Contact Entry" on page 40.)
- 10. Press SAVE ( ) to save the entry.

## Storing Number from a Calls Log

You can store numbers from the Calls logs to your Contacts.

- In standby mode, press MENU (
  ), then select Recent
  Calls.
- Press the corresponding number on the keypad to view the following Calls logs:
  - Outgoing Calls
  - Incoming Calls
  - · Missed Calls
  - All Calls
  - Call Timer
  - Data Counter

A list of your calls appears in the display.

Use the Navigation key to highlight the number you wish to store in Contacts.

- 4. Press the **Options** soft key. The following options appear in the display:
  - Save Saves the selected number to your Contacts list.
  - Erase Deletes the selected number from the selected Calls log.
  - Lock / Unlock Prevents/allows deletion of the selected number.
  - Erase All Deletes all numbers from the selected Calls log.
  - View Timer Shows the call times for the Last Call, Outgoing Calls, Incoming Calls, Roaming Calls, All Calls, Last Reset, and Lifetime Calls timers for the selected Calls loo.
- Use the navigation keys to highlight Save, then press 
   The following options appear in the display:
  - Create New Lets you create a new Contacts entry.
  - Update Existing Lets you add the number or e-mail address you just entered to an existing Contacts entry.

For more information on saving the number, see "Saving a Number from a Call" on page 35.

# Finding a Contacts Entry Voice Method

Use the VoiceSignal **Contacts** command to view contact information for any named contact stored in your Contacts list by saving the name.

**Note:** The Contacts command shows the requested contact information in the display but does not dial any phone numbers for the contact.

To look up information for a specific contact:

- 1. In standby mode, press the (( \( \xi \) key to launch **VoiceSignal**.
  - "Say a Command" appears in the display and is pronounced through the speaker.
- 2. Say "Lookup".

VoiceSignal prompts you to "Say the name."

- Speak clearly and say the full name of the person you want to call, exactly as it is entered in your contact list.
  - If VoiceSignal recognizes the name you said, the contact information for that name appears in the display.
  - If VoiceSignal does not recognize the name you said, a choice list of up to three names appears in the display, and VoiceSignal prompts you with "Did you say?" followed by the first name on the list.
- 4. Say "Yes" to confirm the name or "No" to hear the next name, or use the keypad to select the correct name from the list. (For more information, refer to "Choice Lists" on page 104.)

- To say the name again, press the Repeat soft key.
- To exit VoiceSignal without dialing, press the Settings soft key, then press the Exit soft key.
- 5. The contact information for the name you selected appears in the display.

# **Keypad Methods**

## **Find by Name**

If you have stored a named contact in your Contacts list, Find lets you locate the entry quickly.

- 1. In standby mode, do one of the following:
  - Press Contacts.
- Enter the first few characters of the name of the contact as it appears in your Contacts list.

Example: If you saved a contact name as "Amy Smith", begin your search for that contact by pressing [2] [2] for "A".

**Note:** As you enter letters, the entry names of the closest matches (thus far) appear in the display.

- When the desired Contacts entry is listed in the display, highlight the contact (if necessary). Then, do one of the following
  - Press to dial the number associated with the named contact.
  - Press Edit to change the information about the contact.

  - Press Options. The following options appear in the display:
    - New Contact Lets you add a new number to your Contacts list or to the selected contact.
  - Erase Lets you delete the highlighted contact.
  - Send Text Msg Lets you send a text message to the selected contact.
  - Send PIC Msg Lets you send a picture message to the selected contact.
  - Send Video Msg Lets you send a video message to the selected contact.
  - Call Lets you place a call to the highlighted contact.
  - Send Name Card With Bluetooth Lets you send the highlighted contact to another Bluetooth device.
- 4. Select an option to enter that option's sub-menu.

#### Group

This option lets you find a Contacts list entry with a specific Group name.

- 1. In standby mode, press **MENU** ( ), then select **Contacts** 
  - $\rightarrow$  Group. The Group List screen appears in the display.
- Select the name of the group you wish to browse. The selected Group list appears in the display.
- Use the Up and Down navigation keys to find the desired Contacts entry.
- 4. When the desired Contacts entry is listed in the display, highlight the Contact (if necessary). Then, do one of the following:
  - Press the Remove soft key to delete the selected contact from the Group. (Does not apply to No Group.)
  - Press 
     To ADD an existing contact entry to the selected Group.
     (Does not apply to the General group.)
  - Press the **Options** soft key. The following options appear in the display:
    - Send Text Msg Lets you send a text message to selected contact(s) in the current group.
    - Send PIC Msg Lets you send a picture message to selected contact(s) in the current group.
    - Send Video Msg Lets you send a video message to selected contact(s) in the current group.
- 5. Select an option to enter that option's sub-menu.

## Search by Number

This option lets you find a Contacts list entry by one of its phone numbers.

- In standby mode, enter the first few numbers of the Contacts list entry you wish to find (such as the area code or area code and exchange — for example, 888-987).
- Press Options. The following menu options appear in the display:
  - Search Lets you find Contacts list entries by their phone numbers.
  - 2-Sec Pause Adds a two-second pause.
  - Wait Adds a hard pause (awaits input from you).
  - Send Text Msg Lets you send a text message to the entered number.
  - Send PIC Msg Lets you send a picture message to the entered number.
  - Send Video Msg Lets you send a video message to the entered number
- Select the Search option. The FIND screen appears in the display listing all phone numbers in your Contacts list that contain the entered digits.

- 4. Highlight the desired Contacts entry. Then do one of the following:
  - Press the key to dial the highlighted number.
  - Press the **OK** key (
     ) to display information about the Contacts
     entry associated with the highlighted number. From the **View** Contact screen, you can erase or edit the selected Contacts entry.

# **Editing an Existing Contact Entry**

Once stored in the Contacts, an entry can be changed quite easily.

- Find the desired entry in the Contacts list. (For more information, refer to "Finding a Contacts Entry" on page 37.)
- Press the Edit soft key. The Edit Contact screen appears in the display with the contact name highlighted.
- Highlight a number stored in this contact entry.
- 4. Press to backspace and delete numbers.
- Press and hold to clear all numbers in the highlighted field.

Note: You can also add numbers (such as a second Mobile number or a Fax number) to the entry, assign it to a Group, and add other information.

 When you're finished editing the entry, press . Your changes are saved and a confirmation message appears in the display.

#### Adding Pauses to Contacts Numbers

When you call automated systems (like banking services), you are often required to enter a password or account number. Instead of manually entering the numbers each time, you can store the numbers in your Contacts along with special characters called pauses.

- 2-Sec Pause A two-second pause stops the calling sequence for two seconds and then automatically sends the remaining digits.
- Wait A hard pause stops the calling sequence until further input from you.

Tip: You can enter multiple two-second pauses to extend the length of a pause. For example, two consecutive two-second pauses cause a total pause time of four seconds.

Note: Keep in mind that pauses count as digits towards the 32-digit maximum.

## Store Pauses in a New Contacts Entry

 In standby mode, enter the number you wish to store (such as your bank's teleservice number).

- Press the **Options** soft key. The following menu options appear in the display:
  - Search Lets you find Contacts list entries by their phone numbers.
  - 2-Sec Pause Adds a two-second pause.
  - Wait Adds a hard pause (awaits input from you).
  - Send Text Msg Lets you send a text message to the entered number.
  - Send PIC Msg Lets you send a picture message to the entered number.
  - Send Video Msg Lets you send a video message to the entered number.
- 3. Highlight the pause option of your choice.
- Press to enter the highlighted pause into your number sequence.
- When you're finished entering the number and pauses, press the Save soft key to store the number in your Contacts.

## Add Pauses to an Existing Contacts Entry

 Find the desired entry in the Contacts list. (For more information, refer to "Finding a Contacts Entry" on page 37.)

- Press the Edit soft key. The Edit Contact screen appears in the display with the contact name highlighted.
- 3. Highlight a number stored in this contact entry.
- Use the navigation keys to place the cursor where you want to add a pause (usually at the right-hand end of the number).
- **5.** Press the **Options** soft key. The following menu options appear in the display:
  - Set Speed Dial lets you assign a Speed Dial number to this Contacts entry.

  - 2-Sec Pause a two-second pause.
  - Wait a hard pause (awaits input from you).
- **6.** Select the pause option of your choice to enter the highlighted pause into your number sequence.
- When you're finished entering pauses, press to save your changes to the number in your Contacts.

## **Assigning Speed Dial Numbers**

When you add or edit an entry to the Contacts list, you have the option of assigning a Speed Dial number using the Options pop-

up menu or of returning to the Contacts menu and using the Speed Dial option. You can also change a contact's Speed Dial number.

- Find the desired entry in the Contacts list. (See "Finding a Contacts Entry" on page 37 for more information.)
- Press the Edit soft key. The Edit Contact screen appears in the display with the contact name highlighted.
- Use the navigation keys to highlight a number stored in this contact entry.

Note: If a contact has more than one stored number (such as Home and Office), you can select which of these numbers your phone will dial when you speed dial that contact.

- 4. Press the **Options** soft key. The following menu options appear in the display:
  - Set Speed Dial lets you assign a Speed Dial number to this Contacts entry.
  - Set As Default your phone automatically dials this number when you Find this Contacts entry and press
  - 2-Sec Pause a two-second pause.
  - Wait a hard pause (awaits input from you).
     Set Speed Dial is highlighted.

- 5. Press 📆 . The **Speed Dials** screen appears in the display.
- Enter, or use the navigation keys to select, an unassigned Speed Dial number.
- Press to assign the new Speed Dial number to the selected Contact. You are prompted to confirm the assignment.
- Press the Yes soft key to assign the selected Speed Dial number. The Edit Contact screen appears in the display.
- 9. Press  $\textcircled{\ensuremath{\varpi}}$  to save the new Speed Dial number assignment.

## Add a Number or E-Mail Address to an Existing Entry

- Find the desired entry in the Contacts list. (See "Finding a Contacts Entry" on page 37 for more information.)
- Press the Edit soft key. The Edit Contact screen appears in the display with the contact name highlighted.
- Use the navigation keys to highlight a number field or E-Mail field in this contact entry.
- Enter the phone number or e-mail address for the new Contacts entry.

Press to add the number or e-mail address to the existing entry.

## Edit an Existing E-Mail Address

- Find the desired entry in the Contacts list. (For more information, refer to "Finding a Contacts Entry" on page 37.)
- Press the Edit soft key. The Edit Contact screen appears in the display with the contact name highlighted.
- Use the navigation keys to highlight the E-Mail field (labeled with the @ symbol).
- Use the keypad to edit the E-Mail address. (For more information, refer to "Entering Text" on page 30.)
  - To insert the @ symbol, do the following:
    - Press the Left soft key. A pop-up menu appears in the display with the current text entry mode highlighted.
    - Select Shortcuts.
    - Select the @ symbol.
    - Enter the remainder of the e-mail address using the keypad. (For more information, refer to "Entering Text" on page 30.)
  - To add the domain type to the end of the e-mail address, do the following:

- Press the Left soft key. A pop-up menu appears in the display with the current text entry mode highlighted.
- Select Shortcuts.
- Select the desired domain type (such as, .com, .net, or .edu).
- 5. Press 💮 to save your changes.

# **Speed Dial Numbers**

You can assign and change Speed Dial numbers for Contacts entries.

- 1. In standby mode, press **MENU** ( ), then select **Contacts** 
  - → Speed Dial. The Speed Dial list appears in the display.

Tip: You can also assign a Speed Dial number when creating or editing a Contacts entry. See See "Assigning Speed Dial Numbers" on page 41. for more information.

- Enter a Speed Dial number in the Go To field or use the navigation keys to highlight a Speed Dial number.
- Press SET (
  ). The Set Speed Dial screen appears in the display.
- **4.** Enter a Contact name or use the navigation keys to highlight a Contact entry.
- Press You are prompted to confirm the new Speed Dial setting.

Press the Yes soft key to save the new setting. Press the No soft key to discard the new setting.

## **Renaming a Contacts Group**

Use this option to rename a group in your Contacts list.

- 1. In standby mode, press MENU ( ), then select Contacts
  - → **Group**. A list of group names (like the following list) appears in the display:
  - No Group
  - Business
  - Colleague
  - Family
  - Friends

Note: You cannot rename No Group.

- Use the Navigation keys to highlight the group (other than No Group) that you wish to rename, then press the Options soft key. The following options appear in the display:
  - Send Text Msg Lets you send a text message to all contacts in the selected Group.

- Send PIC Msg Lets you send a picture message to all contacts in the selected Group.
- Send Video Msg Lets you send a video message to all contacts in the selected Group.
- **Rename** Lets you change the name of the selected Group.
- Erase Lets you delete the selected Group (this does not delete the related Contacts).
- Add Lets you add a Contact to this Group.
- Select Rename. The Rename Group screen appears in the display. The current name of the selected group shows with a flashing cursor at the end of the name.
- Enter a new group name using the keypad. (For more information, refer to "Entering Text" on page 30.)
- **5.** Press to save the changed group name.

# **Deleting a Contacts Entry**

- 1. Find the desired entry in the Contacts list. (See "Finding a Contacts Entry" on page 37 for more information.)
- Press the Options (right) soft key ( ). A pop-up menu containing the following options appears in the display:
  - New Contact Lets you add an entry to your Contacts list.

- **Erase** Erases the selected Contact.
- Send Text Msg Lets you send a text message to the selected contact.
- Send PIC Msg Lets you send a picture message to the selected contact.
- Send Video Msg Lets you send a video message to the selected contact.
- Call Calls the highlighted Contact.
- Send Name Card With Bluetooth Lets you send the highlighted contact to another Bluetooth device.
- 3. Use the navigation keys to highlight Erase.
- **4.** Press 📆 . The phone prompts you to confirm the erasure.
- Press Yes to erase the Contacts entry or No to keep the entry.

# **Memory Info**

Use the Memory sub-menu to view the amount of Contacts entries you have stored, as well as the remaining memory.

- ▶ In standby mode, press **MENU** ( ), then select **Contacts** 
  - → **Memory Info**. The amounts of memory used and remaining for Contacts entries appear in the display.

# **Section 7: Messaging**

This section explains how to create, send, receive, and view different types of messages. This section also describes the features and functionality associated with messaging.

# **Accessing Your Messages**

- ➤ To access the Messages menu from standby mode, do one of the following:
  - Press the Messages shortcut (Up navigation) key.
  - Press MENU ( ), then select Messages.

The Messages menu appears in the display.

# **Creating and Sending New Messages**

This section guides you through procedures for creating and sending text messages, picture messages, and video messages.

# Creating and Sending a Text Message

- From the Messages menu, select Send Message → Text Message. The Create Text Msg screen appears in the display showing the To list.
- Address your message by selecting contacts and/or entering number(s) or e-mail address(es) of message recipient(s):

- To select a mobile number or e-mail address using your Contacts list, press Add. The following options appear in the display:
  - Contacts
  - Groups
  - Recent Calls

The **Contacts** option is highlighted.

Press the less key. The **Add Contacts** screen appears in the display. See "Finding a Contacts Entry" on page 37 for more information on finding a contact.

Use the Up and Down navigation keys to highlight a contact. Use the Left and Right navigation keys to select a phone Number or E-Mail address for the highlighted Contact. Press 👵 to mark your selection.

To add the selected contacts to the **Send To** list, press **Done**. The **Create Text Msg** screen appears in the display.

- To enter recipient e-mail address(es), press and hold to change the text entry mode from 123 to T9 word or abc. (For more information, refer to "Add a Number or E-Mail Address to an Existing Entry" on page 42.)
- $\textbf{3.} \quad \text{When you are finished addressing your message, press}$ 
  - The Text field appears in the display.
- Enter the text for your message using the keypad. (For more information, refer to "Entering Text" on page 30.)

- To change the text input method, do one of the following:
  - Repeatedly press and hold the key until the desired text input method is indicated by the left soft key label.
  - Press the Left soft key ( ), use the navigation keys to select the desired text input method, and press .
- Press the Left soft key ( ) to select one of the following text entry methods:
  - T9 Word
  - Abc
  - ABC
- 123
- Symbols
- At any point while composing a message, you can set message send options by pressing the **Options** (right) soft key (See "Message Send Options" on page 50 for more information.)
- Once you're finished composing your message, press the SEND key ( ) to send your message.

## Creating and Sending a Picture Message

From the Messages menu, select Send Message →
 Picture Message. The Create Pic Msg screen appears in
 the display with the To field highlighted.

- Address your message by selecting contacts and/or entering number(s) or e-mail address(es) of message recipient(s).
  - (See Step 2 of "Creating and Sending a Text Message" on page 46 for more information on addressing your message.)
- After addressing your picture message, the Subject field becomes highlighted.
- 4. Enter the Subject text using the keypad.

**6.** Enter the message text using the keypad.

- (See Step 4 of "Creating and Sending a Text Message" on page 46 for more information on choosing a text entry method, also see "Entering Text" on page 30 for more information on using text entry methods.)
- Press the Navigation key Down. The **Text** field becomes highlighted.
  - (See Step 4 of "Creating and Sending a Text Message" on page 46 for more information on choosing a text entry method, also see "Entering Text" on page 30 for more information on using text entry methods.)

- To set message send options, press Options. (See "Message Send Options" on page 50 for more information.)
- 8. To add a picture to the message, use the navigation keys to highlight the PIC field.
  - Press My PIC to access the picture gallery. If there are no pictures in the gallery, press Camera to launch the camera, then take a picture. If there are pictures in the gallery, thumbnail pictures appear in the display. Then, do the following:
    - Use the navigation keys to highlight a picture in the gallery.
    - Press **View** to expand the highlighted picture to fill the display.
    - Press Camera to activate the phone's camera and take a new picture.
       (For more information, refer to "Camera" on page 60.)
  - Press Options. (See "Message Send Options" on page 50 for more information.)
- Once you have selected a photo, press . The Create
  Pic Msg screen appears in the display with the selected
  photo in the PIC field.
  - The Sound field becomes highlighted.
- Press Sounds. The Record New option and a list of sound files appear in the display with the Record New option highlighted.

- **11.** Press the key to record a new sound file, or use the navigation keys to select a listed sound file.
  - If you select the **Record New** option, the **Record New** screen appears in the display. Press **REC** (
    ) to begin recording.
  - Wait for the beep, then start speaking. As it is recording the phone displays a countdown timer that shows the seconds remaining for the recording.
    - To pause the memo, press Pause When a memo is paused, press Resume to continue recording.
  - Press SAVE (
     ) to stop recording. The Record New option and a list of sound files appear in the display with the Record New option highlighted.
  - Use the Navigation key to highlight your new sound file and press
     The Create Pic Msg screen appears in the display with your selected sound file in the Sound field.
- **12.** Once you're finished composing your picture message, do one of the following:
  - Press 
     osen to SEND the message.
  - Press Options. (See "Message Send Options" on page 50 for more information.)

## Creating and Sending a Video Message

From the Messages menu, select Send Message →
 Video Message. The Create Video Msg screen appears in
 the display with the To field highlighted.

- Address your message by selecting contacts and/or entering number(s) or e-mail address(es) of message recipient(s), and press OK ( ).
  - (See Step 2 of "Creating and Sending a Text Message" on page 46 for more information on addressing your message.)
- After addressing your picture message, the Subject field becomes highlighted.
- 4. Enter the Subject text using the keypad.
  - (See Step 4 of "Creating and Sending a Text Message" on page 46 for more information on choosing a text entry method, also see "Entering Text" on page 30 for more information on using text entry methods.)
- Press the Navigation key Down. The **Text** field becomes highlighted.
- 6. Enter the message text using the keypad. (See Step 4 of "Creating and Sending a Text Message" on page 46 for more information on choosing a text entry method, also see "Entering Text" on page 30 for more information on using text entry methods.)

- To set message send options, press Options. (See "Message Send Options" on page 50 for more information.)
- To add a video to the message, use the navigation keys to highlight the Video field.
  - Press My Video to access the video gallery. If there are no videos in the gallery, press Video to launch the camcorder, then take a video. If there are videos in the gallery, thumbnail videos appear in the display. Then, do the following:
    - Use the Navigation key to highlight a video in the gallery.
    - Press Play to expand and review the video.
  - Press Video to activate the phone's camcorder and take a new video.
     (For more information, refer to "Camera" on page 60.)
  - Press Options. (See "Message Send Options" on page 50 for more information.)
- Once you have selected a video, press . The Create
  Video Msg screen appears in the display with the selected
  video in the Video field.
- 10. Once you're finished composing your video message, do one of the following:
  - Press 
     on to SEND the message.
  - Press Options. (See "Message Send Options" on page 50 for more information.)

# **Message Send Options**

You can set priority, validity, and other options before you send a message.

- After you've composed a text, picture, or video message, press Options. The following are Send Options that can appear in the display (which options appear depends on what type of message you composed and what message field you have highlighted):
  - Edit Send To Text Message Lets you change or add to your list of addressees.
  - Preview Picture/Video Message Lets you view a Picture or Video message as the recipient will see it.
  - Add Quick Text Picture/Video Message Lets you add precomposed text to a message.
  - Save As Draft Saves this message in the Drafts folder.
  - Save Quick Text Text Message Saves the text of this message as a Preset Message.
  - Priority Level Lets you assign a High or Normal priority to the message.
  - Validity Period Lets you set a Date and Time when this
    message will no longer be available to the recipient. After the set
    period of time, your message is recalled.

- Deferred Delivery Lets you set a Date and Time for message delivery.
- (Enh.) Deliver Ack Set to On to be alerted when your message is received by the addressee.
- **Remove PIC** Removes the picture from a Picture message.
- Remove Sound Removes the sound file from a Picture message.
- Remove Video Removes the video from a Video message.
- Add To Contacts Lets you add the addressee Numbers or E-Mail addresses to your Contacts list.
- Use the Navigation key to display the various Send Options for each menu item.
- When the desired send option is highlighted, press to confirm the selection or to enter the send option's submenu.

# **Receiving New Messages**

When you receive a message in standby mode, an alert sounds (unless turned off) and a **New Message** notification appears in the display along with the closed envelope icon ( ).

The date and time of the message and the following options also appear in the display:

• View Now — Opens the message in the pop-up.

 View Later — Closes the pop-up and saves the message to your Inbox where you can view it later.

Select the desired option.

## Receive Messages While in a Call

When you receive a message while in a call, a **New Message** notification appears in the display along with the closed envelope icon ( ). The date and time of the message and the following options also appear in the display:

- View Now Opens the message in the pop-up.
- View Later Closes the pop-up and saves the message to your Inbox where you can view it later.

Select the desired option.

## Voicemail

Voicemail allows callers to leave voice messages in your voice mailbox, and lets you review, play, and delete your voice messages any time you are in your Carrier's network coverage area.

# Voice Mail Setup

Before callers can leave voice mail messages, you must first set up your account. (See "Setting Up Your Voicemail" on page 7 and "Message Settings" on page 56 for more information.)

## Checking your Voicemail

- In standby mode, press and hold until you're connected to the voice mail system. A recorded message prompts you for a password.
- Enter your password, then follow the recorded prompts, to listen to your voice message, change administrative options. and so on.

# **Message Folders**

#### Inbox

Received messages of all types (except Voice Mail) are stored in the Inbox.

- From the Messages menu, select Inbox to open the Inbox folder
- 2. Use the Navigation key to highlight a message, then do one of the following:
  - Press Erase to delete the message.
  - Press **OPEN** to view the highlighted message, then proceed to Step 3.

Tip: You can also access your Voicemail by using the entries in the Voicemail folder. See "Voicemail" on page 55 for more information.

- Press **Options**. The following options appear in the display:
  - Reply Lets you reply to a message.
  - Reply With Copy Text Message only Lets you reply to a message and include a copy of the original message.
  - Forward Lets you forward the message to other E-Mail addresses or mobile phone numbers.
  - $\boldsymbol{-}$   $\boldsymbol{Lock}$  /  $\boldsymbol{Unlock}$  Blocks or allows erasure of the selected message.
  - Add To Contacts Lets you add the addressee numbers or E-Mail addresses to your Contacts list.
  - Erase Inbox Deletes all messages from the Inbox folder.
  - Message Info Lets you display status information about a message.

Select the desired option.

- Press to return to the **Messages** menu.
- 3. While viewing a selected message, do one of the following:
  - Press **Erase** to delete the message.
  - Press REPLY (
     ) to compose and send a message to the sender
     of the highlighted message.
  - Press **Options**, The following options appear in the display:
    - Play Again Picture Messages only Replay a sound file included with a Picture message.
    - Forward Lets you forward the message to other E-Mail addresses or mobile phone numbers.

- Reply With Copy Text Message only Lets you reply to a message and include a copy of the original message.
- Save PIC Picture Messages only Saves a copy of the image included in the selected message to the My Images gallery.
- Save Sound Picture Messages only Saves the sound file in the message to the My Sounds gallery.
- Save Video Video Messages only Saves the video file in the message to the My Videos gallery.
- Save Quick Text Saves the message text as a Preset Message entry.
- Lock / Unlock Block or allow changes to the selected message.
- Add To Contacts Lets you add the addressee numbers or E-Mail addresses to your Contacts list.
- Callback # -- Lets you call the originator of the message.
- Message Info Lets you display status information about a message.

Select the desired option.

Press to return to the **Inbox** list.

#### Messages and Lock Mode

Your phone can still receive messages while in Lock Mode. The time and date of the message appear in the display, but you cannot access the message until you enter the lock code. (For more information, refer to "Lock Phone" on page 116.)

#### Outbox

Your phone stores outgoing messages in the Outbox, regardless of whether the message was successfully sent to, or received by, the addressee.

Tip: Verify whether and when a message or e-mail was successfully received by enabling the Delivery Ack message send option. (See "Message Send Options" on page 50 for more information.)

- From the Messages menu, select Outbox. A list of your outgoing messages appears in the display.
- Use the Navigation key to highlight a message, then do one of the following:
  - Press Erase to delete the message.
  - Press OPEN (
    ) to view the highlighted message, then proceed to Step 3.
  - Press **Options**. The following options appear in the display:
    - Forward Send the message to another addressee.
    - Resend Re-send the message.

- Lock / Unlock Block a message from being erased or free a message to be erased.
- Add To Contacts Lets you add the addressee Numbers or E-Mail addresses to your Contacts list.
- Erase Outbox Erase all messages in the Outbox folder.
- Message Info Lets you display status information about picture messages.

Select the desired option.

- Press to return to the Messages menu.
- 3. While viewing a selected message, do one of the following:
  - Press Erase to delete the message.
  - Press RESEND (
     ) to resend a message to the original addressee
  - Press **Options**, The following options appear in the display:
    - Play Again Picture Messages only Replay a sound file included with a Picture message.
    - Forward Send the message to another addressee.
    - Erase Erase this message, if Unlocked.
    - Lock / Unlock Block a message from being erased or free a message to be erased.
    - Save Quick Text Save the message text in the Quick Text folder.
    - Add To Contacts Lets you add the addressee Numbers or E-Mail addresses to your Contacts list.
    - Go To URL Launches the Browser to access a URL in this message.

- Call Lets you call the recipient of the message.
- Message Info Lets you display status information about picture messages.

Select the desired option.

Press to return to the Outbox list.

## **Drafts Folder**

Messages in the Drafts folder are those that have been composed but never sent. You can return to the Drafts folder at any time to view, edit, or send a draft message.

- From the Messages menu, select Drafts. A list of your draft messages appears in the display.
- Highlight the message that you wish to edit, then do one of the following:
  - Press Erase to delete the message.
  - - Text Message Create Text Msg screen showing the Text field appears in the display.
    - Picture Message Create Pic Msg screen showing the To list appears in the display. Change or add numbers and addresses, then press ...
    - Video Message Create Video Msg screen showing the To list appears in the display. Change or add numbers and addresses, then press ...

Proceed to Step 3.

- Press **Options**. The following options appear in the display:
  - Send Send the message to the current addressee(s).
  - Lock/Unlock Block a message from being erased or free a message to be erased.
  - Add To Contacts Lets you add the addressee Numbers or E-Mail addresses to your Contacts list.
  - Save Quick Text Save the message text in the Quick Text folder.
- Erase Drafts Erase all messages in the Drafts folder.
   Select the desired option.
- Press to return to the **Messages** menu.
- If you press EDIT ( ), in the Text screen/field, do one of the following:
  - Press the Left soft key. The following options appear in the display:
    - T9 Word Predictive, single key press per letter text entry mode.
    - Abc Alphabetical, multiple key press text entry mode. The first letter is capitalized.
    - ABC Alphabetical, multiple key press text entry mode. All letters are capitalized.
    - 123 Enter numbers by pressing the corresponding key on the keypad.
    - Symbols Enter symbols into your message by pressing the corresponding number that appears above it in the display.
       Select the desired option.

- Press Options. (See "Message Send Options" on page 50 for more information.)
- 4. Once you're finished composing your message, do one of the following:
  - Press **SEND** ( ) to send your message.
  - Press for to exit the message. You are prompted to save your changed message to the Drafts folder.

#### Voicemail

New voice messages in your voice mailbox are logged in the Voicemail folder of the Messages menu. Open the Voicemail folder to view the Callback # (if available), Urgency, and other details of new voicemail messages.

- From the Messages menu, select Voicemail. A Voicemail status screen indicating the number of new messages in your voice mailbox, their urgency, and any callback numbers appears in the display.
- Press to call your voice mailbox and listen to your voice messages.

Note: You can, in standby mode, also press and hold to dial your voice mailbox.

## **Erasing Messages**

You can erase all of the messages in each/all of your message folders from one convenient location.

Note: This function erases all messages in a selected message folder or in all message folders. To delete a single message, from the Messages menu, open the message folder where the message to be deleted is stored, then select and delete the message from the Option menu while viewing the message content.

- From the Messages menu, select Erase Messages. The following options appear in the display:
  - Inbox Lets you delete all messages from your Inbox.
  - Outbox Lets you delete all messages from your Outbox.
  - **Drafts** Lets you delete all draft messages from the Drafts folder.
  - All Messages Lets you delete all messages from all message folders.
- Use the navigation keys to highlight the folder containing the messages that you wish to delete.
- Press to select the highlighted folder. You are prompted to confirm the erasure of all messages in the folder.
- Press No to cancel deleting any messages, or press Yes to delete all messages from the selected folder.

# **Message Settings**

The **Msg Settings** menu lets you define numerous message settings such as notification types and save options.

 From the Messages menu, select Msg Settings. The following Msg Settings options appear in the display:

#### General

- Auto Save Lets you set whether to automatically save to the Outbox folder, to discard, or to prompt you to save unsent messages when you exit them.
- Auto Erase Automatically erase the oldest read message after memory is full.
- Quick Text Lets you change pre-composed text or compose text for addition to your outgoing messages.
- Voicemail # -- Lets you update your Voicemail access number.
- Entry Mode Lets you set the default text entry mode [T9 Word, Abc/ABC (alphabetical), or 123 (numerical)] for composing message text.
- Callback # Lets you disable, enable, and update the callback number that can be inserted in outgoing messages.
- Signature Lets you disable, enable, and update the text signature that can be inserted in outgoing messages.
- Reminder Lets you choose whether to be reminded of new messages Once, Every 2 Minutes, Every 15 Minutes, or not at all (Off).

## · Text Message

Auto View — Automatically displays the message.

- Signature Lets you disable, enable, and update the text signature that can be inserted in outgoing Text messages.
- Auto Scroll When set to On, the phone automatically scrolls message text, letting you see the complete message text without using the Navigation key.

# Picture/Video Message

- Auto Receive Lets you choose whether to be prompted to receive new Picture/Video messages (Off) or to automatically receive new Picture/Video messages (On).
- Signature Lets you disable, enable, and update the text signature that can be inserted in outgoing Picture/Video messages.
- Select the desired option and value.

## Section 8: Browser

This section outlines how to launch Browser, how to navigate to other pages on the web, and how the keys on the keypad are used with the web application. Additionally, links to other sites are briefly discussed.

#### **Browser**

With Browser, you can conveniently surf the web and download ringtones and wallpapers using your phone. Each time you launch Browser, your phone connects to the Internet and the service indicator icon ( ) appears in the display.

#### Stored Web Content

Browser ends an Internet connection after a certain period of inactivity, however some information from your session remains stored in the phone (if you leave your phone turned on). You can access this information without reconnecting to the Internet. However, if you are viewing stored information, and you select a link to a site that was not accessed in your last session, you automatically re-connect to the Internet.

# **Launching Browser**

To launch Browser, do the following:

In standby mode, press MENU (

→ Go to Web.

Note: The first time you launch Browser, the warning message "Browse & Download use airtime," pops up in your display. To have this message repeat the next time you launch Browser, press the Continue soft key. To stop this message repeating, press the Remove soft key.

A list of categories (each representing one or more web sites) appears in the display.

- 2. Use the navigation keys to browse the categories.
- Once the desired category is highlighted, press the soft key to enter the category list.

#### Exit Browser

Press END<sup>®</sup> to exit Browser.

## **Using Browser**

When you use Browser, some of the keys operate differently than during a normal phone call. Browser presents on-screen items in any of the following ways:

- . Text or numeric input.
- · Links (embedded in content).
- · Numbered options (some may not be numbered).
- · Simple text.

You can act upon options or links by using the soft keys.

## Browser soft keys

The bottom of the Browser display is a bar that contains browser commands. The Left and Right ( ) soft keys on the keypad are used to execute the command that appears above them in the display. These are called "soft keys" because their function changes depending on the application.

# **Using Links**

Links have several purposes, such as jumping to a different page, to a different site, or even initiating a phone call. Links are shown inside of brackets ([ ]). You can normally use the Left soft key ( ) to select a link when it is highlighted.

# **How Browser Keys Work**

The following table lists Browser keys and their functions.



**Navigation keys** — Use to browse lists and options.



**Left Soft Key** — Press to activate the command that appears above it in the display.



**Right Soft Key** — Press to activate the command that appears above it in the display.



**BACK Key** — A browse, back-up key. Press once to back up one page. Press and hold to go back to home page.

Press to clear the last number, letter, or symbol entered. Press and hold to completely clear the display.



**Asterisk/Shift Key** — Press before entering text to enable uppercase characters.



**Last Key** — Press to enter a zero (0), or to move to the last item in a menu.



**Pound/Space Key** — Press to insert a space when entering text.



**Number 1 thru 9** — Use the number keys to select items in a menu if they are numbered.



**End Key** — Press to exit the Browser and return the phone to standby mode.

## **Section 9: Brew**

This section explains the Brew feature where users can download multimedia, applications, games, and check news and sports.

# **Finding Applications**

With Brew, you can download full featured applications over the air including games, personalized ring tones, pictures, and more. To launch **Brew**, do the following:

▶ In standby mode, press MENU (♠), then select Brew → Brew.

#### Section 10: Camera

Use your The r500 phone to take full color digital pictures and videos, display them on your phone's vivid color display, and instantly share them with family and friends. It's fun, and as easy to use as a traditional point-and-click camera or camcorder. This section explains how you can do the following:

- Take pictures and videos with your phone's built-in digital cameracamcorder.
- Send and receive pictures and videos taken with your phone's cameracamcorder.
- Set the several options associated with the camera-camcorder that help you take crisp, clear pictures and videos.

# **Taking Pictures and Videos**

Taking pictures and videos with the built-in camera-camcorder is as simple as choosing a subject, pointing the lens (located on the rear of your phone, at the top), and pressing a button.

## **Taking Snap Shots (Single Pictures)**

To take a single picture using the current camera settings, do the following:

In standby mode, press and hold the Camera key ( so on the right side of the phone.

The message "**Loading**" appears in the display followed by a camera view finder screen. (For more information, refer to "Screen Layouts" on page 63.)

Note: You can also activate the camera by pressing MENU (⊕), then select Multimedia → Camera.

- Using the display as a viewfinder, point the camera at your subject.
- When the image that you wish to capture appears in the display, press Take ( ), then do one of the following:
  - Press the Save soft key to save the picture to memory.
  - Press Send ( ) to save the picture and include it in a Picture message.
  - Press the Erase soft key to erase the photo.

Tip: You can change a number of the camera's settings to suit particular uses for your pictures. For more information, refer to "Camera Options" on page 65.

#### **Taking Multi Shot Pictures**

When taking pictures of moving subjects or subjects you cannot pose, such as children and pets, the camera's Multi Shot mode simplifies the process of taking multiple pictures in quick succession. After taking Multi Shot pictures, the camera automatically displays thumbnail views of the pictures you have just taken so you can select the best picture(s) and discard the rest.

In standby mode, press and hold the Camera key ( )
 on the right side of the phone. The message "Loading"
 appears in the display followed by a camera view finder
 screen. (See "Screen Layouts" on page 63. for more
 information.)

Note: You can also activate the camera by pressing MENU (♠), then select Multimedia → Camera.

- Press the Options soft key. The options menu bar appears in the display with the Self Timer icon ( ) highlighted.
- Use the Left and Right navigation keys to highlight the Multi Shot icon ( ). The following Multi Shot options appear in the display:
  - Series Shot Lets you take a series of 3 or 5 photos.

- Divided Shot Lets you take a mosaic of 4 or 9 photos.
- Auto/Manual Lets you select to take the multiple photos automatically (in quick succession) or to take each successive photo manually.
- 4. When you select Series Shot, the following options appear in the display:
  - Off
  - 3
  - 5

When you select **Divided Shot**, the following options appear in the display:

- Off
- 4
- 9
- 5. Select 3 or 5 (Series Shot) or select 4 or 9 (Divided Shot).

Using the display as a viewfinder, point the camera lens at your subject.  when the image that you wish to capture appears in the display, press Take ( ). The camera takes one picture (Manual) or multiple pictures in quick succession (Auto), then the Series Shot Select to Save screen or the Divided Shot multiple-photo screen appears in the display.

#### Series Shot:

- To save the pictures to memory, press the **Done** soft key.
- To discard the pictures, press \(\text{clr}\).

#### · Divided Shot:

- To save the pictures to memory, press the **Save** soft key.
- To send the picture in a picture message, press **Send** ( ).
- To discard the pictures, press the **Erase** soft key.

## **Taking Videos**

To take a video using the current camcorder settings, do the following:

Press and hold the Camera key ( ) a second time.
 The message "Loading" appears in the display followed by the camcorder view finder screen. (See "Camcorder Screen" on page 64 for more information.)

Note: You can also activate the camcorder by doing one of the following:

- Pressing MENU (⊕), then select Multimedia → Camcorder.
- 2. From the camera screen, by pressing the **Camera** key ( **B** ).
- 3. From the camera screen, by pressing the **Options** soft key, then selecting the Camcorder icon.
- Using the display as a viewfinder, point the camera lens at your subject.
- 4. Press Rec ( ) when the image that you wish to capture appears in the display. Recording continues until you press Stop ( ) or until 15 seconds of video has been recorded, whichever comes first, then do one of the following:
  - Press the Save soft key to save the video to memory.

  - Press the **Erase** soft key to erase the photo.

## **Screen Layouts**

#### Camera Screen

When you activate your phone's camera, the second line of the display is reserved for the current camera resolution setting and the picture counter. The center of the display shows a viewfinder image of the subject at which the camera is pointed. The soft key



labels on the bottom line of the display change to the following:

- My Images Pressing the Left soft key opens the My Images multimedia folder so vou can view or manage vour stored pictures. (For more information, refer to "The Photo Gallery" on page 77.)
- Take Pressing Take ( ) takes a picture of the image currently appearing on the display.
- Options Pressing the Right soft key opens a menu bar of camera options and settings.

#### Camera Screen Icons



**Camera** — Indicates the camera is active.




Night Shot — Indicates the camera is set to take pictures in low light.



**Quality** — Indicates camera's picture quality setting. (You can change the picture quality setting. See "Quality" on page 74. for more information.)



Camera Resolution — Indicates camera's current 謂 resolution setting. (You can change the camera resolution setting. For more information, refer to "Camera Options" on page 65.)



White Balance — Indicates camera's white balance AUM setting. (You can change the camera white balance setting. For more information, refer to "White Balance" on page 74.)

**Phone Memory** — Indicates photos will be stored in the phone's memory.

**Card Memory** — Indicates photos will be stored on a microSD Memory Card.

**Zoom** — Enlarges the image from X0 to X9 before ⟨⟩♪₿□ you take a picture. (Depending on the camera resolution setting.)

**Brightness** — Brightens or darkens the image from ≎eza0 -4 to +4

Multi Shot in use (Divided Shot) — Takes multiple pictures automatically (as shown) or manually ( when you press the key. The number of pictures taken depends upon the Divided Shot setting.



## Multi Shot in use (Series Shot) —



**Self Timer in use** — Delays the camera shutter from 2 to 10 seconds after you press the key.

#### Camcorder Screen

When you activate your phone's camcorder, the first line of the display is shows current camcorder setting icons. The center of the display shows a viewfinder image of the subject at which the camcorder is pointed. The soft key labels on the bottom line of the display change to the following:



- My Videos Pressing the Left soft key opens the My Videos multimedia folder so you can view or manage your stored pictures. (For more information, refer to "The Photo Gallery" on page 77.)
- Rec Pressing Rec ( ) starts the camcorder recording a video of the image currently appearing in the display.
- Options Pressing the Right soft key opens a menu bar of camcorder options and settings.

#### Camcorder Screen Icons



**Camcorder** — Indicates the camcorder is active.



Quality — Indicates camcorder's video quality setting. (You can change the video quality setting. See "Quality" on page 74. for more information.)



Memory Available — Indicates the percentage of memory available for you to store a video.



White Balance — Indicates the camcorder's white balance setting. (You can change the camcorder white balance setting. See "White Balance" on page 74. for more information.)



**Phone Memory** — Indicates videos will be stored in the phone's memory.



Card Memory — Indicates videos will be stored on a microSD Memory Card.



**Zoom** — Enlarges the image from X0 to X9 before you take a video. (Depending on the camcorder quality setting.)



**Brightness** — Brightens or darkens the image from -4 to +4.



**Self Timer in use** — Delays the camcorder from recording for from 2 to 10 seconds after you press the Rev.

Recording Mode — Indicates camcorder is in MMS mode (as shown) with Quality and recording time limits or in Normal mode (

## **Saving Pictures and Videos**

After you've taken a picture or video, you can do any of the following:

- Save the picture or video by pressing the Save soft key.
   A picture is stored in the My Images folder. A video is stored in the My Videos folder. These folders are part of the phone's memory and/or part of an optional Memory Card devoted to storing, browsing, and viewing saved pictures and videos. (See "The Photo Gallery" on page 77. for more information.)
- Discard the picture or video by pressing the Erase soft key.

## **Camera Options**

The Camera Options let you adjust the default camera settings to suite available lighting, the subject of the photo, or the purpose of the photo. To access Camera Options, do the following:

- Press and hold the **Options** soft key. The following submenus appear in the display:
  - Self Timer
  - Multi Shot
  - Quality
  - Resolution
  - · White Balance
  - Fun Tools
  - Settings
- Camcorder
- Use the Left and Right navigation keys to highlight a desired option.
- **4.** Use the Up and Down navigation keys to highlight a **Setting**.

Use the Up and Down navigation keys to highlight an option or setting value, then press to save the selected setting.

## **Self Timer**

Self Timer lets you delay taking a picture long enough to let you join others in a picture.

- In camera mode, press the **Options** soft key. The options menu bar appears in the display.
- Use the Left and Right navigation keys to highlight Self Timer.
- Use the Up and Down navigation keys to highlight one of the following Self Timer options:
  - Off
  - 2 Sec.
  - 5 Sec.
  - 10 Sec.
- Press ... If you select 2 Sec., 5 sec., or 10 sec., the Self Timer icon appears in the camera screen in the display.

The next time you press , the countdown timer indicates the time remaining before the camera takes the picture. The phone reads the countdown timer value beginning with two or three and continuing to zero, when the picture is taken.

#### **Multi Shot**

Multi Shot lets you take multiple pictures in succession at the touch of a key.

- In camera mode, press the **Options** soft key. The options menu bar appears in the display.
- Use the Left and Right navigation keys to highlight Multi Shot.
- 3. Use the Up and Down navigation keys to highlight one of the following Multi Shot options:
  - Series Shot Off / 3 pictures taken in succession / 5 pictures taken in succession.
  - Divided Shot Off / 4 of the same new picture in a 2-by-2 array / 9 of the same new picture in a 3-by-3 array.
  - Auto/Manual Automatically takes pictures / You Manually take the pictures.

 Press to save the setting. The camera screen appears in the display.

Note: When a Multi Shot option is set to a value other than Off, either a Series
Shot progress bar (
appears in the viewfinder screen.

The next time you press ( ), the camera takes several pictures in rapid succession.

# Quality

You can affect how much your photo is compressed, thereby reducing it's overall size (not to be confused with resolution).

- In camera mode, press the **Options** soft key. The options menu bar appears in the display.
- 2. Use the Left and Right navigation keys to highlight Quality.
- Use the navigation keys to highlight one of the Quality options: Fine, Normal, or Economy.
- Press . You're returned to the camera viewfinder screen.

## Resolution

Change the size (in bytes) of your pictures using the Resolution setting.

- In camera mode, press the **Options** soft key. The options menu bar appears in the display.
- Use the Left and Right navigation keys to highlight Resolution.
- Use the Up and Down navigation keys to highlight one of the following Resolution options:
  - 1280 X 960 (pixels)
  - 640 X 480 (pixels)
  - 320 X 240 (pixels)
  - 176 X 144 (pixels)
  - 160 X 120 (pixels)
  - Picture ID lets you take pictures the correct size and resolution for Contacts list picture IDs.
- Press . You're returned to the camera viewfinder screen.

Note: The Resolution setting affects zoom capabilities. When Resolution is set to 1280 X 960, zoom is not available. When Resolution is set to any value lower than 1280 X 960, zoom settings 1 – 9 are available.

#### White Balance

White Balance allows you to adjust picture quality according to available light.

- In camera mode, press the **Options** soft key. The options menu bar appears in the display.
- Use the Left and Right navigation keys to highlight White Balance.
- 3. Use the Up and Down navigation keys to highlight one of the following White Balance options:
  - Auto The camera automatically adjusts picture quality to available light.
  - **Sunny** Use this setting when taking pictures in full sun.
  - Cloudy Use this setting when taking pictures in cloudy conditions.
  - Tungsten Use this setting when taking pictures under incandescent lights.
  - Fluorescent Use this setting when taking pictures under fluorescent lights.

Each option, as you highlight it, shows the effects it has on a picture.

4. When you decide on the White Balance you wish to use, press . The camera viewfinder screen appears in the display with your selected White Balance applied.

The next time you press , the camera applies the selected White Balance to your picture.

#### Fun Tools

#### **Color Effects**

Change the look of your pictures with Color Effects. Choose from nine available settings such as Antique, Negative, and Sepia. The selected color effect previews in the display before you take the picture.

- In camera mode, press the **Options** soft key. The options menu bar appears in the display.
- Use the Left and Right navigation keys to highlight Fun Tools.
- Select Color Effects. The following options appear in the display:

Note: Choose Normal to disable Color Effects.

- **Normal** Subjects and pictures appear with a normal hue.
- Black&White Subjects and pictures appear in black and white.
- **Sepia** Subjects and pictures appear in a brownish-gray hue.
- **Antique** Subjects and pictures appear in a grayish-green hue.
- **Negative** Subjects and pictures appear in inverted colors.

- **Green** Subjects and pictures appear in a greenish hue.
- **Aqua** Subjects and pictures appear in an aqua hue.
- **Cool** Subjects and pictures appear in a bright blue hue.
- Warm Subjects and pictures appear in a reddish hue.
- Select the desired Color Effect. You're returned to the camera viewfinder screen.

When you take your next picture, the phone's display previews your subject image with the selected Color Effect

#### **Fun Frames**

Fun Frames lets you temporarily apply one of the preloaded picture frames in your phone to characterize or enhance one or more pictures.

#### Note: The None frame is a blank frame.

- In camera mode, press the **Options** soft key. The options menu bar appears in the display.
- Use the Left and Right navigation keys to highlight Fun Tools
- Select Fun Frames. A pop-up menu of the available Fun Frames appears in the display.

- Use the Up and Down navigation keys to show the various Fun Frames.
- When you decide on the frame you wish to use, press The camera screen appears in the display with your selected Fun Frame in place.

The next time you press (a), the camera includes the selected Fun Frame in your picture.

## **Settings**

## Memory

- In camera mode, press the **Options** soft key. The options menu bar appears in the display.
- Use the Left and Right navigation keys to highlight Settings.
- Select Memory. The following Memory options appear in the display:
  - **Phone** Stores pictures in phone memory.
  - Card Stores pictures on an optional microSD Memory Card.
- Select the desired memory location. You're returned to the camera viewfinder screen.

#### Auto Save

- In camera mode, press the **Options** soft key. The options menu bar appears in the display.
- Use the Left and Right navigation keys to highlight Settings.
- Select Auto Save. The following options appear in the display:
  - Off
  - On
- Select the desired automatic save setting. You're returned to the camera viewfinder screen.

### **Icon Display**

- In camera mode, press the **Options** soft key. The options menu bar appears in the display.
- Use the Left and Right navigation keys to highlight Settings.
- Select Icon Display. The following options appear in the display:
  - Display All Shows camera icons as seen in "Camera Screen lcons" on page 63.

- Guideline Shows a cross hatch pattern in the view finder screen.
- No Icons Shows a nearly full-display subject image and without icons.
- Select the desired viewfinder display setting. You're returned to the camera viewfinder screen.

### Metering

- In camera mode, press the **Options** soft key. The options menu bar appears in the display.
- Use the Left and Right navigation keys to highlight Settings.
- Select Metering. The following options appear in the display:
  - Average Adjusts exposure to the average light level over a large picture area.
  - Center Adjusts exposure to the average light level over a center portion of the subject.
  - Spot Adjusts exposure to the light level over a small portion of the subject.
- Select the desired Metering setting. You're returned to the camera viewfinder screen.

When you take your next picture, the phone's display previews your subject image with the measured exposure.

#### **View Mode**

- In camera mode, press the **Options** soft key. The options menu bar appears in the display.
- Use the Left and Right navigation keys to highlight Settings.
- Select View Mode. The following options appear in the display:
  - Landscape Shows a wider, more panoramic view of the subject.
  - Portrait Shows a narrower, more vertically oriented view of the subject.
- Select the desired View Mode setting. You're returned to the camera viewfinder screen, which now shows the selected view.

# **Night Shot**

- In camera mode, press the Options soft key. The options menu bar appears in the display.
- Use the Left and Right navigation keys to highlight Settings.

- Select Night Shot. The following options appear in the display:
  - Off
  - On
- Select the desired Night Shot setting. [If On, the Night Shot icon ( ) appears in the viewfinder screen.] You're returned to the camera viewfinder screen.

#### **Shutter Sound**

Choose from four different sounds whenever you take a picture. Aside from being a cool sound effect, Shutter Sounds acts as an audible reminder that your camera has taken a picture.

- In camera mode, press the **Options** soft key. The options menu bar appears in the display.
- Use the Left and Right navigation keys to highlight Settings.
- Select Shutter Sound. The following shutter sounds appear in the display:
  - Off
  - Shutter
  - OK
  - DingDong

Select the desired shutter sound. You're returned to the camera viewfinder screen.

# **Reset Settings**

- In camera mode, press the **Options** soft key. The options menu bar appears in the display.
- Use the Left and Right navigation keys to highlight Settings.
- Select Reset Settings. You are prompted to confirm reset of all camera settings.
  - To reset the camera settings to default values, select Yes.
  - To keep the current camera settings, select No.

### Camcorder

- In camera mode, press the **Options** soft key. The options menu bar appears in the display.
- Use the Left and Right navigation keys to highlight Camcorder, then press the key. The Camcorder view finder screen appears in the display.

# **Camcorder Options**

The Camcorder Options let you adjust the default camcorder settings to suite available lighting, the subject of the video, or the purpose of the video. To access Camcorder Options, do the following:

- I. In standby mode, press and hold the Camera key
  ((西)). The camera viewfinder screen appears in the
  display. The message "Loading" appears in the display
  followed by the camera view finder screen.
- Press and hold the Camera key ( ). The message "Loading" appears in the display followed by the camcorder viewfinder screen.
- 3. Press the **Options** soft key. The following sub-menus appear in the display:
  - Recording Mode
  - Self Timer
  - Quality
  - White Balance
  - Color Effects
  - Settings
  - Camera

 Use the Left and Right navigation keys to highlight the desired option and/or setting, then press to save the selected setting.

# Recording Mode

- In camcorder mode, press the **Options** soft key. The options menu bar appears in the display.
- Select Recording Mode. The following options appear in the display:
  - Limit for MMS Record videos that are a maximum of 15 seconds long. The videos can be included in video messages.

Note: Setting Recording Mode to Limit for MMS automatically sets  ${\bf Quality}$  to Economy.

- Normal Record videos that are any length up, depending on available memory.
- Select the desired recording mode setting. The camcorder screen reappears in the display.

#### Self Timer

Self Timer lets you delay taking a video long enough to let you join others in the video.

- In camcorder mode, press the **Options** soft key. The options menu bar appears in the display.
- 2. Select Self Timer.
- 3. The following options appear in the display:
  - Off
  - 2 Sec.
  - 5 Sec.
  - 10 Sec.
- Select the desired delay. The camcorder screen reappears in the display.

The next time you press , a countdown timer in the display indicates the time remaining before the camcorder starts recording the video. The phone reads the countdown timer value beginning with two or three and continuing to zero, when recording begins.

Tip: To stop the countdown timer without resetting it, press \textstarr.

### Quality

You can affect how much your video is compressed, thereby reducing it's overall size (not to be confused with resolution).

Note: Quality is automatically set to Economy when you set Recording Mode to Limit for MMS.

- In camcorder mode, press the **Options** soft key. The options menu bar appears in the display.
- 2. Use the Left and Right navigation keys to highlight Quality.
- Select Fine, Normal, or Economy.
- 4. You're returned to the camcorder viewfinder screen.

### White Balance

White Balance allows you to adjust video quality according to available light.

- In camcorder mode, press the **Options** soft key. The options menu bar appears in the display.
- Use the Left and Right navigation keys to highlight White Balance. The name of the current White Balance setting appears in the second line of the display. The options are:
  - Auto The camcorder automatically adjusts color balance to available light.

- **Sunny** Use this setting when recording videos in full sun.
- Cloudy Use this setting when recording videos in cloudy conditions.
- Tungsten Use this setting when recording videos under incandescent lights.
- Fluorescent Use this setting when recording videos under fluorescent lights.
- Use the Up and Down navigation keys to show the various White Balances and the effects they have on a video.
- Select the desired White Balance. The camcorder viewfinder screen appears in the display with your selected White Balance applied.

The next time you press , the camcorder applies the selected White Balance to your video.

#### **Color Effects**

Change the look of your videos with Color Effects. Choose from nine available settings such as Gray, Negative, and Sepia. The selected color effect previews in the display before you take the picture.

 In camcorder mode, press the **Options** soft key. The options menu bar appears in the display. 2. Select one of the following **Color Effects**:

Note: Choose Normal to disable Color Effects.

- **Normal** Subjects and pictures appear with a normal hue.
- $\bullet$   $\,$  Black&White Subjects and pictures appear in black and white.
- **Sepia** Subjects and pictures appear in a brownish-gray hue.
- Antique Subjects and pictures appear in a grayish-green hue.
- **Negative** Subjects and pictures appear in inverted colors.
- **Green** Subjects and pictures appear in a greenish hue.
- Aqua Subjects and pictures appear in an aqua hue.
- **Cool** Subjects and pictures appear in a bright blue hue.
- Warm Subjects and pictures appear in a reddish hue.

  You're returned to the camcorder viewfinder screen.
- When you record your next video, the phone's display previews your subject image with the selected color effect.

# Settings

# Memory

- In camcorder mode, press the **Options** soft key. The options menu bar appears in the display.
- 2. Use the Left and Right navigation keys to highlight **Settings**.

- Select Memory. The following Memory options appear in the display:
  - Phone Stores videos in phone memory.
  - Card Stores videos on an optional microSD Memory Card.
- Select the desired memory location setting of your choice.
   You're returned to the camcorder viewfinder screen.

#### **Auto Save**

- In camcorder mode, press the **Options** soft key. The options menu bar appears in the display.
- Use the Left and Right navigation keys to highlight Settings.
- Select Auto Save. The following options appear in the display:
  - Off
  - On
- Select the desired automatic save setting of your choice.
   You're returned to the camcorder viewfinder screen.

### **Icon Display**

In camcorder mode, press the **Options** (right) soft key
 The options menu bar appears in the display.

- Use the Left and Right navigation keys to highlight Settings.
- Select Icon Display. The following options appear in the display:
  - Display All Shows camcorder icons as seen in "Camcorder Screen Icons" on page 64.
  - No Icons Shows a nearly full-display subject image and without icons.
- Select the desired viewfinder screen setting. You're returned to the camcorder viewfinder screen.

#### **Start Sound**

Choose from two different sounds whenever you begin video recording. Aside from being a cool sound effect, Start Sound acts as an audible reminder that your camcorder has begun recording a video.

- In camcorder mode, press the **Options** soft key. The options menu bar appears in the display.
- Use the Left and Right navigation keys to highlight Settings.
- Select Start Sound. The following options appear in the display:

- Off
- · Look here
- 1,2,3!
- Select the desired start sound. You're returned to the camcorder viewfinder screen.

#### **End Sound**

Choose from two different sounds whenever you stop video recording. Aside from being a cool sound effect, End Sound acts as an audible reminder that your camcorder has stopped recording a video.

- In camcorder mode, press the **Options** soft key. The options menu bar appears in the display.
- Use the Left and Right navigation keys to highlight Settings.
- Select End Sound. The following options appear in the display:
  - Off
  - OK
  - Melody
- Select the desired end sound. You're returned to the camcorder viewfinder screen.

#### Reset Settings

- In camcorder mode, press the **Options** soft key. The options menu bar appears in the display.
- Use the Left and Right navigation keys to highlight Settings.
- Select Reset Settings. You are prompted to confirm reset of all camcorder settings.
  - Select the Yes option to reset the camcorder settings to default values.
  - Select the **No** option to keep the current camcorder settings.

#### Camera

- In camcorder mode, press the Options soft key. The options menu bar appears in the display.
- Use the Left and Right navigation keys to highlight Camera, then press . The Camera viewfinder screen appears in the display.

### Zoom

Zoom lets you temporarily enlarge the pictures you take. Increasing the Zoom (1-9) enlarges your pictures or videos (0 is normal).

 In camera or camcorder viewfinder screen, use the Left and Right navigation keys to adjust the Zoom (the screen image enlarges to show the affects of your changes).

The next time you press , the camera takes an enlarged picture or the camcorder takes an enlarged video according to your selected Zoom setting.

# **Brightness**

Brightness lets you temporarily lighten the pictures you take. Increasing the Brightness (-4 - +4) lightens your pictures (0 is normal).

 In camera or camcorder viewfinder screen, use the Up and Down navigation keys to adjust the Brightness (the screen image lightens or darkens to show the affects of your changes).

The next time you press , the camera takes a lighter or darker picture or the camcorder records a lighter or darker video according to your selected Brightness setting.

# The Photo Gallery

Saved pictures are stored in the My Images folder. You can browse the pictures one at a time (expanded mode), or view several pictures at once in thumbnail format.

 In the Camera viewfinder screen, press the My Images soft key. Any pictures that you've saved appear in the display.

Note: You can also access My Images by pressing MENU (m), then selecting Multimedia  $\rightarrow$  My Images.

- 2. Use the Navigation key to browse pictures in the gallery.
- Press the **Options** soft key while viewing pictures in the Gallery.

The following options appear in the display:

- Send Send the currently displayed or highlighted picture as a Picture message.
- Set As Assign the currently displayed or highlighted picture to be standby screen Wallpaper or as a Picture ID for someone in your Contacts list.
- **Slide Show** Show the pictures as a full screen slide show.
- Rename Rename the currently displayed or highlighted picture.
- Move Relocate the currently displayed or highlighted picture from phone memory to a Memory Card or from a Memory Card to phone memory.
- Lock / Unlock Lock the currently displayed or highlighted image so that it cannot be deleted, or unlock the image so that it can be deleted

- Erase Files Mark and erase selected unlocked image files.
- Picture Info View the Title, time and date created, size, and resolution of the currently highlighted or displayed picture.
- Send With Bluetooth Send a copy of this picture to another Bluetooth device.
- Select the desired option to perform the function for the option or enter its sub menu.

### Switch From Expanded to Thumbnail Mode

- Use the Navigation key to highlight a picture that you wish to view full size, then press
- To return to the thumbnail view of your photos, press again.

# The Video Gallery

Saved videos are stored in the My Videos folder. You can view the videos one at a time (expanded mode), or browse several videos at once in thumbnail format

 In the Camcorder viewfinder screen, press the My Videos soft key. Any videos that you've saved appear in the display.

Note: You can also access My Videos by pressing MENU (⊕), then select Multimedia → My Videos.

- 2. Use the Navigation key to browse videos in the gallery.
- Press the **Options** soft key while viewing videos in the gallery. The following options appear in the display:
  - Send Send the currently displayed or highlighted video as a Video message.
  - Set As Assign the currently displayed or highlighted video to be the Main standby screen Wallpaper.
  - **Rename** Rename the currently displayed or highlighted video.
  - Move Relocate the currently displayed or highlighted video from phone memory to a Memory Card or from a Memory Card to phone memory.
  - Lock / Unlock Lock the currently displayed or highlighted video so that it cannot be deleted, or unlock the video so that it can be deleted.
  - Erase Files Mark and erase selected unlocked video files.
  - Video Info View the Name, time and date created, resolution, size, and duration of the currently highlighted or displayed video.
- Use the Navigation key to highlight the desired option.
   Press to perform the function for the option or enter its sub menu.

# Switch From Expanded to Thumbnail Mode

 Use the Navigation key to highlight a video that you wish to play full size, press . The media player launches and begins playing the selected video.



Press the Up navigation key to return to the thumbnail view of your videos.

# Point, Click, and Send Pictures and Videos

Take a picture or record a video and send it to anyone with a compatible device in a few easy steps.

1. In standby mode, press and hold the Camera key ( to activate the camera.

Press and hold the Camera key ( a second time to activate the camcorder.

Note: To record a video for inclusion in a Video Message, the camcorder Recording Mode option must be set to Limit for MMS. (For more information, refer to "Recording Mode" on page 73)

- Using the display as a viewfinder, take the desired picture or record the desired video by pressing .
   To stop video recording, press a second time.
- Press Send (
  ). The picture or video is saved automatically, and the Create Pic Msg or Create Video Msg screen appears in the display.
- **4.** Enter the recipient's phone number or e-mail address using the keypad.
- Press to save the address(es) and move to the Subject field. Use the Navigation key to move to the other message fields. (For more information, refer to "Messaging" on page 46).
- When you are finished composing your message, press SEND ( ) to send the Picture or Video message to the intended recipients.

### Section 11: Multimedia

This section outlines your phone's multimedia functions and key features associated with multimedia.

# **Accessing Multimedia**

- In standby mode, press MENU ( ), then select
  Multimedia. The following Multimedia sub-menus appear
  in the display:
  - Camera Lets you launch and set up your phone's camera. (For more information, refer to "Camera" on page 60.)
  - **Camcorder** Lets you launch and set up your phone's camcorder. (For more information, refer to "Camera" on page 60.)
  - Music Player Lets you play and manage music files stored on a memory card.
  - My Images Lets you choose the multi-media or pictures that appear in your phone's display.
  - My Videos Lets you choose the videos that appear in your phone's display.
  - My Ringtones Lets you assign melody tones for calls, alarms, and other alerts.
  - My Sounds Lets you assign melody tones for calls, alarms, and other alerts

- Use the Up and Down navigation keys to highlight a submenu.
- Press to launch the highlighted sub-menu. The following sections describe the above listed sub-menus in greater detail.

# **Music Player**


Music Player lets you play downloaded music files (MP3) stored on a Memory Card.

### Launching the Music Player Library Menu

 From the Multimedia menu, select Music Player.

The **Library** screen appears in the display, showing the following music lists:

 All — Lists all music files on the Memory Card and lets you play individual music files or play multiple music files by creating a temporary music playlist.



- Artists Lists artist names for music files on the Memory Card and lets you play one or more music files by a selected artist.
- Albums Lists album titles for music files on the Memory Card and lets you play one or more music files from a selected album.
- Genres Lists music categories for music files on the Memory Card and lets you play one or more music files of a particular music category.
- Playlists Lists any playlists you have saved and lets you create, save, and manage playlists.

Ratt

**★** ■ ■ ▶ · · · · ·

All

44f128r.mp3

44f32r.mp3

44f64r.mp3

- 2. Use the Up and Down navigation keys to highlight a music list, then press **VIEW** ( ).
- Use the Up and Down navigation keys to highlight a music file, then:
  - Press the **Play** soft key to play the file.
  - Press MARK (
    ) to select one or more files for playing or other options.
  - Press the **Options** soft key to select and apply any of the following options to the highlighted or marked music files(s):
    - Mark All Marks all listed music files for playing, removal, or assignment of player settings.

- Remove Deletes marked music file(s) from the Memory Card.
- Properties Lists the title, artist, album, genres, copyright information, time length, file size, and bit rate of the highlighted music file.
- Player Settings Lets you assign a particular playback visual to, and view Memory Info for, highlighted or marked music file(s).
   Select the desired option.

# Plaving Music

 From the Multimedia menu, select Music Player.

The **Library** screen appears in the display, showing the following music lists:

- All
- Artists
- Albums
- Genres
- Playlists



- Use the Navigation key to highlight the desired option. press **VIEW** ( ), and then do one of the following:
  - All option Use the Up/Down navigation keys to highlight a music file, then press the Play soft key to play the file.

the Play soft key to play the file.



Tip: To play additional files, highlight and Mark additional files for playback. (For more information, see "Launching the Music Player Library Menu" on page 81.)

> • Other options — Use the Up/Down navigation keys to highlight an Artist, Album, Genre, or Playlist, then press **VIEW** ( ). Use the Up/Down navigation keys to highlight a music file, then press

The Music Player screen appears in the display and the selected music file/playlist begins playing.

### **Music Player Controls**

- Volume kev:
  - To play a music file louder, press the Volume key Up.
  - To play a music file softer, press the Volume key Down.

# Navigation key:

- To pause/resume playing a music file, press 🔞.



Note: With the flip closed, use the Camera key to pause/resume playing a music file.

- To stop playing a music file, press the Down navigation key.
- To skip play to an earlier music file in the selected list, press the Left navigation key.
- To skip to an earlier portion of this music file, press and hold the Left navigation key.
- To skip play to a later music file in the selected list, press the Right navigation key.
- To skip to an later portion of this music file, press and hold the Right navigation key.
- To return to the selected list and choose another music file to play. press the Up navigation key.
- Library soft key Returns you to the Library screen.
- Options soft key Shows the following sub-menus and options:
- Play Mode Lets you change the play mode from Normal. Shuffle. Repeat One, Repeat All, or Shuffle Repeat All.
- Add to Playlist Moves you to the Playlists menu to let you add the selected music file to a playlist.
- Remove Deletes the selected music file from the Memory Card

- Properties Lists the title, artist, album, genre, copyright information, time length, file size, and bit rate of the highlighted music file.
- Visualizer Lets you change the Music Player visualization to Simple View. Equalizer. Album Art. or Lyrics.
- Memory Info Displays the Memory Usage screen which lists Memory Card usage and availability amounts.

Select the desired option or sub-menu.

# My Images

My Images lets you choose the pictures that appear in your phone's display while in standby mode (wallpaper) and as picture IDs for your contacts.

1. From the Multimedia menu, select My Images.

If there are no pictures stored in your phone or on a memory card, "No Image" appears in the My Images screen. [To launch the camera to take a picture, press the Camera soft key. (For more information, refer to "Camera" on page 60.)1

If there are pictures stored in your phone or on a memory card, up to four thumbnail images of your pictures appear in the display.

Tip: You can also access My Images from:

-The Camera screen, by pressing the My Images soft key.

-The Edit Contact screen, by selecting the picture ID field and pressing the Set soft kev.

Use the Navigation key to highlight a picture.

To expand the selected picture to fill the screen, press 💮.



- Press the **Options** (right) soft key ( ). A pop-up menu containing the following options appears in the display:
  - **Send** Lets you send the selected image to a specified recipient in a Picture message.
  - Set As Lets you assign the selected picture as the Main Wallpaper or as the Picture ID for a Contact.
  - Slide Show Shows the available images as a sequence of fullscreen pictures.
  - **Rename** Lets you rename the picture.
  - Move Lets you move the picture from the phone to the memory card or from the memory card to the phone.
  - Lock / Unlock Lets you protect the picture from being deleted.
  - Erase Files Erases one or more selected, unlocked pictures.

- Picture Info Displays information about the picture, such as the picture Name, creation Date and Time, Resolution, and the data Size
- Send With Bluetooth Lets you send a copy of the picture to another Bluetooth device.
- Select the desired option.
  - To return to the previous menu, press
  - To return to standby mode, press END<sup>®</sup>.



# My Videos

My Videos lets you take videos, review your videos, send them as video messages, and assign your videos as wallpaper on your phone.

- 1. From the Multimedia menu, select My Videos.
  - If there are no videos stored in your phone or on a memory card. "No Video" appears in the My Videos screen.
  - If there are videos stored in your phone or on a memory card, up to four thumbnail images from your videos appear in the MY VIDEOS screen.
- To take a new video, press the **Video** soft key. The camcorder view finder screen appears in the display. (For more information, refer to "Camcorder Screen" on page 64.)

- 3. To play a video, use the navigation keys to highlight a video, then press PLAY ( ).
- 4. For more My Videos options, press the **Options** soft key. The following options appear in the display:
  - Send Lets you send the selected video to a specified recipient in a Video message.
  - Set As Lets you assign the selected video as the Main Wallpaper.
  - Rename Lets you change the name of the video.
  - Move Lets you move the video from the phone to the memory card or from the memory card to the phone.
  - Lock / Unlock Lets you protect the video from being deleted.
  - Erase Files Erases one or more selected, unlocked videos.
  - Video Info Displays information about the video, such as the video Name, creation Date and Time, Resolution, data Size, and the **Duration**
- 5. Select the desired option.
  - To return to the previous menu, press CLR.
  - To return to standby mode, press END<sup>®</sup>.



# Playing Videos

1. From the Multimedia menu, select My Videos.

Up to four thumbnail images from your videos appear in the Mv Videos screen.

2. Use the Navigation key to highlight a video that you wish to play full size, then press . The media player launches and begins playing the selected video.



#### **Media Player Controls**

- Volume kev:
  - To play video sound louder, press the Volume key Up.
  - To play video sound softer, press the Volume key Down.

# Navigation key:

To pause/resume playing a video, press



Note: With the flip closed, use the Camera key to pause/resume playing a music file.

- To stop playing a video, press the Down navigation key.
- To skip play to an earlier part of this video, press and hold the Left navigation key.
- To skip play to a later part of this video, press and hold the Right navigation key.

- To return to **My Videos** and choose another video to play, press the Up navigation key.

# **Mv Ringtones**

My Ringtones lets you assign ringtones (preloaded and downloaded) for calls, alerts, and as distinctive ringers for Contacts.

1. From the Multimedia menu, select My Ringtones. A list of ringtones appears in the display.

Tip: You can also access My Ringtones from:

- -A Set Alarm screen by selecting the Ringer option, highlighting the second (file name) field, pressing the Left or Right navigation key, and selectinà My Rinatones.
- -The Edit Contact screen by selecting the Ringtone field, pressing the Set soft key, and selecting My Ringtones.
- Use the Navigation key to highlight a particular ringtone.
  - To PLAY the ringtone, press ( ).
  - To show the file name and file type, press the Options soft key.
- 3. Press the Set As soft key to assign the highlighted ringtone. The following options appear in the display:
  - Ringtone Lets you assign the selected ringtone to incoming voice calls

- Contact ID Lets you assign the selected ringtone as the distinctive ringer for a Contact.
- Alert Tone Lets you assign the selected ringtone to All Messages, Text Message, Picture/Video Message, or Voicemail Msg.

Select the desired option.

- 4. When using a downloaded ringtone, press the **Options** soft key and the following options appear in the display:
  - Lock / Unlock Lets you prevent/permit file deletion.
  - Erase Frases the selected file.
  - Rename Lets you rename the selected file.
  - Ringtone Info Displays information about the selected file, such as the file name, the file type, and the data size.

Select the desired option.

5. To return to the previous menu, press . To return to standby mode, press eno.

# My Sounds

My Sounds lets you record voice memos and lets you assign preloaded and downloaded sound files as ringers for calls, alarms, and other alerts.

 From the Multimedia menu, select My Sounds. Record New and a list of sound files appears in the display. Tip: You can also access My Sounds from:

- -A Set Alarm screen by selecting the Ringer option, highlighting the second (file name) field, pressing the Left or Right navigation key, and selecting My Sounds.
- -The **Edit Contact** screen by selecting the **Ringtone** field, pressing the **Set** soft key, and selecting **My Sounds**.

Note: Recorded sound files (voice memos) do not appear in these lists.

- Use the Navigation key to highlight the Record New option, then press pto record a voice memo. (For more information, refer to "Voice Memo" on page 88.)
- Press the Options soft key.
  - For a recorded sound file, a pop-up menu containing the following options appears in the display:
    - Send Lets you send the selected sound file to a specified recipient in a Picture message.
    - Rename Lets you rename the sound file.
    - Lock / Unlock Lets you protect the sound file from being deleted.
    - Frase All Frases all sound files
    - Sound Info Displays information about the sound file, such as the file name, file size, file type, date, and time.
  - For a preloaded sound file, a pop-up menu containing the following options appears in the display:

- Send Lets you send the selected sound file to a specified recipient in a Picture message.
- Set As Lets you assign the selected sound file as the Ringtone or as the Contact ID for a Contact or an Alert Tone for Text, Picture, or Voicemail messages.
- Erase All Erases all sound files.
- Sound Info Displays information about the sound file, such as the file name, file type, and the data size.
- For a downloaded sound file, the following options appear in the display:
  - Send Lets you send the selected sound file to a specified recipient in a Picture message.
  - Set As Lets you assign the selected sound file as the Ringtone or as the Contact ID for a Contact or an Alert Tone for Text, Picture, or Voicemail messages.
  - Rename Lets you rename the sound file.
  - Lock / Unlock Lets you protect the sound file from being deleted.
  - Erase All Frases all sound files.
- Sound Info Displays information about the sound file, such as the file name, file type, and the data size.

Select the desired option.

#### Voice Memo

You can use your phone to record voice memos for later playback.

Note: The maximum length for a single voice memo is 60 seconds.

You can save as many voice memos as will fit in the empty memory capacity.

#### Record a Voice Memo

- From the Multimedia menu, select My Sounds → Record New. The Record New screen appears in the display.
- Press REC (
  ), then start speaking. As it is recording the
  phone displays a countdown timer that shows the seconds
  remaining for the recording.
  - To pause the memo, press the Pause soft key. When a memo is paused, select Resume to continue recording.
- Once you're finished recording, press SAVE (
   —
   —
   ). The
   new recording is saved, and the standby mode screen
   appears in the display.

#### Review Voice Memos

If you've saved any voice memos, you can review them anytime.

1. From the Multimedia menu, select My Sounds. A list of

- sound files appears in the display.
- Use the Navigation key to highlight the voice memo you wish to review
- 3. To play the voice memo, press PLAY ( ).
  - To stop the memo, press **STOP** ( ).
  - To restart playing the memo, press 🖏 again.

When the voice memo finishes playing, the selected voice memo remains highlighted in the list of sound files.

#### Erase One Voice Memo

- From the Multimedia menu, select My Sounds. A list of sound files appears in the display.
- Use the Navigation key to highlight the voice memo you wish to erase
- Press the Erase soft key. "Erase Sound?" appears in the display.
  - To erase the selected voice memo, press the Yes soft key.
  - To return to the list of sound files, press the No soft key.

#### Erase All Voice Memos at One Time

 From the Multimedia menu, select My Sounds. A list of sound files appears in the display.

- 2. Use the Navigation key to highlight a voice memo.
- 3. Press the **Options** soft key. The following options appear in the display:
  - Send Lets you send a copy of this voice memo as part of a
    picture message.
  - Rename Lets you change the name of this voice memo.
  - Lock/Unlock Blocks/permits erasure of this voice memo.
  - Erase all Erases all unlocked sound files that are not preloaded.
  - Sound Info Shows you the Name, Size, Type, Date, and Time for this sound file.
- Select Erase all. "Erase All Sounds?" appears in the display.
  - To erase all unlocked sound files, press the Yes soft key.
  - To return to the list of sound files, press the **No** soft key.

### **Section 12: Tools/Utilities**

This section explains how to use your phone's digital assistant functionality to schedule events, set reminders, create a "to do" list, perform calculations, and more.

### **Tools/Utilities Menu**

Tools is a suite of Personal Information Management (PIM) applications such as a Calendar, To Do List, and Memo Pad that run on your phone. You can use your phone to schedule events, set reminders, create a to do list, perform calculations, and more with the functions provided by this useful feature.

# Opening Tools/Utilities Menu

- In standby mode, press MENU (
  ), then select Tools/
  Utilities. The following sub-menus appear in the display:
  - Bluetooth Lets you access Bluetooth functions.
  - Calendar Lets you view the current, past, or future month in a monthly calendar layout.
  - Memo Pad Lets you store and review useful information.
  - Alarm Clock Lets you set an alarm to go off once, or daily, at a specified time.
  - World Time Lets you view the current time of day or night in another part of the world.

- Calculator Lets you perform calculations, including addition, subtraction, multiplication, and division.
- Stop Watch Lets you view the amount of time.
- Converter Lets you convert currencies (according to the latest rates) and weights, measures, and temperatures from one system or increment to another.
- Tip Calculator Lets you quickly calculate service gratuities with a minimum of key presses.
- 2. Select the desired tool.

The following sections provide detailed descriptions of the tools and how to use their functions.

#### Bluetooth

Bluetooth is a short-range wireless communications technology capable of exchanging information over a distance of about 30 feet without requiring a physical connection.

Unlike infrared, you don't need to line up the devices to beam information with Bluetooth. If the devices are within a range of one another, you can exchange information between them, even if they are located in different rooms.

The Bluetooth wireless technology settings menu provides the ability to view and change the device name, show the visibility, and set the security for the device.

#### Turn Bluetooth On/Off

When the Bluetooth is turned on, you can use the Bluetooth features available. When the Bluetooth is turned off, you cannot send or receive information via Bluetooth. To save battery life or in situations where Bluetooth use is prohibited, such as airline traveling, you can turn off the Bluetooth wireless technology headset.

#### Add New Device

To search for available Bluetooth devices:

- From the Tools/Utilities menu, select Bluetooth. The following options appear in the display:
  - Add New Device
  - Registered List
  - · Bluetooth Settings
- 2. Select Add New Device.

If Bluetooth is off, you are prompted to "**Turn bluetooth power on?**".

- Press the Yes soft key to turn Bluetooth on. The black Bluetooth icon ( ) appears in the display. "Place device you are connecting to in discovery mode" also appears in the display.
- Place the Bluetooth device in discoverable mode. (For more information, see the device user manual.)
- Press . "Searching" appears in the display, followed by the names of the available devices appears in the display.
- **6.** Use the Up and Down navigation keys to highlight the device you want to pair with your phone.
- Press PAIR ( ) to pair the selected device with the phone. You are prompted to enter the passkey or PIN for the selected device.

Note: When pairing you phone with another Bluetooth device other than a headset or headphones, the same passkey or PIN must be entered on both devices (when prompted) for the pairing to succeed.

- **8.** Enter the device passkey or PIN and press (3). You are prompted to connect to the paired device.
- 9. Press Yes ( ). "Connecting" followed by the blue Bluetooth icon ( ) appear in the display.

### Registered List

This menu provides a list of Bluetooth wireless technology devices discovered by your handset.

 From the Tools/Utilities menu, select Bluetooth → Registered List.

### **Connecting to a Bluetooth Device**

From the Bluetooth Menu.

- 1. Highlight the desired device and press 💮.
- If you are unable to pair with the device a pop-up appears in the display. To retry, press the **Yes** soft key.

### **Bluetooth Settings**

#### Enable/Disable

Selecting this option turns Bluetooth on or off.

# **Discovery Mode**

Allows other users to see your accessibility. Select **On** for other devices to see your device for 1 minute, or **Off** for no visibility.

#### **Device Name**

Shows the handset name. To change this name enter the desired text and press 🚗 .

### **Supported Profiles**

Lists and explains the Bluetooth profiles your phone supports.

#### **Device Info**

Shows the Bluetooth Type, Status, and Address of your phone.

### Calendar

Calendar lets you view the current, past, or future month in a monthly calendar layout. While viewing the calendar, the current date is highlighted and days with scheduled events are surrounded by a box.

### View an Event

 From the Tools/Utilities menu, select Calendar.

A calendar appears in the display with the current date highlighted. The month and year also appear.

- Press the Add soft key to add an event to the highlighted date.
- Press the key to open the highlighted date.



- 2. Use the following keys to move around within the calendar:
  - Press the Volume key Up (A) to view previous months.
  - Press the Volume key Down ( $\sqrt{r}$ ) to view future months.
  - Use the Navigation key to move to an individual day, one day or one week at a time.
  - Press the **Options** soft key while viewing the calendar. The following options appear in the display:
    - Go to Date Lets you jump to any date you specify.
    - Go to Today Lets you jump to the current date.
    - Erase Old Lets you erase past events.
    - Erase all Lets you erase all events.

Use the Navigation key to highlight the desired option, then press the we key to select the highlighted option and perform the related process.

#### Add a New Event

- 1. From the Tools/Utilities menu, select Calendar.
  - A calendar appears in the display with the current date highlighted. The month and year also appear.
- 2. Use the Navigation key, Volume key, or the **Go to Date** option to highlight the date of the new event.
- Press the Add soft key. The New Event screen appears in the display.

- Enter a name for the event. (For more information, refer to "Entering Text" on page 30.)
- Use the Up and Down navigation keys to highlight the Start and End dates and times fields.
- 6. Enter the Start and End dates and times for the event using the keypad. Enter the dates and times for the event using 2 digits for day, month, hour, and minute entries. Use 4 digits for year entries.
- Use the Left and Right navigation keys to change between
   AM and PM, or press 2 for AM or press 7.
- 8. When you're finished entering the dates and times, use the Up and Down navigation keys to highlight the Alert field. Use the Left and Right navigation keys to select a type of alert.
- Use the Up and Down navigation keys to highlight the Reminder field. Use the Left and Right navigation keys to select the Reminder off or to select a reminder interval.

- 10. Use the Up and Down navigation keys to highlight the Alert Time field. Use the Left and Right navigation keys to select the amount of time before the event occurs that you wish to be notified by an alert.
- 11. Press to store the event in your calendar. If you set a notification alert, an alert will notify you prior to the event.

### View, Edit, and Erase Events

- From the Tools/Utilities menu, select Calendar.
   A calendar appears in the display with the current date highlighted. The month and year also appear.
- Use the Navigation key, Volume key, or the Go to Date option to highlight the date of an event. The number of events for this date appears at the bottom of the Calendar screen.
- 3. Press VIEW (R). A list of events for this date appears.

#### To view details of an event:

- Highlight the desired event, then press VIEW ( ). The
  event details appear in the display.
- Use the Up and Down navigation keys to scroll through the list of event details.

- To view another event for this date, use the Left and Right navigation keys.
- To return to the Calendar, press the Options soft key and select Month View

### To edit details of an event:

- While viewing the event details, press the Edit soft key. The
  Edit Event screen appears in the display with the event
  name highlighted.
- Follow Steps 4 11 of "Add a New Event" on page 93, as needed.

#### To erase an event:

- 10. While viewing the events list for this date, highlight the event you wish to delete.
- 11. If desired, view the event details.
- **12.** Press the **Options** soft key and select **Erase**. You are prompted to confirm the erasure.
  - To retain the event, press the No soft key.
  - To erase the event, press the Yes soft key.

#### Memo Pad

You can create a notes and store them in Memo Pad. Return to Memo Pad anytime you wish to review and edit your notes.

Note: You can't prioritize or set an alert for stored notes.

#### Add a Memo

- From the Tools/Utilities menu, select Memo Pad.
- If you have any stored memos, they appear as a list in the display. If this is your first time in Memo Pad, "No Memos" appears in the display. Press the Add soft key to add a new memo.
- Enter a memo using the keypad. (For more information, refer to "Entering Text" on page 30.)
- When you're finished entering details for the memo, pressThe memo is saved.

# View, Edit, and Erase Memos

- 1. From the Tools/Utilities menu, select Memo Pad.
- 2. Use the Navigation key to highlight a memo.
- 3. To view the memo, press VIEW ( ).

- To edit the memo you are viewing, press the Edit soft key or press the Options soft key, then select Edit.
  - Edit the memo using the keypad. (For more information, refer to "Entering Text" on page 30.)
- To erase the memo you are viewing, press the **Options** soft key, then select **Erase**. You are prompted to verify the erasure
  - To keep the memo, press the No soft key.
  - To erase the memo, press the Yes soft key.

#### Alarm Clock

Your phone has an alarm clock that can be set to go off once, or daily at a specified time. Once set, the alarm clock is easy to change or turn off completely.

Note: The alarm doesn't function when the phone is turned off. If the time for an alarm that was set for Once has elapsed and the phone is off, the alarm occurs at the same time on the following day.

- From the Tools/Utilities menu, select Alarm Clock. The following options appear in the display:
  - Alarm 1
  - Alarm 2
  - Alarm 3

- Select the desire Alarm. A Set Alarm screen appears in the display containing the following options:
  - Alarm Turns the alarm Off or On.
  - Time Use the numeric keys to enter the time, and use the Left and Right navigation keys to select AM or PM



- Frequency Lets you repeat the alarm Daily, Mon Fri, Weekends, or Once.
- Ringer Lets you set the alarm ringer to a Tone or to Vibrate, and lets you select a particular Tone.

Use the Up and Down navigation keys to select options, and use the Left and Right navigation keys to select values for the options.

Use the keypad to enter the time for the alarm.

When you're finished entering the time for the alarm, Press
 The alarm is set and the alarm icon ( ) appears in the top of the display.

#### When an Alarm Sounds

An animated alarm clock appears in the display with the options **Snooze** or **Dismiss**, and an alert sounds when the specified time for the alarm arrives.

- ▶ Use the navigation keys to highlight **Dismiss**, then press
  - to silence the alarm.
  - If the alarm was set as a Daily alarm, the alarm icon remains in the top of the display.
  - If the alarm was set as a Mon.-Fri. alarm, the alarm icon remains in the top of the display.
  - If the alarm was set as a Weekends only alarm, the alarm icon remains in the top of the display.
  - If the alarm was set as a Once only alarm, the alarm icon disappears from the top of the display.

# **Disabling Alarms**

#### **Turn Off the Alarm**

Turning an Alarm to Off allows you to retain the current settings for later reuse.

- From the Tools/Utilities menu, select Alarm Clock. The following options appear in the display:
  - Alarm 1
  - Alarm 2

- Alarm 3
- Use the Up and Down navigation keys to highlight an active Alarm selection.
- Press the Options soft key and select Off.

# Reset the Alarm(s)

- From the Tools/Utilities menu, press 4 for Alarm Clock. The following options appear in the display:
  - Alarm 1
  - Alarm 2
  - Alarm 3
- 2. Use the navigation keys to highlight an active Alarm selection.
- Press the **Options** soft key. The following options pop-up in the display:
  - On / Off Enables/disables the highlighted Alarm using the current settings.
  - Reset Alarm Disables the highlighted Alarm and resets its settings to default values.
  - Reset All Disables all Alarm and resets all of their settings to default values.

 Select Reset Alarm or Reset All. The highlighted Alarm or all Alarms are reset to Off.

### **World Time**

World Time lets you view the time of day or night in another part of the world. World Time displays time in any of 45 different cities and/or time zones around the world.

- From the Tools/Utilities
  menu, select World Time. A
  world map appears in the
  display.
- Use the Left and Right navigation keys to display the time zone and city that you wish to view.



The following time zones/cities are supported:

EST/EDT: Detroit Washington D.C New York Montreal Boston	Caracas	Brasilia	Mid Atlantic
Cape Verde	London	Paris	Rome
Berlin	Athens	Helsinki	Jerusalem
Moscow	Baku	Abu Dhabi	Tashkent
Alma-Ata	Bangkok	Jakarta	Hong Kong
Beijing	Seoul	Tokyo	Guam
Sydney	Okhotsk	Wellington	Samoa
Midway	HAST/HADT:	AKST/AKDT:	PST/PDT:
	Honolulu Hawaii	Alaska	Seattle San Francisco Los Angeles

MST/MDT:	CST/CDT:
Denver Arizona	Dallas Chicago Houston Mexico City

- Press the Options soft key select to display (DST On) or not display (DST Off) Daylight Savings Time (DST) for the selected time zone.
- **4.** Do one of the following:
  - Press to set the selected time zone as the home time zone for your phone.
  - Press to return to the **Tools/Utilities** menu.

# Calculator

You can perform calculations, including addition, subtraction, multiplication, and division using your phone.

- From the Tools/Utilities
  menu, select Calculator. The
  Calculator appears in the
  display.
- Enter the first number in your equation using the keypad (numbers can be up to nine digits long).



- Press to enter a decimal point. (Calculator only accepts 3 digits after a decimal point.)
- Press to change the sign for a number to a negative.
- Use the navigation keys to set the type of calculation that you wish to perform. Your choices are as follows:
  - **Up** navigation key [x] Multiplication
  - **Left** navigation key [-] Subtraction
  - **OK** key [=] Equals/Total
  - Right navigation key [+] Addition
  - **Down** navigation key [+] Division
- Use the keypad to enter the second number into your equation.

For additional equation entry options, press the **Operator** soft key. The following options appear in the display:

- ( Beginning of nested equation
- ) End of nested equation
- Power Raise the entered number to a power
- Press to perform the calculation and view the result.
   To perform another calculation, press the Clear soft key.

# **Stop Watch**

You can use this menu to set a stop watch.

- From the Tools/Utilities menu, select Stop Watch.
- Press to start, stop, and resume the stopwatch count.
- Press the Record soft key at the start of each succeeding event/lap to record the completion time for the previous event/lap.



Press the Reset soft key to erase all stop watch (lap) times recorded.

### Converter

The conversion menu provides the following conversion categories:

- Currency
- Length
- Weight
- Volume
- Area
- Temperature

To convert a currency, length, weight, volume, area, or temperature, do the following:

- From the Tools/Utilities menu. select Converter.
- Select the conversion feature you wish to use.
- Use the Navigation key to select the units to be converted From and To.

\* 12

Converter

Temperature

°C

°F

Ratt

30

To

**\***|-

86,00

土 #

Cance


Enter the quantity you want converted in the From field. The converted quantity appears in the **To** field.

Note: To include a decimal point, press .....

# Currency — Reviewing/Editing Exchange Rates

The Currency Converter includes long-term average exchange rates as default values. To review and/or change a default exchange rate to the current exchange rate, do the following:

- From the Tools/Utilities menu. select Converter → Currency.
- Press the Rate soft key. The Exchange Rate list appears in the display.





- To change a exchange rate, press **EDIT** ( ).
- Use the Up and Down navigation keys to highlight the Exchange Rate to be reviewed/changed.
- Change the current exchange rate, as needed, (For more information, refer to "Entering Numbers" on page 32.)
- Press m to save the changed exchange rate.
- Press to return to the Currency Converter screen.

# Currency — Adding Exchange Rates

You can use the Currency Converter to convert from and to obscure currencies by adding exchange rates for these currencies. To add a currency and its exchange rate to the Currency Converter, do the following:

- From the Tools/Utilities
  menu, select Converter → Currency.
- Press the Rate soft key. The Exchange Rate list for the From currency appears in the display.
- Press the Add soft key. The Add Exchange Rate screen appears in the display with the Base field highlighted.
- Use the Left and Right navigation keys to select the Base currency to be converted from.



Exchange Rate

1 USD

2.34

1.16

1.31

8.07

6,29

AUD

BRI

CAD

CHF

CNY

DKK

Add

- Press the Down navigation key to highlight the Currency field
- Enter an identifier of up to 5 characters for the new currency using the keypad. (For more information, refer to "Entering Text" on page 30.)
- Press the Down navigation key to highlight the Exchange Rate field.
- Enter a decimal exchange rate for the new currency using the keypad.

Note: Press to enter the decimal point.

The  ${\bf Exchange}\ {\bf Rate}$  field only accepts two digits after the decimal point.


**9.** Press to save the new exchange rate.

# Currency — Erasing Exchange Rates

You cannot erase the preloaded currencies from the Exchange Rate list. You can erase a currency that you have added to the list by doing the following:

 From the Tools/Utilities menu, select Converter → Currency.

- Press the Rate soft key. The Exchange Rate list for the From currency appears in the display.
- Use the Up and Down
   navigation keys to highlight
   the currency exchange rate to
   be erased





 Press the Yes soft key to erase the selected exchange rate or press the No soft key to return to the Exchange Rate list.

# **Tip Calculator**

Tip Calculator automatically calculates the following amounts:

- Gratuity (tip)
- Individual payment (for groups)

Calculations are based on the total amount of the check, a selected percentage, and the number of people paying.

- From the Tools/Utilities
  menu, select Tip Calculator.
  The Tip Calculator screen
  appears in the display with the
  Bill field highlighted.
- Use the keypad to enter the total amount of the bill.

Rad ₩⊠				
Tip C	Tip Calculator			
Bill	\$	108.56		
Tip	[	18 %		
# Paying	[	4		
Tip	\$	19.54		
Total	\$	128.10		
Each	\$	32.03		
<del>*</del>   •				
		Cancel		

- 3. If needed, press the Down navigation key to highlight the **Tip** field.
- 4. Use the keypad to enter a tip percentage.
- If needed, press the Down navigation key to highlight the # Paying field.
- **6.** Use the keypad to enter the number of persons paying.
- The amount of the Tip, the bill Total, and the amount Each person should pay appear in the lower half of the screen.

### **Section 13: Voice SVC**

This section explains how to use your phone's digital assistant functionality to schedule events, set reminders, create a "to do" list, perform calculations, and more.

# **Launching Voice SVC**

VoiceSignal is state-of-the-art voice recognition software for your mobile phone that lets you dial numbers, lookup contact information, and open applications using your voice. To access your phone's voice settings, do the following:

- In standby mode, press MENU ( ), then select Voice SVC. The following options appear in the display:
  - Voice Commands—Lets you place calls, access your Contacts
    List, review your appointments, and more by speaking commands
    into your phone. Also see "Making a Call Voice Dialing" on
    page 20 and "Voice Method" on page 37 for more information.
  - Voice Settings—Lets you customize VoiceSignal to better respond to your voice and your phone use preferences.
- 2. Use the Up and down navigation keys to highlight the desired sub-menu, then press .

### **Voice Commands**

To start VoiceSignal, do one of the following:

• In standby mode, press the key.

- From the Voice SVC menu, select Voice Commands.
- "Say a Command" appears in the display and plays through the earpiece, followed by a list of available commands.

**Note:** You can also set your phone to start VoiceSignal when you open the phone. For more information, refer to "Voice Launch" on page 106.

VoiceSignal includes the following commands:

- Call Lets you dial the phone by saying any name stored in your
  contact list, without ever having to record, or "train" that name.
   VoiceSignal automatically voice-activates all your contacts, even if you
  have hundreds of them stored on your phone. You can also dial any
  telephone number, even if it is not stored in your contact list, by saying
  the digits in the number. (For more information, refer to "Making a
  Call Voice Dialing" on page 20.)
- Send Text Lets you launch the Create Text Msg screen. (For more information, refer to "Creating and Sending a Text Message" on page 46.)
- Send Picture Lets you launch the Create Pic Msg screen. (For more information, refer to "Creating and Sending a Picture Message" on page 47.)

- Lookup Lets you look up and display contact information for any name stored in your Contacts list by saying the name. ("Finding a Contacts Entry" on page 37.)
- Go to Lets you access the Voice Memo, Calendar, and Contacts List features of your phone. (For more information, refer to "Voice Memo" on page 88, "Calendar" on page 92, and "Your Contacts List" on page 34.)
- Check Lets you check your phone's status (that is, network coverage, signal strength, and battery in the same report), network coverage, signal strength, battery, and phone number.

Note: Speaking clearly, say the command that you want to use. If, after a few seconds, the device has not recognized a command, it prompts you to repeat the command. If, after a few more seconds, it still has not recognized a command, it tells you "Sorry, no match found," and cancels voice recognition.

#### **Voice Command Tips:**

- . Make sure you wait for the beep before speaking.
- Speak clearly at a normal volume, as if you were talking on the phone.

### **Voice-Activating Your Contacts List**

When you first start VoiceSignal, it reads your Contacts list and voice-activates all the names stored there. When you have add or change contacts, VoiceSignal automatically reloads and voice-activates the entire list

# **Ending Calls Before Restarting the VoiceSignal Software**

When you use VoiceSignal to make a call, you must end that call before you can use VoiceSignal again.

# **Voice Settings**

#### Choice Lists

VoiceSignal uses choice lists when it is not confident it has correctly recognized a name or number. In this case, it can display a list of up to three possible choices, and prompt you to confirm the correct one.

You can change the way that VoiceSignal uses choice lists with name dialing, digit dialing, and contacts. For each feature, you can choose to always see a choice list (even if there is only one choice), or never see a choice list (even if there are multiple choices). If you leave the setting at "Automatic," VoiceSignal displays a choice list only when it is not confident it has correctly recognized the name or number.

To change the way VoiceSignal uses choice lists:

- From the Voice SVC menu, select Voice Settings →
   Choice Lists the following options appear in the display:
  - Automatic

    VoiceSignal displays a choice list only when it is not sure if it has correctly recognized the name or number.
  - Always On—VoiceSignal always displays a choice list, even when there is only one choice.

- Always Off-VoiceSignal never displays a choice list.
- 2. Select the preferred setting.

### Sensitivity

- From the Voice SVC menu, select Voice Settings →
   Sensitivity. The Sensitivity screen appears in the display.
- Use the Up and Down navigation keys to adjust the Sensitivity setting to Reject More spoken commands or names or to Reject Less spoken commands or names.
- Press to accept the new setting.

# **Digit Dialing**

If you regularly have trouble with VoiceSignal not recognize the numbers you say, try adapting digit dialing to your voice. Adapting can improve the accuracy of digit recognition, especially for people with strong regional accents.

Note: After you adapt Digit Dial, your phone is customized to your voice, and your voice only. Others will not be able to use it unless they reset the phone to factory defaults.

Adaptation involves recording several sequences of four digits each. The recording process takes about a minute.

### **Tips for Adapting Digit Dialing**

• Use Adapt Digits in a guiet place.

- Make sure you wait for the beep before starting to speak.
- Speak clearly, and say each digit distinctly.
- If you make a mistake while recording a sequence of digits, or if there is an unexpected noise that spoils the recording, re-record that sequence.
- Only adapt digits if you are regularly having problems with digit dialing.
   Once you adapt, digit dialing will not work as well for other people using your phone. (You can always reset digit adaptation to its original state, as described below.)

### **Adapt Digits**

To adapt digit dialing, do the following:

- From the Voice SVC menu, select Voice Settings → Digit
   Dialing → Adapt Digits. Your phone displays the first digit
   sequence and "Please say" plays through the speaker.
- 2. Wait for the beep and say the digits using your normal tone of voice. After a moment, the phone plays back the recording and prompts "Did the recording sound ok?"
  - If the recording was good, say "Yes."
  - If you need to re-record, say "No."

If you say "**No**," the phone prompts you to pronounce the digits again. Wait for the beep and then say the digits.

Repeat this step until you're satisfied with the recording.

- After confirming that the recording sounds "ok", continue the recording process with the next set of digits.
- After six sets of digits, the phone asks whether you want to do more adaptation. Answer "Yes."
- Repeat steps 4 and 5 for another six sets of digits. After the second group of six sets of digits, "Adaptation complete" plays through the speaker and you are returned to the Adapt Digits menu.

#### **Reset Digits**

To reset digit dialing to factory default settings, do the following:

- From the Voice SVC menu, select Voice Settings → Digit
   Dialing → Reset Digits. The phone prompts you to
   confirm digit adaptation rest.
- To reset your digit adaptation, press the **OK** soft key. To cancel and retain your digit adaptation, press the **Back** soft key.
- 3. Press em to save and exit.

#### Sound

Sound lets you specify what (if any) text prompts you want your phone to read to you through the earpiece.

- From the Voice SVC menu, select Voice Settings → Sound. The following options appear in the display:
  - Prompts Enables or disables audio prompts.
  - Digits Enables or disables audio digit playback.
  - Names Enables or disables audio name playback.
  - Name Settings Lets you adjust the Speed and Volume of your phone's audio name playback.
- Select or adjust to the desired setting.

#### Voice Launch

To set the key or action that launches VoiceSignal, do the following:

- From the Voice SVC menu, select Voice Settings → Voice Launch. The following options appear in the display:
  - Key Only Press and hold 
     Meta to activate VoiceSignal for one call.
  - Key / EarMic Attach a headset to your phone. Press and hold
     Ill to activate VoiceSignal. Now, you can make and end calls
     using VoiceSignal by pushing the button on the headset. Press
     to release VoiceSignal.
  - Key / Flip Press the Me key to activate VoiceSignal for repeated calls. Open and close the flip to make and end calls using VoiceSignal. Press of to release VoiceSignal.
- 2. Select the desired setting.

# About VoiceSignal

This option causes the **About VoiceSignal** screen to appear in the display, showing version and build information about the VoiceSignal software included on your phone.

From the Voice SVC menu, select Voice Settings → About.

The **About VoiceSignal** screen appears in the display showing the version level of the VoiceSignal software currently installed on your phone.

# **Section 14: Changing Your Settings**

This section explains how to customize your phone to suit your needs and preferences.

# **Accessing Your Settings**

- To access your phone's settings from standby mode, do one of the following:
  - Press the Settings soft key.
  - Press MENU ( ), then select Settings.

The **Settings** menu appears in the display.

#### Location

This function identifies your location to the network via the Global Positioning System (GPS). You can set this function for continuous operation or to operate only in the event that you dial 911.

Note: Contact your Wireless Provider to determine whether, when, or where location-based services are available.

At the Settings menu, select Location.

The following options appear in the display:

 Location on — GPS location setting is on whenever you make or receive a call, wherever the feature is available.

- 911 Only GPS location setting is on only when you dial 911.
- Select the preferred setting. You're returned to the Settings menu.

# **Display Settings**

Using the **Display** menu, you can set the menu style, set the standby mode animation, customize the backlight settings, and more.

- At the Settings menu, select Display Settings. The following options appear in the display:
  - Menu Style Lets you choose whether the Main Menu appears as a matrix of icons or as a list of menus.
  - Wallpaper Lets you choose the picture(s) that display(s) on your phone when in standby mode.
  - Clock Format Lets you choose whether to show the time in the display in digital or analog format.
  - **Theme** Lets you select the main menu color scheme.
  - Dialing Font Lets you choose how the number will display on the display screen.
  - Banner Lets you create your own personalized greeting that appears in the display when your phone is in standby mode.

- Backlight Lets you set backlight options for the LCDs, keypad, and set the brightness.
- Front Contrast Lets you set contrast level for the Front (Sub) LCD.
- Use the Up and Down navigation keys to highlight a submenu.
- Press to enter the highlighted sub-menu. The following sections describe the above listed display submenus in greater detail.

# Menu Style

Menu Style allows you to choose how main menus appear in your display.

- At the Settings menu, select Display Settings → Menu Style. The following options appear in the display:
  - Icon Display main menus as icons.
  - List Display main menus in a list format.
- Select the preferred setting. You're returned to the Display Settings menu.

# Wallpaper

Wallpaper lets you choose the pictures that appear in your phone's display while in standby mode.

- At the Settings menu, select Display Settings → Wallpaper. The following options appear in the display:
  - My Images Choose a picture to appear in the display when the phone is in standby mode.
  - My Videos Choose a video to appear in the display when the phone is in standby mode.
  - **Preset Images** Choose a preset image to appear in the display when the phone is in standby mode.
- Select the desired sub-menu. Up to four pictures, images, or videos appear in the display.
- Use the Navigation key to highlight a picture, image, or video.
- Press the View soft key to expand/contract the highlighted picture, image, or video.
- Press to set the highlighted picture, image, or video to display when the phone is in standby mode. You're returned to the Wallpaper menu.

#### **Clock Format**


Clock Format lets you choose whether to show the time in the display in digital or analog format.

- At the Settings menu, select Display Settings → Clock Format. The following options appear in the display:
  - Digital Large numerical time and date display
  - Analog 12-hour clock face with moving hour and minute hands
  - Off Default small digital time and date display
- Select the preferred setting. You're returned to the Display Settings menu.

#### Theme

Theme lets you select the color scheme your phone uses to highlight menu items and scroll bar positions.

At the Settings menu, select Display Settings → Theme.
 The following options appear in the display:



Select the preferred Theme. You're returned to the Display Settings menu.

#### **Dialing Font**

Dialing Font adjusts the color of display.

- At the Settings menu, select Display Settings → Dialing Font. The following options appear in the display:
  - Style Sets font (Normal, Quill Pen, Sticky, or Color Dial) used to show dialed numbers.
  - Size Sets size (Normal or Large) of the Style font used to show dialed numbers.
- 2. Select the preferred setting. You're returned to the **Dialing**Font menu.

#### Banner

Create your own personalized text greeting that appears in the display while your phone is in standby mode.

At the Settings menu, select Display Settings → Banner.
 The Banner text entry screen appears in the display.

Note: If necessary, press and hold to erase an existing banner.

- Enter a word or short phrase (up to 12 characters) to appear in your phone's display while in standby mode. (For more information, refer to "Entering Text" on page 30.)
- 3. Press m to save the new banner.

#### **Backlight**

You can set the backlight for your display or keypad to remain on or off or to remain on for a specified period of time.

Note: Prolonged backlight use drains your battery faster.

- At the Settings menu, select Display Settings → Backlight. The following sub-menus appear in the display:
  - Main Display Sets the amount of time the main display backlight remains on with the phone idle. Optional settings are 7, 15, and 30 Seconds and Always On (this setting uses much more power than the timed settings) and Always Off.
  - Keypad Sets the amount of time the main display backlight remains on with the phone idle. Optional settings are 7, 15, and 30 Seconds and Always On (this setting uses much more power than the timed settings) and Always Off.
  - Brightness Use the Left and Right soft keys to select between any of 5 optional settings.
  - Sub LCD Use the Up and Down navigation keys to select the foreground color for the Sub (Front) LCD) between any of 8 optional settings.
- Select a sub-menu and setting. You're returned to the Backlight menu.

#### Front Contrast

Set the Front (Sub) LCD contrast to your preference.

- At the Settings menu, select Display Settings → Front Contrast. The Front Contrast screen appears in the display.
- Use the Left and Right navigation keys to adjust the contrast for the Front Display. The results of your adjustments appear in the display.
- **3.** Press to save your new contrast setting.

# Sounds Settings

The **Sounds Settings** menu provides a variety of options to customize audio properties for such things as ringers, keypad tones alerts, and more.

#### Volume

Use the **Volume** sub-menu to set the default volume for incoming calls and alarms, or set the phone to vibrate.

- At the Settings menu, select Sound Settings → Volume.
   The following options appear in the display:
  - Voice Calls Lets you set the volume and/or vibration for the incoming calls ringer.

- Messages Lets you set the volume and/or vibration for the incoming messages ringer.
- Alarms Lets you set the volume and/or vibration for the alarm ringer.
- 2. Select an option.
- Use the Up and Down volume keys on the left side of the phone (or the Navigation key) to show the desired Volume level (or vibrate mode) for the selected setting.
- 4. Press to save the setting.

# Ringer Type

You can assign ringer types and melody tones for calls, alarms, and other alerts, in the Ringer Type sub-menu.

- At the Settings menu, select Sound Settings → Ringer Type. The following options appear in the display:
  - Voice Calls Lets you set which ringtone, sound file, and/or one of a set of ringtones and/or sound files plays when you receive a wrice call.
  - Messages Lets you set which ringtone or sound file plays when you receive a Text Message, Picture/Video Message, and/or Voicemail message.
  - Roam Ringer Lets you set which ringtone or sound file plays when you receive calls outside your home area.

- 2. Select the desired sub-menu.
  - For Voice Calls and Roam Ringer, the following options appear in the display:
    - My Ringtones
    - My Sounds
  - For **Messages**, the following sub-menus appear in the display:
    - Text Message
    - Picture/Video Message
    - Voicemail

Each of these sub-menus offer **My Ringtones** and **My Sounds** options.

Select an option, or a sub-menu and an option, then Select a ringer.

#### **Alerts**

You can set your phone to sound an alert whenever you enter or leave your service area, connect or disconnect a call, as well as other options.

- At the Settings menu, select Sound Settings → Alerts.
   The following Alerts sub-menus appear in the display:
  - Minute Beep Sounds an alert ten seconds before each elapsed minute of a call.
  - Roaming Sounds an alert when you leave your home service area.

- Call Connect When you make a call, an alert sounds when the call is answered.
- Power On/Off Plays a melody when you turn the phone on or off.
- Charge Alert Plays a melody when you connect the Travel Adapter and when the battery is fully recharged.
- 2. Select an option, then select **On** or **Off**.

# Key Tone

Key Tone lets you adjust the volume level and length of tone that the keypad generates each time you press a key.

- At the Settings menu, select Sound Settings → Key
   Tone. The following options appear in the display:
  - Tone Level (volume)
  - Tone Length

Tone Level is highlighted.

- Press m to adjust the Key Tone volume.
  - Use the volume keys or Navigation key to set the keypad tones volume.
  - Press 
     when the desired key beep volume setting is reached.
     You are returned to the **Key Tone** sub-menu.
- Use the Up and Down navigation keys to highlight Tone Length, then press the key.

 Select Short or Long. You are returned to the Key Tone submenu.

## **Call Settings**

You can use Call Settings to select how your phone handles calls, both voice and data calls.

#### Call Answer

You can select a specific answer mode when you receive an incoming call.

- At the Settings menu, select Call Settings → Call
   Answer. The Call Answer sub-menu with the following options appears in the display:
  - Any Key Press any key except, , the soft keys ( ), or the Volume key to answer an incoming call.
  - Send Key Press to answer an incoming call.
  - Flip Open Open the flip or press to answer an incoming call.

Tip: You can set your phone to answer calls automatically, without any input from you. (See "Auto Answer" on page 114. for more information.)

Select the method you wish to use for answering calls. You're returned to the Call Settings menu.

#### **Auto Answer**

Auto Answer enables your phone to automatically answer calls after a period of time that you specify.

Note: Auto Answer requires that you connect a wired headset or an optional Bluetooth headset or Handsfree Car Kit to your phone.

- At the Settings menu, select Call Settings → Auto
   Answer. The following options appear in the display:
  - Off Disables automatic answering of calls
  - After 1 Second Phone automatically answers calls after 1 second
  - After 3 Seconds Phone automatically answers calls after 3 seconds
  - After 5 Seconds Phone automatically answers calls after 5 seconds
- Select the desired setting. You're returned to the Call Settings menu.

#### **Auto Retry**

Auto Retry automatically re-dials a number if the connection fails. Depending upon your location, the number of times your phone automatically dials the number may vary.

At the Settings menu, select Call Settings → Auto Retry.

The **Auto Retry** sub-menu with the following options appears in the display:

- Off Disables automatic re-dialing of numbers
- Every 10 Seconds Phone automatically re-dials a number every 10 seconds
- Every 30 Seconds Phone automatically re-dials a number every 30 seconds
- Every 60 Seconds Phone automatically re-dials a number every 60 seconds
- Select the desired setting. You're returned to the Call Settings menu.

#### **TTY Mode**

Your phone is fully TTY compatible. TTY equipment is connected to your phone through the headset connector on the left side of the phone. TTY must be enabled before you can use your phone with a TTY device.

At the Settings menu, select Call Settings → TTY Mode.
You are prompted to confirm you want to view/change the
current TTY Mode setting.

Note: Note: The "Enabling TTY may impair headset use and non-TTY accessory performance" message pops up when you select TTY Mode.

- Press the Yes soft key to access the TTY Mode options or press the No soft key to return to the Call Settings submenu.
- If you press the **Yes** soft key, the following options appear in the display:
  - **TTY Full** Enables TTY mode and disables microphone and earpiece.
  - TTY + Talk (VC0) Enables TTY mode and microphone.
  - TTY + Hear (HCO) Enables TTY mode and earpiece.
  - TTY Off Disables TTY mode.
- Select the desired setting. You're returned to the Call Settings menu.

Note: The TTY icon ( ) appears in the top of the display when the phone is in standby mode.

#### Voice Privacy

Voice Privacy when enabled (that is, set to **Enhanced**), turns on advanced voice encryption.

- At the Settings menu, select Call Settings → Voice
   Privacy. The following options appear in the display:
  - Standard Voice privacy is disabled
  - Enhanced Voice privacy is enabled

Select the desired setting. You're returned to the Call Settings menu.

#### **Data Settings**

Use the **Data Settings** menu to configure data connection settings.

- At the Settings menu, select Call Settings → Data Settings.
- 2. The following options appear in the display:
  - Data Off No incoming data calls accepted.
  - Data For Next Call Wait for data call for the next 10 minutes.
  - Data Until Powered Off Data calls only, no voice calls accepted, until you power the phone off and on again.
- Select the desired setting. You're returned to the Call Settings menu.

# **Phone Settings**

# Airplane Mode

When set to **On**, Airplane Mode disables all radio functions of your phone. This prevents you from receiving or making calls (except emergency calls), but allows you to use other features (such as the camera and the Tools) safely in sensitive environments, such as on board an aircraft.

 At the Settings menu, select Phone Settings → Airplane Mode

The following options appear in the display:

- On Disables the radio transmitter and receiver in your phone
- Off Enables the radio transmitter and receiver in your phone
- 2. Select the desired setting. You are prompted to confirm your selection.
- To keep your selected setting, press the Yes soft key. To discard your selected setting, press the No soft key.

# Language

The language option on your phone can change the language of voice prompts, menus, and key-input.

- At the Settings menu, select Phone Settings → Language. The following options appear in the display:
  - English
  - Español
- Select the desired setting. You're returned to the Phone Settings menu.

# Security

Use the Security menu to lock your phone, set up emergency numbers, enable or disable voice privacy, set restrictions, as well as other security options.

#### **Lock Phone**

Locking the phone limits all outgoing calls except calls to 911 emergency and the three user-programmable emergency numbers. You can lock the phone manually during use, or set the phone to lock automatically when it is turned on. With the phone in lock mode, you can answer incoming calls, but you must unlock the phone to place outgoing calls (except to emergency and secret numbers).

At the Settings menu, select Phone Settings → Security.
 You're prompted to enter the lock code.

Note: The default lock code is the last four digits of your telephone number.

- 2. Enter the lock code, then select **Lock Phone**. The following Device Lock Mode options appear in the display:
  - Lock Locks the phone immediately (The phone stays locked until you enter the lock code.)
  - Unlock Unlocks the phone

- On Power Up The phone locks automatically the next time your phone is powered ON (The phone stays locked until you enter the lock code.)
- Select the desired setting. You're returned to the Security sub-menu.

### **Change Lock**

The default lock code for your phone is generally the last four digits of your phone number. It is advisable to change the default lock code to a secret code for security purposes.

At the Settings menu, select Phone Settings → Security.
 You're prompted to enter the lock code.

Note: The default lock code is the last four digits of your telephone number.

- Enter the lock code, then select Change Lock. You're prompted to enter the new lock code.
- Enter the new lock code. You're prompted to re-enter the new lock code for verification.
- Enter the new lock code again. Your changes are stored.

Note: Your phone does not allow you to view the lock code for obvious security reasons. If you change the lock code, be sure to write down or memorize the new code.

#### Emergency #

Your phone provides the option of storing three emergency numbers. Each number can be up to 32 digits in length. All emergency numbers can be manually called at any time, even when your phone is locked or restricted. This can be a useful feature for controlling outgoing calls from your phone.

Note: Emergency number 911 is hard-coded into your phone. You can dial this number any time, even when the phone is locked or restricted. If you call 911 an audible tone is heard and an Emergency prompt appears in the display for the duration of the call.

Important!: Because of various transmission methods, network parameters, and user settings necessary to complete a call from your wireless phone, a connection cannot always be guaranteed. Therefore, emergency calling may not be available on all wireless networks at all times.

**Important!:** DO NOT depend on this phone as a primary method of calling 911 or for any other essential or emergency communications.

Remember to always turn your phone on and check for adequate signal strength before placing a call.

#### Store Emergency Numbers

At the Settings menu, select Phone Settings → Security.
 You're prompted to enter the lock code.

Note: The default lock code is the last four digits of your telephone number.

- 2. Enter the lock code, then select Emergency #.
- 3. Press 1., 2<sub>abc</sub>, or 3<sup>der</sup> to select from the three emergency number entries.
- 4. Enter an emergency number (up to 32 digits in length).
- **5.** Press to save the number that you entered.

#### Call Emergency Numbers in Lock Mode

- In standby mode, enter the emergency number.
- 2. Press send to place the call.

#### **Resetting Your Phone**

Reset Phone returns all setup options to their factory defaults.

At the Settings menu, select Phone Settings → Security.
 You're prompted to enter the lock code.

Note: The default lock code is the last four digits of your telephone number.

Enter the lock code, the select Reset Phone. A prompt appears in the display asking if you wish to restore default settings (except for the Contacts and Voice Dial). To restore default settings, press the Yes soft key. To return to the Security sub-menu, press the No soft key.

#### **Erase All Entries**

Erase memory erases your Contacts. This feature is useful if you want to give your phone to someone else.

At the Settings menu, select Phone Settings → Security.
 You're prompted to enter the lock code.

Note: The default lock code is the last four digits of your telephone number.

Enter the lock code, then select Erase All Entries. You are prompted to enter the lock code a second time.

Note: The default lock code is the last four digits of your telephone number.

- Enter the lock code. You are prompted to confirm erasure of all entries.
- To erase all entries, press the Yes soft key. To return to the Security sub-menu, press the No soft key.

#### Restriction

Restriction lets you restrict the use of your phone for outgoing calls, incoming calls, and calls placed from your Contacts.

At the Settings menu, select Phone Settings → Security.

You're prompted to enter the lock code.

Note: The default lock code is the last four digits of your telephone number.

- 2. Enter the lock code, then select **Restriction**.
- Use the Up and Down navigation keys to highlight Outgoing, Incoming, or Contacts.
- **4.** Press 💮 . The following options appear in the display:
  - On Restrict (block) all selected calls.
  - Off No restriction on selected calls.
- Select On or Off. You're returned to the Restriction submenu.

#### NAM Selection

NAM Selection lets you select NAM (Number Assignment Module) settings for your phone. You can store two NAM settings, which are essentially telephone numbers, for your phone.

- At the Settings menu, select Phone Settings → NAM Selection. The following options appear in the display:
  - **NAM1** Your service contract has one phone line.
  - NAM2 Your service contract has two phone lines.
- Select the desired setting. The phone powers itself off and back on.

#### System Select

The **System Select** menu allows you to select the roaming setting for your phone.

- At the Settings menu, select Phone Settings → System Select. The following roaming options appear in the display:
  - Home only Your phone is available for normal operation only within your designated coverage area.
  - Automatic Your Wireless Provider's Preferred Roaming List (PRL) of networks is used to acquire service. If no preferred networks are found, any digital system is acquired.
- Select the desired roaming setting. You're returned to the Phone Settings sub-menu.

#### Set Time

Use the **Set Time** option to set the current date and time.

Note: In digital service mode, the Set Time feature is disabled. The network adjusts time and date automatically.

- At the Settings menu, select Phone Settings → Set Time.
  - The following options appear in the display:
  - Set Date
  - Set Time

- 2. Select the desired option.
  - For Set Date, the Set Date screen appears in the display.
    - Enter the current date using your keypad.
       The month and day must be entered using two digits each. The year must be entered using all four digits.
    - Press 
       to save your date setting.
  - For **Set Time**, the **Set Time** screen appears in the display.
    - Enter the current time using your keypad.
       The hour and minute must be entered using two digits each and in 12/ 24-hour format.
    - Use the Left and Right navigation keys to select AM, PM, or 24 Hours.
    - Press 
       to save the your time setting.

#### **Quick Search**

Quick Search is an easy way to locate Menu items and Contacts.

- At the Settings menu, select Phone Settings → Quick Search. The following options appear in the display:
  - On Quick Search is enabled.
  - Off Quick Search is disabled.
- Use the Navigation key to highlight the desired Quick Search setting.

#### Searching for a Menu Item

 In standby mode, press the first few numeric keys that correspond to the letters of the Menu item name.

For example, to search for "Inbox" you would enter:



- Press the Down navigation key. The Menu List screen appears in the display with the first menu item matching your entry highlighted.
- 3. Press the Rey key to access the content of the menu item.

Tip: If the menu item you are searching for does not appear in the **Menu List** screen, try expanding your search by pressing the key to delete the last digit of your entry.

# **Searching for a Contact**

 In standby mode, press the first few numeric keys that correspond to the letters of the contacts name. For example, to search for "Sally" you would enter:



- Press the Up navigation key. The Find screen appears in the display with the first contact name matching your entry highlighted.
- 3. Press send to call the contact.

# Shortcut Key

The Navigation keys can be customized to launch any one of numerous applications or functions from standby mode. Use the Shortcut Key sub-menu to choose the application that you wish each of the Navigation keys to launch.

- At the Settings menu, select Phone Settings → Shortcut Key.
- Select Up Key, Right Key, Down Key, or Left Key. The following functions appear in the display, with the current setting highlighted:
  - BREW
  - Browser

- New Text Msg
- New Pic Msg
- Inbox
- Contacts
- Recent Calls
- Voice Command
- · My Images
- · My Ringtones
- My Sounds
- My Videos
- Calendar
- Memo Pad
- Alarm Clock
- World Time
- Calculator
- Stop Watch
- Converter
- Voice Recording
- Camera
- Tip Calculator
- Select the desired function. You're returned to the Shortcut Key sub-menu.

You can now press the changed Navigation key in standby mode to launch the selected function

# **Memory Info**

**Memory Info** lets you quickly and easily review and manage your phone memory usage. To access **Memory Info**, do the following:

- At the Settings menu, select Memory Info. The following options appear in the display:
  - Save Options Lets you specify whether your images and videos will be stored in your phone or on an optional Memory Card.
  - Phone Memory Lets you review your phone's available memory and manage your files stored there.
  - Card Memory Lets you review a removable Memory Card's available memory, manage your files stored there, and format new Memory Cards.

# **Save Options**

Lets you specify where you want your images and videos stored. To access **Save Options**, do the following:

- At the Settings menu, select Memory Info → Save Options. The following file type options appear in the display:
  - Images

#### Videos

- 2. Select the desired file type. The following storage options appear in the display:
  - Phone Memory saves the selected type of files in your phone's memory.
  - Card Memory saves the selected type of files in a removable microSD memory card.
- Select the desired storage location. "Save Options set" appears in the display, and you are returned to the Save Options menu.

# **Phone Memory**

Lets you review your phone's available memory and manage your files stored there.

# **Memory Usage**

**Memory Usage** lets you review your usage of your phone's memory.

- At the Settings menu, select Memory Info → Phone Memory → Memory Usage. The Memory Usage screen appears in the display showing the following information:
  - Total memory usage
  - Available unused memory

- My Images memory usage
- My Videos memory usage
- My Ringtones memory usage
- My Sounds memory usage
- Applications memory usage
- Pic/Video Msg memory usage
- 2. Press em to return to the Phone Memory menu.

# Freeing Memory

**Phone Memory** sub-menus let you list files in your multimedia folders and let you erase or move files as needed to free up memory on your phone for reuse.

- At the Settings menu, select Memory Info → Phone Memory. The Phone Memory screen appears in the display listing the following options:
  - · Memory Usage
  - · My Images
  - My Videos
  - My Ringtones
  - · My Sounds

 Select the desired storage folder (My Images / Videos / Ringtones / Sounds). A list of all files in the related folder appears in the display.

Files are listed by name, and each file entry shows the name and size of each file.

- 3. To erase files, do the following:
  - Press the Options soft key, then select Erase.
  - Highlight a file you want to erase, then press to mark the file for erasure. (Press the Mark All soft key to mark all files for erasure.)
  - Press the **Done** soft key. You are prompted to confirm erasure of the selected file(s).
  - Press the Yes soft key to erase all marked files, or press the No soft key to return to the Erase screen.
- 4. To move files to the Memory Card, do the following:
  - Press the Options soft key, then select Move.
  - Highlight a file you want to move, then press to mark the file for moving. (Press the Mark All soft key to mark all files for moving.)
  - Press the **Done** soft key. You are prompted to confirm moving the selected file(s) to the Memory Card.
  - Press the Yes soft key to move all marked files, or press the No soft key to return to the Move screen.

 Press to return to the My Images / Videos / Ringtones / Sounds sub-menu. Press to return to standby mode.

# Card Memory

**Card Memory** lets you review a removable, microSD Memory Card's available memory, manage your files stored there, and format new microSD Memory Cards.

### **Memory Usage**

**Memory Usage** lets you review your usage of your Memory Card.

- At the Settings menu, select Memory Info → Card Memory → Memory Usage. The Memory Usage screen appears in the display showing the following information:
  - Total memory usage
  - Available unused memory
  - My Images memory usage
  - My Videos memory usage
  - My Music memory usage
- 2. Press 💮 to return to the Card Memory menu.

### Freeing Memory

**Card Memory** sub-menus let you list files in your multimedia folders and let you erase or move files as needed to free up space on your Memory Card for reuse.

- At the Settings menu, select Memory Info → Card Memory. The Card Memory screen appears in the display listing the following options:
  - Memory Usage
  - · My Images
  - My Videos
  - My Music
  - Format Card
- Select the desired storage folder (My Images / Videos / Music). A list of all files in the related folder appears in the display.

Files are listed by name, and each file entry shows the name and size of each file.

- 3. To erase Image and Video files, do the following:
  - Press the Options soft key, then select Erase.
  - Highlight a file you want to erase, then press to mark the file for erasure. (Press the Mark All soft key to mark all files for erasure.)

- Press the **Done** soft key. You are prompted to confirm erasure of the selected file(s).
- Press the Yes soft key to erase all marked files, or press the No soft key to return to the Erase screen.
- 4. To erase Music files, do the following:
  - Press the Erase soft key.
  - Highlight a Music file you want to erase, then press so to mark the file for erasure. (Press the Mark All soft key to mark all Music files for erasure.)
  - Press the **Done** soft key. You are prompted to confirm erasure of the selected file(s).
  - Press the Yes soft key to erase all marked files or press the No soft key to return to the Erase screen.
- 5. To move image and video files to the phone, do the following:
  - Press the Options soft key, then select Move.
  - Highlight a file you want to move, then press to mark the file for moving. (Press the Mark All soft key to mark all files for moving.)
  - Press the **Done** soft key. You are prompted to confirm moving the selected file(s) to the phone.
  - Press the Yes soft key to move all marked files, or press the No soft key to return to the Move screen.
- 6. Press to return to the **My Images / Videos / Music** sub-menu. Press to return to standby mode.

# **Formatting a Memory Card**

Formatting a microSD Memory Card erases any data currently on the card and creates multimedia directories compatible with your phone. To format a Memory Card, do the following:

- At the Settings menu, select Memory Info → Card Memory → Format Card. You are prompted to confirm formatting of the Memory Card.
- Press the Yes soft key to format the Memory Card, or press the No soft key to return to the Card Memory screen.

#### Phone Info

Phone Info options let you identify important information about your phone, such as the hardware and software versions of your phone, the meanings of your phones status icons, and the phone number assigned to your phone.

#### Phone Number

This option causes the Phone Number screen to appear in the display and show the ten-digit number assigned to your phone by your Wireless Provider.

At the Settings menu, select Phone Info → Phone
 Number. The phone number assigned by your Wireless
 Provider appears in the display.

2. Press ( to return to the **Phone Info** menu.

#### **Icon Glossary**

This option causes the ICON GLOSSARY list to appear in the display and show the icons that can appear in the display and the names of the icons.

- At the Settings menu, select Phone Info → Icon
   Glossary. A list of the icons that can appear on the top line
   of the display shows in the display.
- 2. Press 💮 to return to the **Phone Info** menu.

#### Version

You can view both the software and hardware version of your phone using this feature. This feature is helpful if you need to contact Customer Service.

- At the Settings menu, select Phone Info → Version.
   Your phone's hardware and software version information appears in the display.
- 2. Press 💮 to return to the Phone Info menu.

# **Section 15: Health and Safety Information**

This section outlines the safety precautions associated with using your phone. These safety precautions should be followed to safely use your phone.

# Health and Safety Information Exposure to Radio Frequency (RF) Signals Certification Information (SAR)

Your wireless phone is a radio transmitter and receiver. It is designed and manufactured not to exceed the exposure limits for radio frequency (RF) energy set by the Federal Communications Commission (FCC) of the U.S. government.

These FCC exposure limits are derived from the recommendations of two expert organizations, the National Counsel on Radiation Protection and Measurement (NCRP) and the Institute of Electrical and Electronics Engineers (IEEE).

In both cases, the recommendations were developed by scientific and engineering experts drawn from industry, government, and academia after extensive reviews of the scientific literature related to the biological effects of RF energy.

The exposure limit set by the FCC for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate (SAR). The SAR is a measure of the rate of

absorption of RF energy by the human body expressed in units of watts per kilogram (W/kg). The FCC requires wireless phones to comply with a safety limit of 1.6 watts per kilogram (1.6 W/kg).

The FCC exposure limit incorporates a substantial margin of safety to give additional protection to the public and to account for any variations in measurements.

SAR tests are conducted using standard operating positions accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output.

Before a new model phone is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the exposure limit established by the FCC. Tests for each model phone are performed in positions and locations (e.g. at the ear and worn on the body) as required by the FCC.

For body worn operation, this phone has been tested and meets FCC RF exposure guidelines when used with an accessory that

contains no metal and that positions the handset a minimum of 1.5 cm from the body.

Use of other accessories may not ensure compliance with FCC RF exposure guidelines.

The FCC has granted an Equipment Authorization for this mobile phone with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. The maximum SAR values for this model phone as reported to the FCC are:

- Head: 0.721 W/Kg.
- Body-worn: 1.27 W/Kg.

SAR information on this and other model phones can be viewed online at <a href="http://www.fcc.gov/oet/ea">http://www.fcc.gov/oet/ea</a>. To find information that pertains to a particular model phone, this site uses the phone FCC ID number which is usually printed somewhere on the case of the phone.

Sometimes it may be necessary to remove the battery pack to find the number. Once you have the FCC ID number for a particular phone, follow the instructions on the website and it should provide values for typical or maximum SAR for a particular phone. Additional product specific SAR information can also be obtained at <a href="https://www.fcc.gov/cgb/sar">www.fcc.gov/cgb/sar</a>.

# **Samsung Mobile Products and Recycling**

Samsung cares for the environment and encourages its customers to recycle Samsung mobile phones and genuine Samsung accessories.

Go to: http://www.samsung.com/us/consumer/type/ type.do?group=mobilephones&type=mobilephones for more information

# **UL Certified Travel Adapter**

The Travel Adapter for this phone has met applicable UL safety requirements. Please adhere to the following safety instructions per UL guidelines.

FAILURE TO FOLLOW THE INSTRUCTIONS OUTLINED MAY LEAD TO SERIOUS PERSONAL INJURY AND POSSIBLE PROPERTY DAMAGE.

IMPORTANT SAFETY INSTRUCTIONS - SAVE THESE INSTRUCTIONS.

DANGER - TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, CAREFULLY FOLLOW THESE INSTRUCTIONS.

FOR CONNECTION TO A SUPPLY NOT IN NORTH AMERICA, USE AN ATTACHMENT PLUG ADAPTOR OF THE PROPER CONFIGURATION FOR THE POWER OUTLET. THIS POWER UNIT IS INTENDED TO BE CORRECTLY ORIENTATED IN A VERTICAL OR HORIZONTAL OR FLOOR MOLINT POSITION

#### **Consumer Information on Wireless Phones**

The U.S. Food and Drug Administration (FDA) has published a series of Questions and Answers for consumers relating to radio frequency (RF) exposure from wireless phones. The FDA publication includes the following information:

# What kinds of phones are the subject of this update?

The term wireless phone refers here to hand-held wireless phones with built-in antennas, often called "cell," "mobile," or "PCS" phones. These types of wireless phones can expose the user to measurable radio frequency energy (RF) because of the short distance between the phone and the user's head. These RF exposures are limited by Federal Communications Commission safety guidelines that were developed with the advice of FDA and other federal health and safety agencies.

When the phone is located at greater distances from the user, the exposure to RF is drastically lower because a person's RF exposure decreases rapidly with increasing distance from the source. The so-called "cordless phones," which have a base unit connected to the telephone wiring in a house, typically operate at far lower power levels, and thus produce RF exposures well within the FCC's compliance limits.

# Do wireless phones pose a health hazard?

The available scientific evidence does not show that any health problems are associated with using wireless phones. There is no proof, however, that wireless phones are absolutely safe. Wireless phones emit low levels of radio frequency energy (RF) in the microwave range while being used. They also emit very low levels of RF when in the stand-by mode. Whereas high levels of RF can produce health effects (by heating tissue), exposure to low level RF that does not produce heating effects causes no known adverse health effects. Many studies of low level RF exposures have not found any biological effects. Some studies have suggested that some biological effects may occur, but such findings have not been confirmed by additional research. In some cases, other researchers have had difficulty in reproducing those studies, or in determining the reasons for inconsistent results.

# What is FDA's role concerning the safety of wireless phones?

Under the law, FDA does not review the safety of radiationemitting consumer products such as wireless phones before they can be sold, as it does with new drugs or medical devices. However, the agency has authority to take action if wireless phones are shown to emit radio frequency energy (RF) at a level that is hazardous to the user. In such a case, FDA could require the manufacturers of wireless phones to notify users of the health hazard and to repair, replace or recall the phones so that the hazard no longer exists.

Although the existing scientific data do not justify FDA regulatory actions, FDA has urged the wireless phone industry to take a number of steps, including the following:

- Support needed research into possible biological effects of RF of the type emitted by wireless phones;
- Design wireless phones in a way that minimizes any RF exposure to the user that is not necessary for device function; and
- Cooperate in providing users of wireless phones with the best possible information on possible effects of wireless phone use on human health

FDA belongs to an interagency working group of the federal agencies that have responsibility for different aspects of RF safety to ensure coordinated efforts at the federal level. The following agencies belong to this working group:

- · National Institute for Occupational Safety and Health
- Environmental Protection Agency
- Federal Communications Commission
- Occupational Safety and Health Administration
- National Telecommunications and Information Administration

The National Institutes of Health participates in some interagency working group activities, as well.

FDA shares regulatory responsibilities for wireless phones with the Federal Communications Commission (FCC). All phones that are sold in the United States must comply with FCC safety guidelines that limit RF exposure. FCC relies on FDA and other health agencies for safety questions about wireless phones.

FCC also regulates the base stations that the wireless phone networks rely upon. While these base stations operate at higher power than do the wireless phones themselves, the RF exposures that people get from these base stations are typically thousands of times lower than those they can get from wireless phones.

Base stations are thus not the primary subject of the safety questions discussed in this document.

#### What are the results of the research done already?

The research done thus far has produced conflicting results, and many studies have suffered from flaws in their research methods. Animal experiments investigating the effects of radio frequency energy (RF) exposures characteristic of wireless phones have yielded conflicting results that often cannot be repeated in other laboratories. A few animal studies, however, have suggested that low levels of RF could accelerate the development of cancer in laboratory animals. However, many of the studies that showed increased tumor development used animals that had been genetically engineered or treated with

cancer-causing chemicals so as to be pre-disposed to develop cancer in absence of RF exposure. Other studies exposed the animals to RF for up to 22 hours per day. These conditions are not similar to the conditions under which people use wireless phones, so we don't know with certainty what the results of such studies mean for human health.

Three large epidemiology studies have been published since December 2000. Between them, the studies investigated any possible association between the use of wireless phones and primary brain cancer, glioma, meningioma, or acoustic neuroma, tumors of the brain or salivary gland, leukemia, or other cancers. None of the studies demonstrated the existence of any harmful health effects from wireless phones RF exposures.

However, none of the studies can answer questions about longterm exposures, since the average period of phone use in these studies was around three years.

# What research is needed to decide whether RF exposure from wireless phones poses a health risk?

A combination of laboratory studies and epidemiological studies of people actually using wireless phones would provide some of the data that are needed. Lifetime animal exposure studies could be completed in a few years. However, very large numbers of animals would be needed to provide reliable proof of a cancer promoting effect if one exists. Epidemiological studies can

provide data that is directly applicable to human populations, but ten or more years' follow-up may be needed to provide answers about some health effects, such as cancer.

This is because the interval between the time of exposure to a cancer-causing agent and the time tumors develop - if they do - may be many, many years. The interpretation of epidemiological studies is hampered by difficulties in measuring actual RF exposure during day-to-day use of wireless phones. Many factors affect this measurement, such as the angle at which the phone is held, or which model of phone is used.

# What is FDA doing to find out more about the possible health effects of wireless phone RF?

FDA is working with the U.S. National Toxicology Program and with groups of investigators around the world to ensure that high priority animal studies are conducted to address important questions about the effects of exposure to radio frequency energy (RF).

FDA has been a leading participant in the World Health Organization international Electromagnetic Fields (EMF) Project since its inception in 1996. An influential result of this work has been the development of a detailed agenda of research needs that has driven the establishment of new research programs around the world. The Project has also helped develop a series of public information documents on EMF issues.

FDA and Cellular Telecommunications & Internet Association (CTIA) have a formal Cooperative Research and Development Agreement (CRADA) to do research on wireless phone safety. FDA provides the scientific oversight, obtaining input from experts in government, industry, and academic organizations.

CTIA-funded research is conducted through contracts to independent investigators. The initial research will include both laboratory studies and studies of wireless phone users. The CRADA will also include a broad assessment of additional research needs in the context of the latest research developments around the world.

# What steps can I take to reduce my exposure to radio frequency energy from my wireless phone?

If there is a risk from these products - and at this point we do not know that there is - it is probably very small. But if you are concerned about avoiding even potential risks, you can take a few simple steps to minimize your exposure to radio frequency energy (RF). Since time is a key factor in how much exposure a person receives, reducing the amount of time spent using a wireless phone will reduce RF exposure.

 If you must conduct extended conversations by wireless phone every day, you could place more distance between your body and the source of the RF, since the exposure level drops off dramatically with distance.
 For example, you could use a headset and carry the wireless phone away from your body or use a wireless phone connected to a remote antenna

Again, the scientific data do not demonstrate that wireless phones are harmful. But if you are concerned about the RF exposure from these products, you can use measures like those described above to reduce your RF exposure from wireless phone use.

#### What about children using wireless phones?

The scientific evidence does not show a danger to users of wireless phones, including children and teenagers. If you want to take steps to lower exposure to radio frequency energy (RF), the measures described above would apply to children and teenagers using wireless phones. Reducing the time of wireless phone use and increasing the distance between the user and the RF source will reduce RF exposure.

Some groups sponsored by other national governments have advised that children be discouraged from using wireless phones at all. For example, the government in the United Kingdom distributed leaflets containing such a recommendation in December 2000.

They noted that no evidence exists that using a wireless phone causes brain tumors or other ill effects. Their recommendation to limit wireless phone use by children was strictly precautionary; it

was not based on scientific evidence that any health hazard exists

# Do hands-free kits for wireless phones reduce risks from exposure to RF emissions?

Since there are no known risks from exposure to RF emissions from wireless phones, there is no reason to believe that handsfree kits reduce risks. Hands-free kits can be used with wireless phones for convenience and comfort. These systems reduce the absorption of RF energy in the head because the phone, which is the source of the RF emissions, will not be placed against the head. On the other hand, if the phone is mounted against the waist or other part of the body during use, then that part of the body will absorb more RF energy. Wireless phones marketed in the U.S. are required to meet safety requirements regardless of whether they are used against the head or against the body. Either configuration should result in compliance with the safety limit.

# Do wireless phone accessories that claim to shield the head from RF radiation work?

Since there are no known risks from exposure to RF emissions from wireless phones, there is no reason to believe that accessories that claim to shield the head from those emissions reduce risks. Some products that claim to shield the user from RF absorption use special phone cases, while others involve nothing

more than a metallic accessory attached to the phone. Studies have shown that these products generally do not work as advertised. Unlike "hand-free" kits, these so-called "shields" may interfere with proper operation of the phone. The phone may be forced to boost its power to compensate, leading to an increase in RF absorption. In February 2002, the Federal trade Commission (FTC) charged two companies that sold devices that claimed to protect wireless phone users from radiation with making false and unsubstantiated claims.

According to FTC, these defendants lacked a reasonable basis to substantiate their claim.

# What about wireless phone interference with medical equipment?

Radio frequency energy (RF) from wireless phones can interact with some electronic devices. For this reason, FDA helped develop a detailed test method to measure electromagnetic interference (EMI) of implanted cardiac pacemakers and defibrillators from wireless telephones. This test method is now part of a standard sponsored by the Association for the Advancement of Medical instrumentation (AAMI). The final draft, a joint effort by FDA, medical device manufacturers, and many other groups, was completed in late 2000. This standard will allow manufacturers to ensure that cardiac pacemakers and defibrillators are safe from wireless phone EMI. FDA has tested

wireless phones and helped develop a voluntary standard sponsored by the Institute of Electrical and Electronic Engineers (IEEE). This standard specifies test methods and performance requirements for hearing aids and wireless phones so that no interference occurs when a person uses a compatible phone and a compatible hearing aid at the same time. This standard was approved by the IEEE in 2000.

FDA continues to monitor the use of wireless phones for possible interactions with other medical devices. Should harmful interference be found to occur, FDA will conduct testing to assess the interference and work to resolve the problem.

Additional information on the safety of RF exposures from various sources can be obtained from the following organizations (Updated 12/1/2006):

- FCC RF Safety Program: http://www.fcc.gov/oet/rfsafety/
- Environmental Protection Agency (EPA): http://www.epa.gov/radiation/
- Occupational Safety and Health Administration's (OSHA): http://www.osha.gov/SLTC/radiofrequencyradiation/index.html
- National Institute for Occupational Safety and Health (NIOSH): http://www.cdc.gov/niosh/homepage.html
- World Health Organization (WHO): http://www.who.int/peh-emf/

- International Commission on Non-Ionizing Radiation Protection: http://www.icnirp.de
- National Radiation Protection Board (UK): http://www.hpa.org.uk/radiation
- US Food and Drug Administration http://www.fda.gov/cellphones

# **Road Safety**

Your wireless phone gives you the powerful ability to communicate by voice, almost anywhere, anytime. But an important responsibility accompanies the benefits of wireless phones, one that every user must uphold.

When driving a car, driving is your first responsibility. When using your wireless phone behind the wheel of a car, practice good common sense and remember the following tips:

- Get to know your wireless phone and its features, such as speed dial and redial. If available, these features help you to place your call without taking your attention off the road.
- When available, use a hands-free device. If possible, add an additional layer of convenience and safety to your wireless phone with one of the many hands free accessories available today.

- 3. Position your wireless phone within easy reach. Be able to access your wireless phone without removing your eyes from the road. If you get an incoming call at an inconvenient time, let your voice mail answer it for you.
- 4. Let the person you are speaking with know you are driving; if necessary, suspend the call in heavy traffic or hazardous weather conditions. Rain, sleet, snow, ice and even heavy traffic can be hazardous.
- 5. Do not take notes or look up phone numbers while driving. Jotting down a "to do" list or flipping through your address book takes attention away from your primary responsibility, driving safely.
- 6. Dial sensibly and assess the traffic; if possible, place calls when you are not moving or before pulling into traffic. Try to plan calls when your car will be stationary. If you need to make a call while moving, dial only a few numbers, check the road and your mirrors, then continue.

- 7. Do not engage in stressful or emotional conversations that may be distracting. Make people you are talking with aware you are driving and suspend conversations that have the potential to divert your attention from the road.
- Use your wireless phone to call for help. Dial 9-1-1 or other local emergency number in the case of fire, traffic accident or medical emergencies.
- 9. Use your wireless phone to help others in emergencies. If you see an auto accident, crime in progress or other serious emergency where lives are in danger, call 9-1-1 or other local emergency number, as you would want others to do for you.
- 10. Call roadside assistance or a special non-emergency wireless assistance number when necessary. If you see a broken-down vehicle posing no serious hazard, a broken traffic signal, a minor traffic accident where no one appears injured, or a vehicle you know to be stolen, call roadside assistance or other special non-emergency number.

# "The wireless industry reminds you to use your phone safely when driving."

For more information, please call 1-888-901-SAFE, or visit our web-site <a href="https://www.ctia.org">www.ctia.org</a>.

Important!: If you are using a handset other than a standard numeric keypad, please call 1-888-901-7233.

Provided by the Cellular Telecommunications & Internet Association.

# Responsible Listening

Caution!: Avoid potential hearing loss.

Damage to hearing occurs when a person is exposed to loud sounds over time. The risk of hearing loss increases as sound is played louder and for longer durations. Prolonged exposure to loud sounds (including music) is the most common cause of preventable hearing loss. Some scientific research suggests that using portable audio devices, such as portable music players and cellular telephones, at high volume settings for long durations may lead to permanent noise-induced hearing loss. This includes the use of headphones (including headsets, earbuds, and Bluetooth or other wireless devices). Exposure to very loud sound has also been associated in some studies with tinnitus (a ringing in the ear), hypersensitivity to sound and distorted hearing.

Individual susceptibility to noise-induced hearing loss and potential hearing problem varies. Additionally, the amount of sound produced by a portable audio device varies depending on the nature of the sound, the device settings, and the headphones that are used. As a result, there is no single volume setting that is appropriate for everyone or for every combination of sound, settings and equipment.

You should follow some commonsense recommendations when using any portable audio device:

- Set the volume in a quiet environment and select the lowest volume at which you can hear adequately.
- When using headphones, turn the volume down if you cannot hear the people speaking near you or if the person sitting next to you can hear what you are listening to.
- Do not turn the volume up to block out noisy surroundings. If you
  choose to listen to your portable device in a noisy environment, you
  noise-cancelling headphones to block out background environmental
  noise. By blocking background environment noise, noise cancelling
  headphones should allow you to hear the music at lower volumes than
  when using earbuds.
- Limit the amount of time you listen. As the volume increases, less time is required before you hearing could be affected.

- Avoid using headphones after exposure to extremely loud noises, such as rock concerts, that might cause temporary hearing loss. Temporary hearing loss might cause unsafe volumes to sound normal.
- Do not listen at any volume that causes you discomfort. If you
  experience ringing in your ears, hear muffled speech or experience
  any temporary hearing difficulty after listening to your portable audio
  device. discontinue use and consult your doctor.

You can obtain additional information on this subject from the following sources:

#### American Academy of Audiology

11730 Plaza American Drive, Suite 300

Reston, VA 20190

Voice: (800) 222-2336

Email: info@audiology.org

Internet: http://www.audiology.org

#### National Institute on Deafness and Other Communication Disorders

National Institutes of Health

31 Center Drive, MSC 2320

Bethesda, MD 20892-2320

Voice: (301) 496-7243

Email: nidcdinfo@nih.gov

Internet: http://www.cdc.gov/niosh/topics/noise/default.html

#### National Institute for Occupational Safety and Health

Hubert H. Humphrey Bldg.

200 Independence Ave., SW

Washington, DC 20201

Voice: 1-800-35-NIOSH (1-800-356-4647)

Internet: http://www.cdc.gov/niosh/topics/noise/default.html

# **Operating Environment**

Remember to follow any special regulations in force in any area and always switch your phone off whenever it is forbidden to use it, or when it may cause interference or danger.

When connecting the phone or any accessory to another device, read its user's guide for detailed safety instructions. Do not connect incompatible products.

As with other mobile radio transmitting equipment, users are advised that for the satisfactory operation of the equipment and for the safety of personnel, it is recommended that the equipment should only be used in the normal operating position (held to your ear with the antenna pointing over your shoulder if you are using an external antenna).

# Using Your Phone Near Other Electronic Devices

Most modern electronic equipment is shielded from radio frequency (RF) signals. However, certain electronic equipment may not be shielded against the RF signals from your wireless phone. Consult the manufacturer to discuss alternatives.

# Implantable Medical Devices

A minimum separation of six (6) inches should be maintained between a handheld wireless phone and an implantable medical device, such as a pacemaker or implantable cardioverter defibrillator, to avoid potential interference with the device.

Persons who have such devices:

- Should ALWAYS keep the phone more than six (6) inches from their implantable medical device when the phone is turned ON;
- . Should not carry the phone in a breast pocket;
- Should use the ear opposite the implantable medical device to minimize the potential for interference;

- Should turn the phone OFF immediately if there is any reason to suspect that interference is taking place;
- Should read and follow the directions from the manufacturer of your implantable medical device. If you have any questions about using your wireless phone with such a device, consult your health care provider.

For more information see:

http://www.fcc.gov/oet/rfsafety/rf-fags.html

# FCC Hearing-Aid Compatibility (HAC) Regulations for Wireless Devices

On July 10, 2003, the U.S. Federal Communications Commission (FCC) Report and Order in WT Docket 01-309 modified the exception of wireless phones under the Hearing Aid Compatibility Act of 1988 (HAC Act) to require digital wireless phones be compatible with hearing-aids.

The intent of the HAC Act is to ensure reasonable access to telecommunications services for persons with hearing disabilities.

While some wireless phones are used near some hearing devices (hearing aids and cochlear implants), users may detect a buzzing, humming, or whining noise. Some hearing devices are more immune than others to this interference noise, and phones also vary in the amount of interference they generate.

The wireless telephone industry has developed a rating system for wireless phones, to assist hearing device users find phones that may be compatible with their hearing devices. Not all phones have been rated. Phones that are rated have the rating on their box or a label located on the box.

The ratings are not guarantees. Results will vary depending on the user's hearing device and hearing loss. If your hearing device happens to be vulnerable to interference, you may not be able to use a rated phone successfully. Trying out the phone with your hearing device is the best way to evaluate it for your personal needs

**M-Ratings**: Phones rated M3 or M4 meet FCC requirements and are likely to generate less interference to hearing devices than phones that are not labeled. M4 is the better/higher of the two ratings.

**T-Ratings**: Phones rated T3 or T4 meet FCC requirements and are likely to generate less interference to hearing devices than phones that are not labeled. T4 is the better/higher of the two ratings.

Hearing devices may also be rated. Your hearing device manufacturer or hearing health professional may help you find this rating. Higher ratings mean that the hearing device is relatively immune to interference noise. The hearing aid and wireless phone rating values are then added together. A sum of 5

is considered acceptable for normal use. A sum of 6 is considered for best use.



In the above example, if a hearing aid meets the M2 level rating and the wireless phone meets the M3 level rating, the sum of the two values equal M5. This is synonymous for T ratings. This should provide the hearing aid user with "normal usage" while using their hearing aid with the particular wireless phone.

"Normal usage" in this context is defined as a signal quality that is acceptable for normal operation.

The M mark is intended to be synonymous with the U mark. The T mark is intended to be synonymous with the UT mark. The M and T marks are recommended by the Alliance for Telecommunications Industries Solutions (ATIS). The U and UT marks are referenced in Section 20.19 of the FCC Rules.

The HAC rating and measurement procedure are described in the American National Standards Institute (ANSI) C63.19 standard.

#### Other Medical Devices

If you use any other personal medical devices, consult the manufacturer of your device to determine if it is adequately shielded from external RF energy. Your physician may be able to assist you in obtaining this information. Switch your phone off in health care facilities when any regulations posted in these areas instruct you to do so. Hospitals or health care facilities may be using equipment that could be sensitive to external RF energy.

#### **Vehicles**

RF signals may affect improperly installed or inadequately shielded electronic systems in motor vehicles. Check with the manufacturer or its representative regarding your vehicle. You should also consult the manufacturer of any equipment that has been added to your vehicle.

#### Posted Facilities

Switch your phone off in any facility where posted notices require you to do so.

# **Potentially Explosive Environments**

Switch your phone off when in any area with a potentially explosive atmosphere and obey all signs and instructions. Sparks in such areas could cause an explosion or fire resulting in bodily injury or even death.

Users are advised to switch the phone off while at a refueling point (service station). Users are reminded of the need to observe restrictions on the use of radio equipment in fuel depots (fuel storage and distribution areas), chemical plants or where blasting operations are in progress.

Areas with a potentially explosive atmosphere are often but not always clearly marked. They include below deck on boats, chemical transfer or storage facilities, vehicles using liquefied petroleum gas (such as propane or butane), areas where the air contains chemicals or particles, such as grain, dust or metal powders, and any other area where you would normally be advised to turn off your vehicle engine.

# **Emergency Calls**

This phone, like any wireless phone, operates using radio signals, wireless and landline networks as well as user-programmed functions, which cannot guarantee connection in all conditions. Therefore, you should never rely solely on any wireless phone for essential communications (medical emergencies, for example).

Remember, to make or receive any calls the phone must be switched on and in a service area with adequate signal strength. Emergency calls may not be possible on all wireless phone networks or when certain network services and/or phone features are in use. Check with local service providers.

To make an emergency call:

- 1. If the phone is not on, switch it on.
- Key in the emergency number for your present location (for example, 911 or other official emergency number). Emergency numbers vary by location.
- 3. Press the SEND key.

If certain features are in use (call barring, for example), you may first need to deactivate those features before you can make an emergency call. Consult this document and your local cellular service provider.

When making an emergency call, remember to give all the necessary information as accurately as possible. Remember that your phone may be the only means of communication at the scene of an accident; do not cut off the call until given permission to do so.

# Restricting Children's access to your Phone

Your phone is not a toy. Children should not be allowed to play with it because they could hurt themselves and others, damage the phone or make calls that increase your phone bill.

#### **FCC Notice and Cautions**

#### **FCC Notice**

The phone may cause TV or radio interference if used in close proximity to receiving equipment. The FCC can require you to stop using the phone if such interference cannot be eliminated.

Vehicles using liquefied petroleum gas (such as propane or butane) must comply with the National Fire Protection Standard (NFPA-58). For a copy of this standard, contact the National Fire Protection Association, One Batterymarch Park, Quincy, MA 02269. Attn: Publication Sales Division.

#### **Cautions**

Any changes or modifications to your phone not expressly approved in this document could void your warranty for this equipment, and void your authority to operate this equipment. Only use approved batteries, antennas and chargers. The use of any unauthorized accessories may be dangerous and void the phone warranty if said accessories cause damage or a defect to the phone.

Although your phone is quite sturdy, it is a complex piece of equipment and can be broken. Avoid dropping, hitting, bending or sitting on it.

### Other Important Safety Information

- Only qualified personnel should service the phone or install the phone
  in a vehicle. Faulty installation or service may be dangerous and may
  invalidate any warranty applicable to the device.
- Check regularly that all wireless phone equipment in your vehicle is mounted and operating properly.
- Do not store or carry flammable liquids, gases or explosive materials in the same compartment as the phone, its parts or accessories.
- For vehicles equipped with an air bag, remember that an air bag inflates with great force. Do not place objects, including both installed or portable wireless equipment in the area over the air bag or in the air bag deployment area. If wireless equipment is improperly installed and the air bag inflates, serious injury could result.
- Switch your phone off before boarding an aircraft. The use of wireless phone in aircraft is illegal and may be dangerous to the aircraft's operation.
- Failure to observe these instructions may lead to the suspension or denial of telephone services to the offender, or legal action, or both.

#### **Product Performance**

### **Getting the Most Out of Your Signal Reception**

The quality of each call you make or receive depends on the signal strength in your area. Your phone informs you of the current signal strength by displaying a number of bars next to the signal strength icon. The more bars displayed, the stronger the signal.

If you're inside a building, being near a window may give you better reception.

#### **Understanding the Power Save Feature**

If your phone is unable to find a signal after searching, a Power Save feature is automatically activated. If your phone is active, it periodically rechecks service availability or you can check it yourself by pressing any key.

Anytime the Power Save feature is activated, a message displays on the screen. When a signal is found, your phone returns to standby mode.

# **Understanding How Your Phone Operates**

Your phone is basically a radio transmitter and receiver. When it's turned on, it receives and transmits radio frequency (RF) signals. When you use your phone, the system handling your call controls the power level. This power can range from 0.006 watts to 0.2 watts in digital mode.

#### Maintaining Your Phone's Peak Performance

For the best care of your phone, only authorized personnel should service your phone and accessories. Faulty service may void the warranty.

There are several simple guidelines to operating your phone properly and maintaining safe, satisfactory service.

- To ensure that the Hearing Aid Compatibility rating for your phone is maintained, secondary transmitters such as Bluetooth and WLAN components must be disabled during a call. For more information, refer to "Bluetooth" on page 90.
- If your phone is equipped with an external antenna, hold the phone with the antenna raised, fully-extended and over your shoulder.
- Do not hold, bend or twist the phone's antenna, if applicable.
- Do not use the phone if the antenna is damaged.
- If your phone is equipped with an internal antenna, obstructing the internal antenna could inhibit call performance.
- · Speak directly into the phone's receiver.
- Avoid exposing your phone and accessories to rain or liquid spills. If your phone does get wet, immediately turn the power off and remove the battery. If it is inoperable, call Customer Care for service.

## **Availability of Various Features/Ring Tones**

Many services and features are network dependent and may require additional subscription and/or usage charges. Not all features are available for purchase or use in all areas.

Downloadable Ring Tones may be available at an additional cost.

Other conditions and restrictions may apply. See your service provider for additional information.

### **Battery Standby and Talk Time**

Standby and talk times will vary depending on phone usage patterns and conditions. Battery power consumption depends on factors such as network configuration, signal strength, operating temperature, features selected, frequency of calls, and voice, data, and other application usage patterns.

### **Battery Precautions**

- Avoid dropping the cell phone. Dropping it, especially on a hard surface, can potentially cause damage to the phone and battery. If you suspect damage to the phone or battery, take it to a service center for inspection.
- · Never use any charger or battery that is damaged in any way.
- Do not modify or remanufacture the battery as this could result in serious safety hazards.
- If you use the phone near the network's base station, it uses less power; talk and standby time are greatly affected by the signal strength on the cellular network and the parameters set by the network operator.
- Follow battery usage, storage and charging guidelines found in the user's guide.

- Battery charging time depends on the remaining battery charge and the type of battery and charger used. The battery can be charged and discharged hundreds of times, but it will gradually wear out. When the operation time (talk time and standby time) is noticeably shorter than normal, it is time to buy a new battery.
- If left unused, a fully charged battery will discharge itself over time.
- Use only Samsung-approved batteries and recharge your battery only
  with Samsung-approved chargers. When a charger is not in use,
  disconnect it from the power source. Do not leave the battery
  connected to a charger for more than a week, since overcharging may
  shorten its life.
- Do not use incompatible cell phone batteries and chargers. Some Web sites and second-hand dealers, not associated with reputable manufacturers and carriers, might be selling incompatible or even counterfeit batteries and chargers. Consumers should purchase manufacturer or carrier recommended products and accessories. If unsure about whether a replacement battery or charger is compatible, contact the manufacturer of the battery or charger.
- Misuse or use of incompatible phones, batteries, and charging devices could result in damage to the equipment and a possible risk of fire, explosion, leakage, or other serious hazard.
- Extreme temperatures will affect the charging capacity of your battery: it may require cooling or warming first.
- Do not leave the battery in hot or cold places, such as in a car in summer or winter conditions, as you will reduce the capacity and

- lifetime of the battery. Always try to keep the battery at room temperature. A phone with a hot or cold battery may temporarily not work, even when the battery is fully charged. Li-ion batteries are particularly affected by temperatures below 0 °C (32 °F).
- Do not place the phone in areas that may get very hot, such as on or near a cooking surface, cooking appliance, iron, or radiator.
- Do not get your phone or battery wet. Even though they will dry and appear to operate normally, the circuitry could slowly corrode and pose a safety hazard.
- Do not short-circuit the battery. Accidental short-circuiting can occur
  when a metallic object (coin, clip or pen) causes a direct connection
  between the + and terminals of the battery (metal strips on the
  battery), for example when you carry a spare battery in a pocket or
  bag. Short-circuiting the terminals may damage the battery or the
  object causing the short-circuiting.
- Do not permit a battery out of the phone to come in contact with metal objects, such as coins, keys or jewelry.
- Do not crush, puncture or put a high degree of pressure on the battery as this can cause an internal short-circuit, resulting in overheating.
- Dispose of used batteries in accordance with local regulations. In some areas, the disposal of batteries in household or business trash may be prohibited. For safe disposal options for Li-lon batteries, contact your nearest Samsung authorized service center. Always recycle. Do not dispose of batteries in a fire.

#### Care and Maintenance

Your phone is a product of superior design and craftsmanship and should be treated with care. The suggestions below will help you fulfill any warranty obligations and allow you to enjoy this product for many years.

- Keep the phone and all its parts and accessories out of the reach of small children.
- Keep the phone dry. Precipitation, humidity and liquids contain minerals that will corrode electronic circuits.
- Do not use the phone with a wet hand. Doing so may cause an electric shock to you or damage to the phone.
- Do not use or store the phone in dusty, dirty areas, as its moving parts may be damaged.
- Do not store the phone in hot areas. High temperatures can shorten the life of electronic devices, damage batteries, and warp or melt certain plastics.
- Do not store the phone in cold areas. When the phone warms up to its normal operating temperature, moisture can form inside the phone, which may damage the phone's electronic circuit boards.
- Do not drop, knock or shake the phone. Rough handling can break internal circuit boards.
- Do not use harsh chemicals, cleaning solvents or strong detergents to clean the phone. Wipe it with a soft cloth slightly dampened in a mild soap-and-water solution.

- Do not paint the phone. Paint can clog the device's moving parts and prevent proper operation.
- Do not put the phone in or on heating devices, such as a microwave oven, a stove or a radiator. The phone may explode when overheated.
- If your phone is equipped with an external antenna, use only the supplied or an approved replacement antenna. Unauthorized antennas or modified accessories may damage the phone and violate regulations governing radio devices.
- If the phone, battery, charger or any accessory is not working properly, take it to your nearest qualified service facility. The personnel there will assist you, and if necessary, arrange for service.

# **Section 16: Warranty Information**

# **Standard Limited Warranty**

## What is Covered and For How Long?

SAMSUNG TELECOMMUNICATIONS AMERICA, LLC ("SAMSUNG") warrants to the original purchaser ("Purchaser") that SAMSUNG's Phones and accessories ("Products") are free from defects in material and workmanship under normal use and service for the period commencing upon the date of purchase and continuing for the following specified period of time after that date:

Phone 1 Year
Batteries 1 Year
Leather Case 90 Days
Holster 90 Days
Other Phone Accessories 1 Year

What is Not Covered? This Limited Warranty is conditioned upon proper use of Product by Purchaser. This Limited Warranty does not cover: (a) defects or damage resulting from accident, misuse, abuse, neglect, unusual physical, electrical or electromechanical stress, or modification of any part of Product, including antenna, or cosmetic damage; (b) equipment that has the serial number

removed or made illegible; (c) any plastic surfaces or other externally exposed parts that are scratched or damaged due to normal use; (d) malfunctions resulting from the use of Product in conjunction with accessories, products, or ancillary/peripheral equipment not furnished or approved by SAMSUNG; (e) defects or damage from improper testing, operation, maintenance, installation, or adjustment; (f) installation, maintenance, and service of Product, or (g) Product used or purchased outside the United States or Canada.

This Limited Warranty covers batteries only if battery capacity falls below 80% of rated capacity or the battery leaks, and this Limited Warranty does not cover any battery if (i) the battery has been charged by a battery charger not specified or approved by SAMSUNG for charging the battery, (ii) any of the seals on the battery are broken or show evidence of tampering, or (iii) the battery has been used in equipment other than the SAMSUNG phone for which it is specified.

What are SAMSUNG's Obligations? During the applicable warranty period, SAMSUNG will repair or replace, at SAMSUNG's sole option, without charge to Purchaser, any defective component part of Product. To obtain service under this Limited Warranty, Purchaser must return Product to an authorized phone service

facility in an adequate container for shipping, accompanied by Purchaser's sales receipt or comparable substitute proof of sale showing the date of purchase, the serial number of Product and the sellers' name and address. To obtain assistance on where to deliver the Product, call Samsung Customer Care at 1-888-987-4357. Upon receipt, SAMSUNG will promptly repair or replace the defective Product. SAMSUNG may, at SAMSUNG's sole option, use rebuilt, reconditioned, or new parts or components when repairing any Product or replace Product with a rebuilt. reconditioned or new Product. Repaired/replaced leather cases, pouches and holsters will be warranted for a period of ninety (90) days. All other repaired/replaced Product will be warranted for a period equal to the remainder of the original Limited Warranty on the original Product or for 90 days, whichever is longer. All replaced parts, components, boards and equipment shall become the property of SAMSUNG.

If SAMSUNG determines that any Product is not covered by this Limited Warranty, Purchaser must pay all parts, shipping, and labor charges for the repair or return of such Product.

WHAT ARE THE LIMITS ON SAMSUNG'S WARRANTY/LIABILITY?
EXCEPT AS SET FORTH IN THE EXPRESS WARRANTY CONTAINED
HEREIN, PURCHASER TAKES THE PRODUCT "AS IS," AND
SAMSUNG MAKES NO WARRANTY OR REPRESENTATION AND
THERE ARE NO CONDITIONS. EXPRESS OR IMPLIED. STATUTORY

OR OTHERWISE, OF ANY KIND WHATSOEVER WITH RESPECT TO THE PRODUCT, INCLUDING BUT NOT LIMITED TO:

- THE MERCHANTABILITY OF THE PRODUCT OR ITS FITNESS FOR ANY PARTICULAR PURPOSE OR USE;
- WARRANTIES OF TITLE OR NON-INFRINGEMENT;
- DESIGN, CONDITION, QUALITY, OR PERFORMANCE OF THE PRODUCT;
- THE WORKMANSHIP OF THE PRODUCT OR THE COMPONENTS CONTAINED THEREIN; OR
- COMPLIANCE OF THE PRODUCT WITH THE REQUIREMENTS OF ANY LAW, RULE, SPECIFICATION OR CONTRACT PERTAINING THERETO.

NOTHING CONTAINED IN THE INSTRUCTION MANUAL SHALL BE CONSTRUED TO CREATE AN EXPRESS WARRANTY OF ANY KIND WHATSOEVER WITH RESPECT TO THE PRODUCT. ALL IMPLIED WARRANTIES AND CONDITIONS THAT MAY ARISE BY OPERATION OF LAW, INCLUDING IF APPLICABLE THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE HEREBY LIMITED TO THE SAME DURATION OF TIME AS THE EXPRESS WRITTEN WARRANTY STATED HEREIN. SOME STATES/PROVINCES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. IN ADDITION, SAMSUNG SHALL NOT BE LIABLE FOR ANY DAMAGES OF ANY KIND RESULTING FROM THE PURCHASE, USE, OR MISUSE OF, OR INABILITY TO USE THE PRODUCT OR ARISING DIRECTLY OR INDIRECTLY FROM THE USE

OR LOSS OF USE OF THE PRODUCT OR FROM THE BREACH OF THE EXPRESS WARRANTY. INCLUDING INCIDENTAL. SPECIAL. CONSEQUENTIAL OR SIMILAR DAMAGES. OR LOSS OF ANTICIPATED PROFITS OR BENEFITS, OR FOR DAMAGES ARISING FROM ANY TORT (INCLUDING NEGLIGENCE OR GROSS NEGLIGENCE) OR FAULT COMMITTED BY SAMSUNG. ITS AGENTS OR EMPLOYEES, OR FOR ANY BREACH OF CONTRACT OR FOR ANY CLAIM BROUGHT AGAINST PURCHASER BY ANY OTHER PARTY SOME STATES/PROVINCES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES. SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS, WHICH VARY FROM STATE TO STATE/PROVINCE TO PROVINCE. THIS LIMITED WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL PURCHASER OF THIS PRODUCT AND STATES PURCHASER'S EXCLUSIVE REMEDY, IF ANY PORTION OF THIS LIMITED WARRANTY IS HELD ILLEGAL OR LINENFORCEARLE BY REASON OF ANY LAW. SUCH PARTIAL ILLEGALITY OR UNENFORCEABILITY SHALL NOT AFFECT THE ENFORCEABILITY FOR THE REMAINDER OF THIS LIMITED WARRANTY WHICH PURCHASER ACKNOWLEDGES IS AND WILL ALWAYS BE CONSTRUED TO BE LIMITED BY ITS TERMS OR AS LIMITED AS THE LAW PERMITS. THE PARTIES UNDERSTAND THAT THE PURCHASER MAY USE THIRD-PARTY SOFTWARE OR EQUIPMENT

IN CONJUNCTION WITH THE PRODUCT. SAMSUNG MAKES NO WARRANTIES OR REPRESENTATIONS AND THERE ARE NO CONDITIONS, EXPRESS OR IMPLIED, STATUTORY OR OTHERWISE, AS TO THE QUALITY, CAPABILITIES, OPERATIONS, PERFORMANCE OR SUITABILITY OF ANY THIRDPARTY SOFTWARE OR EQUIPMENT, WHETHER SUCH THIRD-PARTY SOFTWARE OR EQUIPMENT IS INCLUDED WITH THE PRODUCT DISTRIBUTED BY SAMSUNG OR OTHERWISE, INCLUDING THE ABILITY TO INTEGRATE ANY SUCH SOFTWARE OR EQUIPMENT WITH THE PRODUCT. THE QUALITY, CAPABILITIES, OPERATIONS, PERFORMANCE AND SUITABILITY OF ANY SUCH THIRD-PARTY SOFTWARE OR EQUIPMENT LIE SOLELY WITH THE PURCHASER AND THE DIRECT VENDOR, OWNER OR SUPPLIER OF SUCH THIRD-PARTY SOFTWARE OR EQUIPMENT, AS THE CASE MAY BE.

This Limited Warranty allocates risk of Product failure between Purchaser and SAMSUNG, and SAMSUNG's Product pricing reflects this allocation of risk and the limitations of liability contained in this Limited Warranty. The agents, employees, distributors, and dealers of SAMSUNG are not authorized to make modifications to this Limited Warranty, or make additional warranties binding on SAMSUNG. Accordingly, additional statements such as dealer advertising or presentation, whether oral or written, do not constitute warranties by SAMSUNG and should not be relied upon.

#### **Precautions for Transfer and Disposal**

If data stored on this device is deleted or reformatted using the standard methods, the data only appears to be removed on a superficial level, and it may be possible for someone to retrieve and reuse the data by means of special software.

To avoid unintended information leaks and other problems of this sort, it is recommended that the device be returned to Samsung's Customer Care Center for an Extended File System (EFS) Clear which will eliminate all user memory and return all settings to default settings. Please contact the Samsung Customer Care Center for details

Important!: Please provide warranty information (proof of purchase) to Samsung's Customer Care Center in order to provide this service at no charge. If the warranty has expired on the device, charges may apply.

**Customer Care Center:** 

1000 Klein Rd.

Plano, TX 75074

Toll Free Tel: 1.888.987.HELP (4357)

Samsung Telecommunications America, LLC:

1301 East Lookout Drive

Richardson, Texas 75082

Phone: 1-800-SAMSUNG (726-7864)

Important!: If you are using a handset other than a standard numeric keypad, dial the numbers listed in brackets.

Phone: 1-888-987-HELP (4357)

©2008 Samsung Telecommunications America. All rights reserved

No reproduction in whole or in part allowed without prior written approval. Specifications and availability subject to change without notice.

# Index

Α	Adjusting the Call Volume 22	Options 65
Airplane Mode 115	Answering a Call 22	Photo Gallery 77
В	Call Log 22	Save Pictures 65
BACK key 13	Making a Call — Number Entry	Screen Icons 63
Backup to last menu 28	Dialing 18	Taking Multi Shot Pictures 61
Bluetooth 90	Making a Call — Speed Dialing 19	Taking Single Pictures 60
Add New Device 91	Call Options	Taking Snap Shots 60
Connecting 92	Auto Retry 114	Zoom 77
Registered List 92	Call Settings 113	Camera Key 13
Settings 92	Auto Answer 114	Camera Options
Turn On/Off 91	Call Answer 113	Resolution 67
Browser	Data Settings 115	Card Memory
How Browser Keys Work 58	TTY Mode 114	Formatting 125
Launching Browser 57	Voice Privacy 115	Freeing 124
Using Browser 57	Camcorder	Usage Info 124
Using Links 58	Options 72	Contacts List 34
C	Screen Icons 64	Open 34
Calendar	Taking Videos 62	Creating and Sending New Messages
Add a New Event 93	Video Gallery 78	Picture (Pic) Message 47
Review, Edit, and Erase Events 94	Camera	Text Message 46
Call Answer mode 15	Brightness 77	Video Message 48
Call Functions	Color Tones 68, 74	D
	Multi Shot 66	Display screen icons 14

Display Setting	Formatting a Memory Card 125	Review, Edit, and Erase Memos 9
Clock Format 109	Formatting a microSD Card 125	Memory Card
Display Settings 108	G	Formatting 125
Backlight 111	Gallery	Menu shortcuts 29
Banner 110	Photo 77	Menu, in-use options 28
Dialing Font 110	Video 78	Message Folders 51
Front Contrast 111	Н	Drafts folder 54
Menu Style 109	HAC 138	Inbox 51
Theme 110	Health and Safety Information 127	Messages and Lock Mode 53
Wallpaper 109	I	Outbox 53
E	Icon Glossary 126	Voicemail 55
Emergency Calls 18	Input mode 15	Message Send Options 50
END key 13	International Calls 18	Message Setting 56
Entering Text	In-use menu 28	Messaging
Alpha (Abc) Mode 31	K	Erasing Messages 55
Entering Numbers 32	Key Tone 113	Message Settings 56
Entering Symbols 32	L	microSD
Entering Upper and Lower Case	<del>-</del>	Formatting 125
Letters 32	Language 116  Launching Voice SVC 103	Mode
Text Entry Modes 30	Left soft key 12	Call answer 15
Erase All Entry 118	Lock mode 15	Input 15
Erase memos 89		Lock 15
Exit Browser 57	M	Silent 16
F	Memo Pad	Standby 16
File Save Options 122	Add a Memo 95	Talk 16

S M-Ratings 139 **Phone Settings** Multi shot 66 Airplane Mode 115 SAR values 127 N Language 116 Save pictures 65 NAM Selection 119 Screen Layouts 63 Navigation key 13 Quick Search 120 Navigation key shortcuts 28 Security Settings Set Time 119 Number Entry Dialing 18 Change Lock 117 Shortcut Key 121 Emergency # 117 0 System Select 119 Erase All Entry 118 **OK kev** 12 Photo gallery 77 Lock Phone 116 Р **Photos** Resetting Your Phone 118 Personal Organizer Sending 79 Restriction 118 Alarm Clock 95 Picture (Pic) message 47 SEND kev 13 Calculator 98 Send Pic messages 79 Calendar 92 Quality, pictures 67, 74 Set Time 119 Memo Pad 95 Ouick Search Setinas Voice Memo 88 Location 108 Dialing 20 World Time 97 Setting 120 Settings Phone Info R Call Settings 113 Icon Glossarv 126 Display 108 **Receiving New Messages** 50 Phone Number 125 Display Settings 108 While in a Call 51 Version 126 Kev Tone 113 Record memos 88 Phone Memory Memory Info 122 Resetting Your Phone 118 Freeing 123 Security Settings 116 Return to last menu 28 Usage Info 122 Setup Right soft key 12 Phone Number 125 Voicemail 51 Roaming 27 Phone Safety 137

Shortcut Key 121	U
Shortcut to menus 29	UL Certification 128
Shutter sound 71	Understanding Your Contacts
Silent mode 16	Adding a New Contact Entry 34
Sounds Settings	Deleting a Contact Entry 44
Alerts 112	Editing an Existing Contact Entry 40
Key Tone 113	Finding a Contact Entry 37
Ringer Type 112	Memory 45
Volume/Vibrate 111	Pauses 40
Speakerphone Key 16	Understanding Your Phone
Speed Dialing 19	Closed View of Your Phone 9
One-Touch Dialing 19	Command Keys 12
Three Touch Dialing 19	Display Screen 14
Two-Touch Dialing 19	Features of Your Phone 9
Standard Limited Warranty 146	Front View of Your Phone 10
Standby mode 16	V
T	Version 126
Talk mode 16	Video gallery 78
Text Conventions 4	Video message 48
Text message 46	Voice Dialing 20
Tools	Voice Launch 106
Tools Menu 90	Voice Memo 88
T-Ratings 139	Erase all memos 89
TTY Mode 114	Record memos 88
	Review memos 88

Voice Privacy 115
Voice SVC
Launching 103
Voicemail 51
Checking 51
Setup 51
VoiceSignal
About VoiceSignal 107
Voice Memos 88

Warranty Information 146